
# JVC

# SERVICE MANUAL

**COLOUR TELEVISION** 

# AV-29FH1BUG, AV-29FH1SUG



#### **TABLE OF CONTENTS**

1	PRECAUTION	1-3
2	SPECIFIC SERVICE INSTRUCTIONS	1-4
3	DISASSEMBLY	1-5
4	ADJUSTMENT	1-8
5	TROUBLESHOOTING	1-12

## **SPECIFICATION**

Items		Co	ntents
item	S	AV-29FH1BUG	AV-29FH1SUG
Dimensions (W×F	H×D)	81.2cm × 60.1cm × 52.2cm	
Mass		40kg	
TV RF System		CCIR (B/G, D/K, I, L/L')	
Colour System		PAL / SECAM / NTSC (Only in EXT mode)	
Stereo System	1 1 1	A2 (B/G, D/K) / NICAM (B/G, I, D/K, L)	S A MINIST
Teletext System		Fastext (UK system)	
		TOP (German system)	
		WST(World standard system)	E COUNTY OF
Receiving	VHF	47MHz ~ 470MHz	
Frequency	UHF	470MHz ~ 862MHz	
	French CATV	116MHz ~ 172MHz / 220MHz ~ 469MHz	
Intermediate	VIF Carrier	38.9MHz (B/G, D/K, I , L) / 33.95MHz (L')	AL REAL PROPERTY.
Frequency	SIF Carrier	33.4MHz (5.5MHz:B/G) / 32.9MHz (6.0MHz:I) / 32.4MHz (6.5MHz:L, D/K) / 40.45MHz (6.5MHz:L')	
Colour Sub	PAL	4.43MHz	
Carrier Frequency	SECAM	4.40625MHz / 4.25MHz	THE PARTY DESIGNATION OF THE PARTY OF THE PA
	NTSC	3.58MHz / 4.43MHz	
Power Input		AC220V ~ AC240V, 50Hz	205
Power Consumptio	n	84W, standby : 3W	
Aerial Input Ter <mark>min</mark>	al	75 $\Omega$ unbalanced, coaxial	
Picture Tube		Visible size : 68cm (Measured diagonally)	
Audio Power Output		7W + 7W	
EXT-1 / EXT-2 (Input / Output)		21-pin Euro connector (SCART socket × 2)	
EXT-3 (Input)	Video	1V(p-p) 75Ω (RCA pin jack × 1)	
	Audio (L/R)	500mV(rms) (-4dBs), High impedance (RCA	oin jack × 2)
Headphone J <mark>ack</mark>		Stereo mini jack (Ø3.5mm) x 1	A COLUMN TO THE REAL PROPERTY OF THE PARTY O
Remote Control Un	it	RM-C1514B (AAA/R03 dry battery x 2)	RM-C1514 (AAA/R03 dry battery × 2)

Design & specifications are subject to change without notice.

# SECTION 1 PRECAUTION

#### 1.1 SAFETY PRECAUTIONS

- (1) The design of this product contains special hardware, many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
- (2) Alterations of the design or circuitry of the products should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
- (3) Many electrical and mechanical parts in the products have special safety-related characteristics. characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the parts list of Service manual. Electrical components having such features are identified by shading on the schematics and by ( A ) on the parts list in Service manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the parts list of Service manual may cause shock, fire, or other hazards.
- (4) Don't short between the LIVE side ground and ISOLATED (NEUTRAL) side ground or EARTH side ground when repairing.

Some model's power circuit is partly different in the GND. The difference of the GND is shown by the LIVE:  $(\bot)$  side GND, the ISOLATED (NEUTRAL):  $( \ \ \ \ \ \ \ \ )$  side GND and EARTH:  $(\ \ \ \ \ \ \ )$  side GND.

Don't short between the LIVE side GND and ISOLATED (NEUTRAL) side GND or EARTH side GND and never measure the LIVE side GND and ISOLATED (NEUTRAL) side GND or EARTH side GND at the same time with a measuring apparatus (oscilloscope etc.). If above note will not be kept, a fuse or any parts will be broken.

- (5) If any repair has been made to the chassis, it is recommended that the B1 setting should be checked or adjusted (See B1 POWER SUPPLY check).
- (6) The high voltage applied to the picture tube must conform with that specified in Service manual. Excessive high voltage can cause an increase in X-Ray emission, arcing and possible component damage, therefore operation under excessive high voltage conditions should be kept to a minimum, or should be prevented. If severe arcing occurs, remove the AC power immediately and determine the cause by visual inspection (incorrect installation, cracked or melted high voltage harness, poor soldering, etc.). To maintain the proper minimum level of soft X-Ray emission, components in the high voltage circuitry including the picture tube must be the exact replacements or alternatives approved by the manufacturer of the complete product.
- (7) Do not check high voltage by drawing an arc. Use a high voltage meter or a high voltage probe with a VTVM. Discharge the picture tube before attempting meter connection, by connecting a clip lead to the ground frame and connecting the other end of the lead through a 10kΩ 2W resistor to the anode button.

- (8) When service is required, observe the original lead dress. Extra precaution should be given to assure correct lead dress in the high voltage circuit area. Where a short circuit has occurred, those components that indicate evidence of overheating should be replaced. Always use the manufacturer's replacement components.
- (9) Isolation Check (Safety for Electrical Shock Hazard)
  After re-assembling the product, always perform an isolation check on the exposed metal parts of the cabinet (antenna terminals, video/audio input and output terminals, Control knobs, metal cabinet, screw heads, earphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.

#### a) Dielectric Strength Test

The isolation between the AC primary circuit and all metal parts exposed to the user, particularly any exposed metal part having a return path to the chassis should withstand a voltage of 3000V AC (r.m.s.) for a period of one second. (.

. . . Withstand a voltage of 1100V AC (r.m.s.) to an appliance rated up to 120V, and 3000V AC (r.m.s.) to an appliance rated 200V or more, for a period of one second.) This method of test requires a test equipment not generally found in the service trade.


#### b) Leakage Current Check

Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.). Using a "Leakage Current Tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground (water pipe, etc.). Any leakage current must not exceed 0.5mA AC (r.m.s.). However, in tropical area, this must not exceed 0.2mA AC (r.m.s.).

#### Alternate Check Method

Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.). Use an AC voltmeter having  $1000\Omega$  per volt or more sensitivity in the following manner. Connect a  $1500\Omega$  10W resistor paralleled by a  $0.15\mu F$  AC-type capacitor between an exposed metal part and a known good earth ground (water pipe, etc.). Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75V AC (r.m.s.). This corresponds to 0.5mA AC (r.m.s.).

However, in tropical area, this must not exceed 0.3V AC (r.m.s.). This corresponds to 0.2mA AC (r.m.s.).




# SECTION 2 SPECIFIC SERVICE INSTRUCTIONS

#### 2.1 21-pin Euro connector (SCART) : EXT-1/EXT-2

Pin No.	Signal designation	Matching value	EXT-1	EXT-2
1	AUDIO R output	500mV(rms) (Nominal), Low impedance	Used (TV OUT)	Used (LINE OUT)
2	AUDIO R input	500mV(rms) (Nominal), High impedance	Used (R1)	Used (R2)
3	AUDIO L output	500mV(rms) (Nominal), Low impedance	Used (TV OUT)	Used (LINE OUT)
4	AUDIO GND	USA STATE OF THE STATE OF T	Used	Used
5	GND (B)	I ESSERVINITE COVERNIA	Used	Used
6	AUDIO L input	500mV(rms) (Nominal), High impedance	Used (L1)	Used (L2)
7	B input	700mV <sub>(B-W)</sub> , 75 Ω	Used	NC
8	FUNCTION SW (SLOW SW)	Low: 0V-3V, High: 8V-12V, High impedance	Used	NC
9	GND (G)		Used	NC
10	SCL / T-V LINK		Not used	NC
11	G input	700mV(B-W), 75 Ω	Used	NC
12	SDA	44.0	Not used	NC
13	GND (R)	-20	Used	Used
14	GND (YS)	1000	Used	Used
15	R / C input	R : 700mV <sub>(B-W)</sub> , 75 Ω C : 300mV <sub>(P-P)</sub> , 75 Ω	Used (R)	Used (C)
16	Ys input (FAST SW)	Low: 0V-0.4V, High: 1V-3V, 75 Ω	Used	NC
17	GND (VIDEO output)		Used	Used
18	GND (VIDEO input)		Used	Used
19	VIDEO output	$1V_{(P-P)}$ (Negative sync), 75 $\Omega$	Used (TV OUT)	Used (LINE OUT)
20	VIDE <mark>O / Y input</mark>	$1V_{(P-P)}$ (Negative sync), 75 $\Omega$	Used	Used
21	COMMON GND		Used	Used

(P-P= Peak to Peak, B-W= Blanking to white peak)



# SECTION 3 DISASSEMBLY

#### 3.1 DISASSEMBLY PROCEDURE

#### 3.1.1 REMOVING THE REAR COVER

- (1) Unplug the power cord.
- (2) Remove the 8 screws [A].
- (3) Remove the 1 screw [B].
- (4) Withdraw the REAR COVER toward you.

#### 3.1.2 REMOVING THE SIDE SPEAKER

- · Remove the REAR COVER.
  - (1) Remove the 4 screws [D], attaching the SPEAKER.
  - (2) Follow the same steps when removing the other hand SPEAKER.

#### 3.1.3 REMOVING THE PFC FILTER PWB

- Remove the REAR COVER.
  - (1) Remove the 2 screws [C] as shown in the figure.
  - (2) Take off the 2 connectors linking chassis to PFC FILTER PWB and withdraw the PFC FILTER PWB.

#### 3.1.4 REMOVING THE MAIN PWB

- Remove the REAR COVER.
  - (1) Slightly raise the both sides of the MAIN PWB by hand and withdraw the MAIN PWB backward. (If necessary, take off the wire clamp, connectors etc.)

#### 3.1.5 CHECKING THE PW BOARD


- . To check the back side of the PW Board.
  - (1) Pull out the MAIN PWB. (Refer to REMOVING THE MAIN PWB)
  - (2) Erect the MAIN PWB vertically so that you can easily check the back side of the PW Board.

#### 3.1.6 CAUTION

- When erecting the MAIN PWB, be careful so that there will be no contacting with other PW Board.
- Before turning on power, make sure that the wire connector is properly connected.
- When conducting a check with power supplied, be sure to confirm that the CRT EARTH WIRE (BRAIDED ASS'Y) is connected to the CRT SOCKET PW board.

#### 3.1.7 WIRE CLAMPING AND CABLE TYING

- (1) Be sure to clamp the wire.
- (2) Never remove the cable tie used for tying the wires together.
  - Should it be inadvertently removed, be sure to tie the wires with a new cable tie.



#### 3.2 REPLACEMENT OF MEMORY IC

#### 3.2.1 MEMORY IC

This TV use memory IC. In the memory IC, there are memorized data for correctly operating the video and deflection circuits. When replacing memory IC with a blanking memory IC, the set is automatically memorized following SERVICE MANU initial data.

#### 3.2.2 SERVICE MENU ADJUSTMENT ITEMS

There are 21 SERVICE ADJUSTMENT ITEMS. After replacing memory IC, automatically memorized following initial data.

No.	Adjustment	titem
1	HOR CEN	
2	RED GAIN	THE STATE OF
3	GRN GAIN	La State
4	BLUE GAIN	THE REAL PROPERTY.
5	RED BIAS	1 5 11
6	GRN BIAS	= 77
7	AGC LEVEL	I I I I I
8	G2-SCREEN	
9	AFT	59.5
10	OPTION1	F4:0 ==
11	OPTION2	mile .
12	AVL	2008
13	PARAB <mark>OLA</mark>	
14	HOR WIDTH	STATE OF THE PARTY
15	CORNER T	No. of Street
16	CORNER B	
17	HOR PARAL	
18	V. LINEAR	
19	EW TRAPEZ	
20	S CORRECT	
21	VERT CENT	
22	VERT SIZE	
23	SHIPPING	

#### 3.2.3 FACTORY SETTING

#### 3.2.3.1 FRONT BUTTON SETTING AND INITIAL SEETING

Item	Value
MAIN POWER	OFF(SUB POWER ON)
PR POSITION	01
INPUT MODE	TV

#### 3.2.3.2 USER MENU SETTING

Item	50 KH 18	Value
	PICTURE	
BRIGHTNESS	Center	
CONTRAST	Center	
COLOUR	Center	
SHARPNESS	Center	
TINT	Center	
NOISE RED.	WEAK	
12.25 A. H. H. H.	SOUND	
VOLUME	18	
BALANCE	Center	
BASS	Center	
TREBLE	Center	
E F	EATURES	
CHILD LOCK	OFF	
WAKE TIME	OFF	
WAKE PROG.	01	
CLOCK	:	
CLOCK PROG	01	
PROG. INFO	ON	
ZOOM AUTO	4:3	
LANGUAGE	GB	
	INSTALL	
ATSS	Others	
EDIT		
SYSTEM	EURO	
CHANNEL	C 02	
FREQUENCY	048. 25	
NAME		
PROGRAM	01	
STORE TO	01	

#### 3.3 REPLACEMENT OF CHIP COMPONENT

#### 3.3.1 CAUTIONS

- (1) Avoid heating for more than 3 seconds.
- (2) Do not rub the electrodes and the resist parts of the pattern.
- (3) When removing a chip part, melt the solder adequately.
- (4) Do not reuse a chip part after removing it.

#### 3.3.2 SOLDERING IRON


- (1) Use a high insulation soldering iron with a thin pointed end of it.
- (2) A 30w soldering iron is recommended for easily removing parts.

#### 3.3.3 REPLACEMENT STEPS


1. How to remove Chip parts

#### [Resistors, capacitors, etc.]

(1) As shown in the figure, push the part with tweezers and alternately melt the solder at each end.



(2) Shift with the tweezers and remove the chip part.



#### [Transistors, diodes, variable resistors, etc.]

(1) Apply extra solder to each lead.



(2) As shown in the figure, push the part with tweezers and alternately melt the solder at each lead. Shift and remove the chip part.




#### NOTE:

After removing the part, remove remaining solder from the pattern.


#### 2. How to install Chip parts

[Resistors, capacitors, etc.]

(1) Apply solder to the pattern as indicated in the figure.



(2) Grasp the chip part with tweezers and place it on the solder. Then heat and melt the solder at both ends of the chip part.



#### [Transistors, diodes, variable resistors, etc.]

- (1) Apply solder to the pattern as indicated in the figure.
- (2) Grasp the chip part with tweezers and place it on the solder.
- (3) First solder lead A as indicated in the figure.



(4) Then solder leads B and C.



# SECTION 4 ADJUSTMENT

#### 4.1 ADJUSTMENT PREPARATION

- (1) There are 2 ways of adjusting this TV: One is with the REMOTE CONTROL UNIT and the other is the conventional method using adjustment parts and components.
- (2) Make sure that connection is correctly made AC to AC power source.
- (3) Turn on the power of the TV and measuring instruments for warning up for at least 30 minutes before starting adjustments.
- (4) If the receive or input signal is not specified, use the most appropriate signal for adjustment.
- (5) Never touch the parts (such as variable resistors, transformers and condensers) not shown in the adjustment items of this service adjustment.

#### 4.2 MEASURING INSTRUMENT AND FIXTURES

- (1) DC voltmeter (or digital voltmeter)
- (2) Signal generator (Pattern generator : PAL / SECAM / NTSC)
- (3) Remote control unit.

#### 4.3 BASIC OPERATION OF SERVICE MENU

#### 4.3.1 TOOL OF SERVICE MENU OPERATION

Operate the SERVICE MENU with the REMOTE CONTROL UNIT.

#### 4.3.2 SERVICE ADJUSTMENT ITEMS

There are 23 adjustment items.

No.	Adjustm <mark>ent item</mark>	No.	Adjustment item
1	HOR CEN	13	PARABOLA
2	RED GAIN	14	HOR WIDTH
3	GRN GAIN	15	CORNER T
4	BLUE GAIN	16	CORNER B
5	RED BIAS	17	HOR PARAL
6	GRN BIAS	18	V. LINEAR
7	AGC LEVEL	19	EW TRAPEZ
8	G2-SCREEN	20	S CORRECT
9	AFT	21	VERT CENT
10	OPTION1	22	VERT SIZE
11	OPTION2	23	SHIPPING
12	AVL		

#### 4.3.3 HOW TO ENTER SERVICE MENU

- (1) Press [i](Information) key and [成](Muting) key same time then enter SERVICE MENU.
- (2) Adjust sharpness to minimum and exit all menus.
- (3) Within 2 seconds press the key sequence [RED]-[GREEN]-[MENU]key.

#### 4.3.4 SELECTION OF MENU SCREEN


 Press [▲]/[▼] keys of the REMOTE CONTROL UNIT and select adjustment item.

#### 4.3.5 SETTING VALUE OF ADJUSTMENT ITEMS


(1) Press [ ◀ ] / [ ▶ ] keys of the REMOTE CONTROL UNIT and setting value of adjustment items.

#### 4.3.6 HOW TO EXIT SERVICE MENU

(1) Press [MENU] key, then exit SERVICE MENU.



SERVICE MENU SCREEN



REMOTE CONTROL UNIT

#### 4.4 ADJUSTMENT PROCEDURE

#### 4.4.1 LOCAL OSCILLATOR ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description	
AFT adjustment	Signal generator Remote control unit   \$\int_{1502}\$ \$\int_{1501}\$  L150  TUNER    B01	MAIN PWE	AFT coil : (L150) [MAIN PWB]	(1) Receive a colour bar pattern signal. (2) The frequency of the signal carrier must be a (Max +/-10kHz deviation from the nominal of frequency). (3) Select < AFT >. (4) Adjust the AFT coil (L150) to bring the cursor tral poison.  Cursor  SERVICE VO. 31A TP 119  +00057 AFT LEVEL	channel

## 4.4.2 AGC

Item	Measuring instrument	Test point	Adjustment part	Description
AGC adjustment	Signal generator		AGC	<ul> <li>(1) Receive a colour bar pattern signal.</li> <li>(2) Select &lt; AGC &gt;.</li> <li>(3) Press the [OK] key and wait until AGC level stabilize</li> </ul>
	Remote control unit			to the optimum value.

#### 4.4.3 FOCUS ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
FOCUS adjustment	Signal generator  Remote control unit		FOCUS VR [On FBT]	(1) Receive a cross-hatch signal. (2) Adjust the FOCUS volume on the FBT to have the best resolution on the screen.
	FBT	FOCU SCRE		

#### 4.4.4 SCREEN ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
SCREEN adjustment	Signal generator		G2-SCREEN SCREEN VR	<ul><li>(1) Receive a colour bar pattern signal.</li><li>(2) Select &lt; G2-SCREEN &gt;.</li><li>(3) Adjust the SCREEN VR on the FBT to bring the</li></ul>
	Remote control unit		[On FBT]	cursor to central position.

#### 4.4.5 WHITE BALANCE ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
WHITE	Signal		RED BIAS	(1) Receive a black and white pattern signal (colour off).
BALANCE adjustment	generator	1	GRN BIAS	(2) Select < RED BIAS >, < GRN BIAS > and adjust the screen until the black portion in the screen becomes
-	Remote		RED GAIN	black.
	control unit		GRN GAIN BLUE GAIN	(3) Select < RED GAIN >, < GRN GAIN >, < BLUE GAIN > and adjust the screen until the white portion in the screen become white.

#### 4.4.6 DEFLECTION CIRCUIT ADJUSTMENT

Item	Me <mark>asuring</mark> instrument	Test point	Adjustment part	Description
VERTICAL GEOMETORY adjustment	Signal generator  Remote control unit	19.7	V. LINEAR S CORRECT VERT SIZE VERT CENT	(1) Receive a circle pattern signal. (2) Select < V. LINEAR >(Veretical linearity), < S CORRECT > (S correction), < VERT SIZE >(Vertical size), < VERT CENT >(Vertical center) respectively. (3) Adjust to compensate for vertical distortion.
			+	
HORIZONTAL POSITION adjustment	Signal generator  Remote control unit		HOR CEN	<ul> <li>(1) Receive a circle pattern signal.</li> <li>(2) Select &lt; HOR CEN &gt; (Horizontal center).</li> <li>(3) Adjust to have the picture in the center of the screen.</li> </ul>

Item	Measuring instrument	Test point	Adjustment part	Description
HORIZONTAL GEOMETORY adjustment	Signal generator  Remote control unit		PARABOLA HOR WIDTH CORNER HOR PARAL EW TRAPEZ	(1) Receive a cross-hatch pattern signal. (2) Select < PALABOLA >(Side pin), < HOR WIDTH: (Horizontal width), < CORNER >(Top/botton corner), < HOR PARAL >(Horizontal parallel), < EV TRAPEZ >(Trapezium).
		113		(3) Adjust these items to compensate for geometrical distortion.
	P/	ARABOLA		
	H	OR WIDTH		
		CORNER		
	н	OR PARAL		
	E	W TRAPEZ		

# SECTION 5 TROUBLESHOOTING This service manual does not describe TROUBLESHOOTING. 1-12 (No.YA008)









# InteriArt **T-VLINK**


# AV-29FH1SUG AV-29FH1BUG

# **COLOUR TELEVISION**

**INSTRUCTIONS** 

FARBFERNSEHGERÄT
TELEVISEUR COULEUR
KLEURENTELEVISIE
TELEVISOR A COLOR
TELEVISORE A COLORI
TELEVISOR A CORES

BEDIENUNGSANLEITUNG
MANUEL D'INSTRUCTIONS
GEBRUIKSAANWIJZING
MANUAL DE INSTRUCCIONES
ISTRUZIONI
INSTRUÇÕES



Thank you for buying this JVC colour television.

To make sure you understand how to use your new TV, please read this manual thoroughly before you begin.

# **IMPORTANT SAFEGUARDS**

#### 1. WATER AND MOISTURE

The apparatus shall not be exposed to dripping or splashing water and no object filled with liquids, such as vases , should be placed on the apparatus.

#### 2. HEAT

Never place the set near heat sources.

Never put a naked flame, such as a candle, on the top of TV set.

#### 3. VENTILATION

Do not cover the ventilation openings in the cabinet and never place the set in a confined space such as in a bookcase or built-in cabinet unless proper ventilation is provided. Leave a minimum 10 cm gap all around the unit.

#### 4. OBJECT ENTRY

Do not insert foreign objects, such as needles and coins, in the ventilation openings.

#### 5. LIGHTNING STRIKE

You should disconnect the set from the mains and the aerial system during thunderstorms.

#### 6. CLEANING

Unplug the set from the mains while cleaning.

#### 7. AFTER MOVING THE SET

If the set is moved or turned, the MAIN POWER button must be switched off for at least 15 minutes in order to take out colour patches on the screen.

#### 8. CAUTION

There is danger of choking or suffocation if the cap which is removed from the TV is accidentally swallowed by children. Store the cap out of the reach of children.


# **CONTENTS**

MPORTANT SAFEGUARDS	1
DENTITY OF LOCAL & REMOTE CONTROL	2
SETTING UP	3
START UP	3
NSTALLATION	
TV-LINK FUNCTION	
DAILY USE	8
TELETEXT	
CONNECTING EXTERNAL EQUIPMENT	
TROUBLESHOOT NG	
SPEC F CAT ONS	16

# **ENGLISH**

# **IDENTITY OF LOCAL & REMOTE CONTROL**

#### LOCAL CONTROL




 $\overline{\Pi} \cap \overline{\Pi} \cap \overline{\Pi}$ 

 $\overline{\dots}$ 


#### REMOTE CONTROL


SCART 1 socket EXT-1

SCART 2 socket EXT-2 -




# **SETTING UP**






Warning: be careful to respect battery polarities.



Insert the main plug into a 220 - 240V 50Hz AC power socket.




Connect aerial to aerial jack. It is usually connected by means of a 75 ohm cable.

# **START UP**

#### **SWITCHING ON**

Switch the TV set on with the MAIN POWER button (B1).



## **LANGUAGE MENU**

The very first time that you turn on the TV, the **LANGUAGE** menu will appear on the screen. Its purpose is to enable you to select the language that will be used for all the OSD (On Screen Display) menus. The user must enter a choice of language before proceeding further.

The descriptions used in the menu are those of the country code (e.g. GB = English, NL = Holland etc).



#### **LANGUAGE**

BG CZ D DK E F FIN GB GR H I N NL PL RO RUS S

Selection is made by use of the remote control CURSOR UP (A11) / CURSOR DOWN (A12) buttons and CURSOR LEFT (A13) / RIGHT (A14) buttons. Once you are satisfied with your selection, push the OK button (A9) to confirm your choice, and then the menu will disappear.

The language entered at this stage can still be modified at any later time, by entering the LANGUAGE selection (accessed from the FEATURES menu page 11).

Note: The languages shown are subject to modification without prior notice.

# **INSTALLATION**

#### **AUTO TUNING SYSTEM**

#### **MENU SELECTION**

Press remote control MENU button (A10) to display the MAIN MENU.

Move the cursor to INSTALL by using the remote control CURSOR UP (A11),DOWN(A12) buttons.

Then press the remote control OK button (A9).

Note: All menus are removed within 60 seconds if you don't press any button.





#### INSTALL ATSS EDIT

SYSTEM
CHANNEL
FREQUENCY
NAME
PROGRAM
STORE TO

GB C 31 551.25 BBC1 01

GB

#### **COUNTRY SELECTION**

Position the cursor at **ATSS** Menu and select country code where TV is used by pressing the remote control **CURSOR LEFT** (A13), **RIGHT**(A14) buttons.

The following countries can be selected.

A, B, CH, CZ, D, DK E, F, FIN, GB, H, I, IRL, N, NL, P, PL, S, SK, Others

#### ATSS - Auto Tuning and Sorting System

After selecting country code, press and hold OK button for 3 - 4 seconds until "Please wait!" is displayed, then auto program tuning starts searching all the available TV stations in your area. When auto tuning and sorting is completed, the EDIT menu with the recorded programs appears on the screen.

You can proceed to edit the the program numbers using the EDIT functions. For details, see "EDIT MENU" below. If you do not need to use the EDIT functions, go to next step to download the data to VCR with the T-V LINK function.

To exit the **EDIT** menu, press **MENU** button 3 times, then the menu display will disappear from **TV** screen. Now you can select program using the remote control **UP** (A11) or **DOWN** (A12) buttons.


#### **EDIT MENU**

The **EDIT** menu shows you the programme position assignment. When using the **AUTO TUNING** method, the broadcasts may not be found and stored in the order you desired. For example, BBC1 may not be allocated to programme number 01, and BBC2 may not be allocated to programme number 02, etc. The **EDIT** menu enables you to change the programme position assignment according to your personal preference.

To reach the **EDIT** menu you have to first select **INSTALL** menu from the **MAIN** menu.

#### CHANGING ORDER OF CHANNELS

Position the cursor to the programme number you want to move and press the remote control **GREEN** (A5) **MOVE** button. The programme turns to red colour. Then use the **UP** (A11) or **DOWN** (A12) buttons to move the programme number you wish to store it to and press **MOVE** button again to confirm the operation. Press **MENU** to return to **INSTALL** menu.








#### **DELETE PROGRAMME POSITION DATA**

Position the cursor to the programme number you wish to delete using the remote control **UP** (A11) or **DOWN** (A12) buttons. Press the **YELLOW/DELETE** (A6) button.





#### SKIPPING THE CHANNELS

Position the cursor to the programme number you wish to skip, then press the **RED** (SKIP) (A4) button. A skipped programme is marked with the sign " v " at its right end. The channel corresponding to a skipped programme will not appear on screen when changing channels using **PROGRAM UP** (A11) / **DOWN** (A12) buttons.



#### USING THE DECODER (EXT -2) FUNCTION WITH T-V LINK:

When connecting a T-V IINK compatible VCR to the EXT-2 terminal, be sure to connect the Decoder to the VCR. If not the T-V LINK function may not work properly.

Position the cursor to the channel capable of being unscrambled with the decoder on EXT-2, then press the "CYAN" (A7) button. A channel functioning with a decoder is marked with the icon of a key beside the program number.

Even if the decoder is functioning a scrambled picture appears at this time. The decoded signal won't be visible until you exit **EDIT** and **INSTALL** menus.

#### DOWNLOADING THE DATA TO VCR WITH T-V LINK

In the **EDIT** menu, you can transmit the latest Program number data to the VCR with the T-V LINK function. To start the data transfer, you must press and hold OK button for 3-4 seconds until "TV VCR" is displayed flashing in the header of **EDIT** menu.

Caution: This operation will only be successful if a T-V LINK compatible VCR is connected to the EXT-2 terminal, and if the VCR is ON.

Once the data transmission ends, the "TV VCR" indicator disappear and the EDIT menu vanishes after 3 sec.

**Note**: If the TV is unable to transfer the data, the feature not available is displayed in the header of EDIT menu in red to indicate an error. In such case, ensure the following three items are correct.

- Has the T-V LINK compatible VCR been connected to the EXT-2 terminal?
- Has the VCR power been turned ON?
- Does the SCART cable that is connected to the EXT-2 terminal to proper connections?

If above is OK, then press and hold 3-4 seconds again.

#### MANUAL CHANNEL TUNING

Tuning by **ATSS** (Auto Tuning Sorting System) is recommendable, as it is the easiest tuning method. But Manual Tuning is also possible using the following procedure.

#### **BROADCASTING SYSTEM SELECTION**

Select **INSTALL** menu and using the remote control **CURSOR UP** (A11) / **DOWN** (A12) buttons, move the cursor to **SYSTEM** menu and select the appropriate system by the **LEFT** (A13) or **RIGHT** (A14) button.

"FRANCE"	France	<b>SECAM</b>	1/1'
IIVAINOL	Tance	SECAIN	느/느

"GB"	Great Britain / Ireland PAL-I/I'
"EURO"	Westen Europe PAL-SECAM B/G
"E/EURO"	Eastern Europe PAL-SECAM D/K

INSTALL	
ATSS	GB
EDIT	
SYSTEM	GB
CHANNEL	C 49
FREQUENCY	551.25
NAME	BBC1
PROGRAM	01
STORE TO	01

#### **ACTIVATING MANUAL TUNING**

Move the cursor to **FREQUENCY** (channel frequency) menu and press and hold for more than 2 seconds the remote control **CURSOR LEFT** (A13) or **RIGHT** (A14) buttons. When one channel is tuned, the corresponding station name is indicated automatically in **NAME** menu.

To tune the next channel, press the remote control CURSOR LEFT (A13) or RIGHT (A14) buttons again.

#### CHANNEL AND FREQUENCY MENU

If you know the channel or frenquency number you want to search, enter the data by 0...9 buttons. TV will tune that channel quickly.

#### PERFORM FINE TUNING

If you are unable to obtain good picture or reasonable sound volume due to poor reception it is possible to perform fine tuning. - Select the "FREQUENCY" menu.

- Press for less than 2 seconds, the remote control CURSOR LEFT (A13) and CURSOR RIGHT (A14) buttons to activate FINE TUNING in steps of 0.05 MHz(50kHz).

#### STORING CHANNEL NAME

When one channel is tuned, the corresponding station NAME will be detected automatically. But in some cases, NAME will not be detected due to the broadcasting situation. You may put in the channel NAME yourself.

Position the cursor to **NAME** menu and press the remote control **CURSOR RIGHT**(A14) button. A cursor appears on the left end of NAME line ("----"). Then press **CURSOR UP** (A11) or **DOWN** (A12) buttons untill you get the right letter or symbol. Move the cursor to the next position by using **CURSOR LEFT** (A13) or **RIGHT** (A14) buttons and repeat the operation. Press **OK** (A9) button to store the NAME.

#### PROGRAM MENU

The number on the right side of the PROGRAM menu indicates the program number of the currently displayed channel.

#### STORE TO MENU

Select **STORE TO** menu and select the program number by 0....9 buttons or **CURSOR LEFT** (A13) or **RIGHT** (A14) buttonsto which you want to store the currently displayed channel then press **OK** button.

Warning! If you store the number already programmed, the previous programmes will be erased automatically.

#### CAUTION TO T-V LINK COMPATIBLE VCR USER:

After any channel arrangement modification you must also update the data memorised in your VCR. This can be done easily with the T-V LINK. See page 5 : DOWNLOADING THE DATA TO VCR.



# **T-V LINK FUNCTIONS**

When a T-V LINK compatible VCR is connected to the EXT-2 Terminal on the TV, it is easier to set up the VCR and to view videos. T-V LINK uses the following features:

#### TO USE T-V LINK FUNCTIONS:

A T-V LINK compatible VCR is necessary.

The VCR must be connected to the EXT-2 terminal on the TV by a fully wired SCART cable.

Note: A "T-V LINK compatible VCR means a JVC VCR with the T-V LINK logo or a VCR with one of the following logos. However, these VCRs may support some or all of the features described below. For details, refer to your VCR insturction manual,

"Q-LINK" (a trademark of Panasonic Corporation)

"Data Logic" (a trademark of Metz Corporation)

"Easy Link" (a trademark of philips Corporation)

"Megalogic" (a trademark of Grundig Corporation)

"SMARTLINK" (a trademark of Sony Corporation)

#### PRE-SET DOWNLOAD

Download the registred data on the TV channels from the TV to the VCR.

The Preset Download function must be used when the initial setting is complete or whenever the AUTO PROGRAM or EDIT/MANUAL operations are performed.

Note: This function can be operated via VCR operation.

When "TV VCR" is displayed in red :

If "TV VCR" is displayed in red, the download was not performed correctly. Before trying to download again, ensure the following:

- The VCR power is turned on.
- The VCR is T-V LINK compatible
- The VCR is connected to the EXT-2 terminal
- The SCART cable is fully wired.

If all points are OK, please press and hold OK button 3-4 seconds.

#### DIRECT REC.

#### "What You See is What You Record"

You can record to VCR the images that you are currently viewing on TV by a simple operation.

For detalis, read the manual for your VCR.

The recording is initialed by the VCR.

Caution: When recording images from an external device connected to the TV, the VCR will stop recording if the TV is turned off or if the input is switched.

The direct recording is not possible under following condition :

- When INSTALL or EDIT menu are on screen.
- When watching teletext

Note: - Operation via the TV is not possible

- Generally, the VCR cannot record a TV channel that cannot be received properly by the VCR's tuner, even though you can view that TV channel on the TV. However, some VCR's can record a TV channel by using the TV's output if that channel can be viewed on the TV, even though the TV channel cannot be received properly by the VCR's tuner. For details, refer to your VCR instruction manual.
- When the signal source is RGB, direct recording function may not operate properly. To check if the TV signal source is RGB, press 'i' key, the program status display will indicate "EXT-1 RGB".

#### TV AUTO POWER ON/VCR IMAGE VIEW

When the VCR starts playing, the TV automatically turns on and the images from EXT-2 terminal are displayed on the screen. When the VCR menu is operated, th TV automatically turns on and the image from EXT-2 terminal are displayed on the screen.

Note: This function does not operate if your TV's main power is turned off. Set your TV's main power to on (standby mode).

# **DAILY USE**

#### SWITCHING ON AND OFF TV SET

#### **SWITCHING ON**

If stand-by indicator (B6) is not lit, then the TV set is powered off. Switch the set ON with **POWER (ON/OFF)** Button  $\circlearrowleft$  (B1), then, stand-by indicator turns to red.

Press again **PROGRAM UP** or **DOWN** buttons (B10) on the front of the set, or **POWER** button (A2) or **UP/DOWN** button (A11) or, one of the NUMBER 0...9 button on the remote control, then stand-by indicator turn to green and picture appears on the screen.

If stand-by indicator (B6) is flashing red and green, TV set is in CHILD LOCK mode. To deblock CHILD LOCK, press the remote control POWER button (A2) or one of NUMBER 0...9 buttons (A3) or PROGRAM UP (A11) / DOWN (A12) buttons

Note: The front panel PROGRAM UP or DOWN (B10) button will not function when CHILD LOCK is ON.



Press POWER button (A2) on the remote control to return the set to its STAND BY mode. If you don't use the set for an extanded period of time, turn it off with MAIN POWER button (B1) on the set.





#### PROGRAM SELECTION (FROM 0 TO 99)

11	
10	
09	
08	
07	
06	CHANNEL 5
05	S4C
04	CHANNEL 4
03	ITV
02	BBC2
01	BBC1
00	
99	
98	
97	
96	
95	
94	
93	
92	
91	

#### **Direct selection**

Use the remote control NUMBER 0..9 buttons (A3). For two digit program numbers, enter the second digit within 2 seconds.

#### Up / Down selection

Use the remote control PROGRAM UP (A11) / DOWN (A12) buttons or the TV set front panel PROGRAM UP / DOWN buttons (B10).





#### LIST menu

Press on the **CYAN** button (A7) to display the **LIST** menu. Then use the **CURSOR UP** (A11) or **DOWN** (A12) buttons to browse the list and find a program, with the aid of the program numbers plus associated names (see section Manual Channel Tuning pages 5/6 for how to add or modify program names).

When you have found a program you want to select (the highlighted line in the middle of the menu), press on the **OK** button (A9) to tune this program. The **LIST** menu will disappear at the same time.

If you decide to keep the current program, the menu can be cancelled at any time by pressing on the CYAN button (A7).



#### **SOUND CONTROL**

#### Volume adjustment

Use the remote control **VOLUME UP** (A14) / **DOWN** (A13) buttons or the TV set front panel **VOLUME UP / DOWN** buttons (B9).





#### Mono forcing, dual language

- If you are unable to get good sound quality for a program due to poor reception, you can force a change from stereo to mono transmission by pressing the remote control MODE button (A26). Then the program status display will indicate "MONO" with a ( ) icon.



- On the other hand, during a program with dual language transmission, the MODE button (A26) allows you to toggle between the first and second language. The program status display will indicate "DUAL 1" or "DUAL 2" (plus NICAM according to the received signal) instead of Stereo or Mono.
- To return to initial state, press again the **MODE** button (A26).

#### Mute

- Mute the sound by pressing the remote control SOUND MUTE button (A1).
- If a sound related function is used (e.g. VOLUME, 

  ) then the **MUTE** will also be cancelled.



#### Sound effects

A SPATIAL sound effect is available, by using the remote control (A5) button.



The following display appears:



To return to initial sound effect, press again the ⊕ (A5) button. The following display appears:



For other adjustments such as BALANCE, BASS or TREBLE use the **SOUND** menu (here under).

#### **SOUND MENU**

Select SOUND menu from the MAIN menu.

- Select **VOLUME** function to adjust the volume level.
- Select BALANCE function to adjust sound balance between the left and right speakers. If the indicator is highlighted in red, then the central balance position has been found.
- Select the BASS and TREBLE functions to adjust the tone levels.

# SOUND VOLUME BALANCE BASS TREBLE

#### PICTURE CONTROL

Select PICTURE menu from the MAIN menu.

- Select and adjust the level of each function: BRIGHTNESS, CONTRAST, COLOUR, SHARPNESS, TINT (if available) and NOISE REDUCTION.
- The above modified values are automatically stored in FAVOURITE mode.
- NOISE REDUCTION feature has 4 levels according to your preference.
- The FAVOURITE preset contains the settings that you lastly entered.

If the NTSC standard is detected (eg from VHS player connected to EXT-1), then TINT will be available. Otherwise, TINT will be displayed but not selectable.





You can select three pictures settings, by pressing repeatedly the remote control PICTURE/OK button (A9):

- NORMAL I (standard hard picture)
- NORMAL II (standard soft picture)
- FAVORITE.

01 BBC1

NORMAL I

\$\text{\$\exititit{\$\text{\$\exitititt{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\exititit{\$\text{\$\text{\$\exititit{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$

01 BBC1

NORMAL II

© 18:20

01 BBC1
FAVOURITE
① 18:20

#### PROGRAM STATUS DISPLAY (INFORMATION)

Use the remote control ① button (A24) to display (for 4 seconds only) program status information. This display appears also after a program selection or after switching on the TV set.




#### **SLEEP FUNCTION**

The set will turn off (to stand-by mode) after a period of time that you can select. By pressing repeatedly the remote control **YELLOW** button (A6), you can enter one of the following settings:

OFF > 20 min > 40 min > 60 min > 80 min > 100 min > 120 min > OFF

The **SLEEP** time remaining (before TV turn-off) can be seen again at any time by one touch on the remote control **YELLOW** button (A6). A second touch (while the status display is on screen) will modify the SLEEP time remaining.



#### **FORMAT SELECTION**

AUTO setting: If picture format signalling data is received, then the most appropriate ZOOM format will be automatically selected.

Otherwise, the preferred mode of the user can be forced by repeated pressing of the remote control ZOOM button (A4): The following picture formats are available:

AUTO > 14:9 > 16:9 > FULL SCREEN > AUTO.



#### **FEATURES MENU**

Select the FEATURES MENU from the main MENU as follows:



PICTURFOR

Press on the button MENU

Position cursor on FEATURES menu

Press on the OK button

#### FEATURES menu content the following sub-menus.

When switched to ON:
 Prevents the use of the TV set without remote control.

#### 2. Wake up function

This function is only selectable when the clock is set. The TV set turns on from stand-by at the WAKE TIME and with the programme entered on the WAKE PROG. line. Put the TV set on stand-by with the remote control.

3. Shared with WAKE TIME

#### 4. TV clock setting

This function allows user to enter the time manually.

Note: If you turn off the set with the main power button, the clock setting is lost. An automatic attempt is made to set the clock again at power on.

- Programme Information function
   This status information is under the editorial contro of the transmitting station, and can contain the programme title.
- 6. This function is only selectable when the default picture format is currently active (see also FORMAT SELECTION, AUTO setting, page 8). This selects the default format to be used only when the format selected with the ZOOM button (A4) is AUTO, and no picture format signalling data is received.

7. LANGUAGE menu entry

#### **FEATURES**

CHILD LOCK
WAKE TIME
WAKE PROG.
CLOCK
CLOCK PROG
PROG. INFO
ZOOM AUTO
LANGUAGE

OFF OFF 04 --:--01 ON 4:3 GB

- 1. Adjust this value ON or OFF
- In stand-by mode, the stand-by indicator flashes red and green to indicate the CHILD LOCK is set.
- The front panel TV buttons (B7, B8, B9) become inactive and the TV will only respond to the remote control.
- Switch the WAKE UP function 'OFF' or 'ON' (the time will be shown e.g. 07:15) with the remote control CURSOR LEFT (A13) / RIGHT (A14) buttons.
- Enter the wake up time with the remote control 0..9 NUMBER (A3) buttons.
- 3. Adjust TV turn-on program number
- 4. Adjust TV clock. Clock will start at 00 seconds upon entry of the 4th figure. The prog. no. which is used to automatically seize the time at turn on should be entered here.
- 5. Adjust this value ON or OFF.
  - When ON, the information (if available) is displayed upon change of channel.
- When OFF, no information is displayed.
- Choose your preferred default format with the remote control CURSOR LEFT (A13) / RIGHT (A14) buttons.

Note: FULL SCREEN is represented here by 4:3.

 The currently selected LANGUAGE is displayed. Press the OK button (A9) to access the menu and change the selection.

#### LANGUAGE MENU

Select LANGUAGE menu from the FEATURES menu.

- Select the preferred LANGUAGE by use of the CURSOR LEFT (A13), RIGHT (A14) buttons, and the CURSOR UP (A11) or DOWN (A12) buttons.
- Press the **OK** button (A9) to confirm the selection (the choice will be highlighted in red).

Note: The languages shown are subject to modification without prior notice

#### **LANGUAGE**


BG CZ D DK E
F FIN GB GR H
I N NL PL RO
RUS S

# **ENGLISH**

## **TELETEXT**

#### **ENTERING/LEAVING TELETEXT MODE**

- Set the VCR / @ / DVD switch (A25) to the @ (teletext) position.
- Press the remote control **TELETEXT** ( ) button (A8) to select teletext mode.
- To return to TV mode, press again the **TELETEXT** ( ) button (A8).
- Note: Some of the buttons may not work if the VCR / □ / DVD) switch is not set to the □ (teletext) position.



#### PAGE SELECTION

- You can directly enter the 3 figure page number by using the remote control NUMBER 0..9 buttons (A3).
- You can sequentially select teletext pages by pressing the remote control PAGE UP (A11) / DOWN (A12) buttons.

#### **COLOUR buttons FOR TELETEXT**

- A red, green, yellow, and blue field is shown at the bottom of the screen. If TOP or FLOF teletext (FASTTEXT) is transmitted by the station, pressing the corresponding colour button on the remote controller, you can select the desired page easily.

Once a request is made, the page number is shown in the extreme top left corner of the screen. If the requested page is not immediately available the rolling header will be active until the page arrives.

#### **USEFUL TELETEXT FUNCTIONS**

#### **INDEX** button



(A23):

Allows you to return directly to the initial teletext page.

#### **PAGE HOLD button**



(A16)

Several sub pages can be combined under a page number and are scrolled at an interval determined by the television station. The presence of sub pages is indicated by, for example, 3/6 beneath the time, which means that you are looking at the 3rd page of a total of 6 pages. If you want to look at a subpage for a longer period of time, press the HOLD button. " " appears at the top of the screen and the contents of the subpage shown are kept on the screen and no longer updated or switched to other subpages. Pressing the HOLD button again, the current subpage appear

#### SUBPAGE button



(A24):

Allows you to request a specific subpage:

- Press the **SUBPAGE** button. At the base of the screen a **SUBPAGE** menu will appear. This has a red subpage minus link, a green subpage plus link, plus a white background showing (example for page 110), 110 / 0001. This is ready to accept the subpage number.
- Enter directly the subpage number you want with the remote control **NUMBER 0..9** buttons (A3): for example to request the 2nd subpage, type 0002.
- Alternatively, use the red subpage minus link or the green subpage plus link.
- The subpage number entered is shown at the base of the screen.
- If the requested page is not immediately available the rolling header will be active until the page arrives.

Warning: If the subpage is not available (does not exist), then the header will roll continuously and no new page will be found.

- To exit subpage mode, press the SUBPAGE button (A24) again.

Note: Teletext specification allows for subpage numbers 0000 to 3979 (the first figure is limited to the range 0..3, and the third figure 0..7).

#### **DOUBLE SIZE button** (+)

Repeadly pressing the SIZE button doubles the character size in the following order:

(A19)

Upper half of the page > Lower half of the page > Return to normal size

If the page is in UP or DOWN mode, then normal size is automatically set if

- A new page request is made (e.g CYAN, INDIX or PAGE UP /DOWN).
- A CANCEL mode (A22) function is used.
- VOLUME menu is activated with the MENU button (A10)

Note; The menu at the base of the screen is always visible.

#### REVEAL ANSWER button

answer and press again to hide it.

 $\bigcirc$  (A18)


This fonction can be used on certain pages to reveal the solution of riddles. Press the REVEAL button to reveal a hidden

#### **VOLUME, BRIGHTNESS & CONTRAST CONTROL**

VOLUME (and sound MUTE), BRIGHNESS and CONTRAST controls are all possible in teletext mode. The BRIGHTNESS and CONTRAST controls are dedicated to the teletext display.

- Access the **VOLUME** control by pressing the **MENU** button (A10) in teletext mode. A bargraph will appear in the lower part of the screen (as in TV mode). If **MUTE** is active, a mute icon is also shown.
- A second press on the MENU button (A10) will access the BRIGHTNESS control, and a third press the CONTRAST control.
- The active bargraph will timeout after 3-4 seconds (as in TV mode VOLUME control) or by pressing on the **MENU** button (A10) a fourth time (after CONTRAST control).







- Each control can be adjusted by using the remote control CURSOR LEFT (A13) / RIGHT (A14) buttons.
- Mute can always be activated by pressing the SOUND MUTE button (A1).
- Any change to the VOLUME level will cancel the SOUND MUTE.

#### WATCHING TV WHILE PAGE SEARCHING

The **CANCEL** function can be used to make the teletext page transparent, thus revealing the TV picture:

- To enter cancel mode, press the **CANCEL** ⊗ button (A22) while in teletext mode. The TV program will reappear on the screen, while only the teletext page number remains at the top and left corner of the screen.
- You can enter a new page number in this mode only by using the remote control **NUMBER 0..9** buttons (A3), or with the **INDEX button** (A23).
- If a page has been requested, but has not yet arrived, "???" flashing characters will be displayed until the page arrives. Otherwise, the same characters will be displayed without flashing until the next arrival of the page in the transmission cycle. Once arrived the page number will be displayed.
- The teletext page can be made visible again by pressing the CANCEL & button (A22).
- It should be noted that the TV program cannot be changed while in cancel mode.



#### **WATCHING TV WITH TELETEXT SUBTITLES**

If the actual teletext page is a news flash or subtitle page, then most of the TV picture becomes visible. In this situation the ZOOM format chosen in TV mode is reactivated, where possible.

# **CONNECTING EXTERNAL EQUIPMENT**

The rear Scart EXT-1, Scart EXT-2 sockets, the front EXT -3 socket are three dedicated sockets to connect audio-video equipment.



#### **TV/AV SELECTION**

Allows to switch between TV and external modes. By repeatedly pressing the remote control **AV** (A15) or the TV front panel **TV /AV** button (B8), the on-screen display is changed as shown:


#### EXT-1 > EXT-2 > EXT-2 S > EXT-3 > EXT-3 S > TV

Remark: If the signal source from the rear SCART socket (EXT-1) is RGB (e.g.normally from a DVD player) then EXT-1 RGB will be displayed. You can return to TV mode also by pressing number buttons or PROGRAM UP/DOWN buttons



#### VCR / DVD / Video Game / Pay-TV decoder

**Important**: If your video equipment does not have SCART socket(s), or if you wish to use only the aerial (RF) connection (not recommended), then you should make use of program number 00 on the TV set for best performance.



#### **REAR SCART SOCKET (EXT-1)**

This socket has video / audio inputs and outputs. It is recommended to connect to this socket automatic AV switching equipment such as pay-TV decoders, video games, DVD players and most VCR's.

This SCART socket doesn't support T-V LINK function. For correct operation, you should not connect any T-V LINK compatible device to this terminal.

In most cases, when connecting powered equipment to this socket, the TV set switches automatically to AV mode. If not, then use the **AV** buttons (A15 or B8) to select **EXT-1**.

#### **REAR SCART SOCKET (EXT-2)**

This socket has video / audio inputs and outputs. Automatic AV switching equipment (for example most VCR's) can be connected to this socket. In most cases, when connecting powered equipment to this socket, the TV set switches automatically to AV mode. If not, then use the AV buttons (A15 or B8) to select EXT-2. You can also receive an S-VHS signal by selecting EXT-2 S with the AV buttons (A15 or B8).

RGB mode is not available on this SCART T-V LINK compatible device must be connected to this terminal.


When a decoder is connected to a T-V LINK compatible VCR, set the DECORDER function to ON. For details,

see "Using the DECORDER (EXT-2) function" on page 5 Otherwise, you will not be able to view scambled channels.

#### Front

#### FRONT AV SOCKET (EXT-3)

The front AV socket has audio and video inputs. To switch from TV to these inputs, use the AV buttons (A15 or B8) and select **EXT-3**.



# **TROUBLESHOOTING**

• If the plug is disconnected from the AC socket, or the TV aerial has problems, you may think there is a problem with the TV itself. Be sure to check the following before calling for service.

#### **IMPORTANT**

Review all instruction in this manual

	PROBLEM	ACTION		
■ GENERAL	The TV cannot be turned on.	<ul> <li>Insert the plug in an AC socket.</li> <li>Turn the main power on. (See page 3)</li> <li>The buttons on the front panel of the TV will not work if the CHILD LOCK is operating (see FEATURES menu, on page 11). Use the POWER button on the remote control to turn the TV on.</li> </ul>		
	No picture or sound.	<ul> <li>Check aerial connections. (See page 3).</li> <li>Select the correct input source (See page 14).</li> <li>Change the SYSTEM setting manually (see Manual Channel Tuning on pages 5/6).</li> </ul>		
	The TV shuts off automatically.	<ul> <li>Did you set the SLEEP function? (See page 10).</li> <li>If the broadcast signal is not present for about 30 minutes, the set will be automatically turned off.</li> <li>For safety reasons, the TV will automatically turn off if no operations are made within approximately 3 hours after the TV is turned on with the WAKE UP function.</li> </ul>		
	The TV turns on automatically.	Did you set the WAKE UP function? (See page 11).		
	Inoperable remote control.	<ul> <li>Replace the batteries. (See page 3).</li> <li>Insert the batteries correctly. (See page 3).</li> <li>Use the remote control within about 7 metres of the TV.</li> </ul>		
PICTURE	Poor colour.	Change the SYSTEM setting manually (see Manual Channel Tuning on pages 5/6).		
	Lines or streaks in picture (interference)	Move any external equipment away until the interference is eliminated.     Reposition the aerial.		
	Spots (crosstalk)	Reposition the aerial. Replace with an aerial with better directionality.		
	Double pictures (ghosts)	<ul> <li>Reposition the aerial.</li> <li>Replace with an aerial with better directionality.</li> </ul>		
	Snowy pictures (noise)	<ul> <li>Check aerial connections.</li> <li>Redirect the aerial.</li> <li>Replace or repair the aerial.</li> </ul>		
SOUND	No sound from the TV's speakers	Disconnect the headphones.		

#### The following are normal and are NOT malfunctions:

- When touching the picture tube surface, you might feel a slight charge of static electricity. This is because the picture tube contains static electricity; it does not affect the human body.
- The TV may emit a crackling sound due to a sudden change of temperature. There is no problem unless the picture or sound is abnormal.
- When a still, bright image (of a white dress, for example) appears on the screen, the image may picture tubes, and as the bright image disappears, the colour also disappears.
- This TV is equipped with a microcomputer that may operate abnormally due to interference from external equipment. If this happens, turn off the main power and disconnect the power cord from the AC socket. Then reconnect the power cord to the AC socket and turn on the main power again.

# **SPECIFICATIONS**

Mode Item	AV-29FH1SUG / AV-29FH1BUG		
Broad casting systems	CCIR B/G, I ,D/K, L/L'		
Colour systems	PAL, SECAM The EXT terminals also support the NTSC 3.58/4.43 MHz system.		
Channels and frequencies	* E2-E12, E21-E70, S1-S41, X, Y, Z, Z+1, Z+2, ITALY A-H, ITALY H+1, ITALY H+2, F2-F10, F21-F70, R1-R12, R21-R70  * French cable TV channel of broadcast frequencies 116 - 172 MHz and 220 - 469 MHz		
Sound-multiplex systems	A2 (B/G, D/K), NICAM (B/G, D/K, I, L) systems		
Teletext systems	FLOF (Fastext) / TOP / WST (World standard system)		
Power requirements	AC 220-240V, 50 Hz		
Power consumption	84W, stand-by 3W		
Picture tube size	Visible area 68cm (measured diagonally)		
Audio output	Rated Power output: 7W + 7W		
Ext-1 terminal	Euroconnector (21-pin, SCART)  * Video input, Audio L/R inputs and RGB inputs are available  * TV broadcast outputs (Video and Audio L/R) are available.		
Ext-2 terminal	Euroconnector (21-pin, SCART)  * Video input, S-VIDEO (Y/C) input, Audio L/R inputs are available  * Video and Audio L/R outputs are available  * T-V LINK functions are available		
Ext-3 terminal  RCA connerctors x 3 S-VIDEO connector x 1  * Video input, S-VIDEO (Y/C) input and Audio L/R inputs are available.			
Headphone jack	Stereo mini-jack (3.5mm in diameter)		
Dimensions (Wx Hx D)	812 mm x 600 mm x 522 mm		
Weight	40 kg		
Remote control unit	l unit RM-C1514, battery AA / R6 x 2		

Design and specifications are subject to change without notice

Pictures displayed on the screen using this TV's image processing functions should not be shown for any commercial or demonstration purpose in public places (tearooms and halls in hotels, etc.) without the consent of the owners of copyright of the original picture sources, as this constitutes an infringement of copyright.

# **PARTS LIST**

#### **CAUTION**

- The parts identified by the △ symbol are important for the safety. Whenever replacing these parts, be sure to use specified ones to secure the safety.
- The parts not indicated in this Parts List and those which are filled with lines —— in the Parts No. columns will not be supplied.
- P. W. Board Ass'y will not be supplied, but those which are filled with the Parts No. in the Parts No. columns will be supplied.

#### CONTENTS

■ USING PW BOARD & REMOTE CONTROL UNIT	· 3-1
■ EXPLODED VIEW PARTS LIST	. 3-2
■ EXPLODED VIEW ····································	. 3-3
■ PRINTED WIRING BOARD PARTS LIST	
BACKING / PACKING PARTS LIST	. 2 0

#### **USING P.W. BOARD AND REMOTE CONTROL UNIT**


PWB ASS'Y	AV-29FH1BUG	AV-29FH1SUG
MAIN PWB	4859808593	<b>←</b>
CRT SOCKET PWB	4859829013	<b>←</b>
PFC FILTER PWB	4859813824	<b>←</b>
REMOTE CONTROL UNIT	48BC1514 (RM-C1514)	48BC1514B- (RM-C1514B)

No. YA008 3-1


# **EXPLODED VIEW PARTS LIST**

⚠ Ref.No.	Part No.	Part Name	Description
↑ V01 ↑ L01 ↑ T402	4859640560 58G0000149 50H0000260	CRT (PHILIPS 29") COIL DEGAUSSING FBT	Inc.DEF YOKE, PC MAGNET
↑ T402 ↑ 1 ↑ 1 ↑ 2 ↑ 2	4852086101 4852086111 4854866801	MASK FRONT MASK FRONT BUTTON POWER	AV-29FH1BUG AV-29FH1SUG AV-29FH1BUG
∆ 2 3 △ 4 △ 4	4854866811 4856716000 4851951001	BUTTON POWER SPRING DOOR ASSY	AV-29FH1BUG AV-29FH1BUG
21\(\delta\) 4 5 6 7	4851951011 485506084001 4857923300 48556243SD02	DOOR ASSY DECO CTRL DOOR LOCK MARK BRAND	AV-29FH1SUG AV-29FT1BUG
, 7 8 ∧ 9	48556243SD01 4858315210 4859903511	MARK BRAND SPEAKER CORD POWER	AV-29FH1SUG (×2)
Д 9 Д 10 Д 10 11	4852164301 4852164311G 7172401612	COVER BACK COVER BACK SCREW TAPPING	AV-29FH1BUG AV-29FH1SUG (×8)
12 13 Δ 14 15	7178301212 4853535600 4855415800 485580002207	SCREW TAPPITE HOLDER CORD S/PLATE LABEL SERIAL	

# **EXPLODED VIEW**



## **EXPLODED VIEW**



3-3

# PRINTED WIRING BOARD PARTS LIST

∆ Symbol No.	Part No.	Part Name	Description	∆ Symbol No.	Part No.	Part Name	Description
1101 1301 1501 1502 1601 1602 1701 1702 1703 1801 △ 1804 1806 1810 1820 1821 1822 1823 1824 1825 1827 1901	1TDA4470M- 1TDA8358J- 1VSP9402AQ 1DDP3315CQ 1MSP3410V3 1TDA8946J- 1SDA55SXFL 1AT24C16PC 1TSOP1238W 1STRF6654- 1KP1010C 1DP130 TX0.002DA 1L7805CV 1LD1117V33 1L7808CV 1LD1117V33 1LD1117V35 1LD1117V35 1LD1117V35	IC IF IC VERTICAL IC CHIP VIDEO IC CHIP IC SOUND IC AUDIO IC MICOM OTP IC MEMORY IC PREAMP IC SMPS IC PHOTO COUPLER IC ERROR AMP THYRISTOR IC REGULATOR	TDA4470-M TDA83581 VSP9402 DDP3315CQ MSP3410G-V3 TDA893451 SDA555XFL AT24C16-10PC TSOP1238W11 STR-F6654 KP-1010C DP130 X02020A L7805CV L7808CV .01117AV33 3.3V T0-220 .01117AV18 1.8V T0-220 .01117AV18 1.8V T0-220 .01117AV18 3.3V T0-220 .01117AV18 2.5V T0-220 .01117AV25 2.5V T0-220 .01117AV33 3.3V T0-220 .01117AV35 2.5V T0-220	↑ D801 ↑ D802 ↑ D803 ↑ D804 D805 D806 D808 D809 D811 D820 D821 D824 D825 D830 D831 D840 D841 D840 D841 D860 D870 D911 D912 D912	DLT2A05G DLT2A05G DLT2A05G DLT2A05G DLT2A05G DRCP15J DRCP15J DRCP15J DTX6V2 DBYW76 D1W148 DRCP15J DRCP15J DRCP15J DNCP15J DNCP15J DRCP15J DRCP15J DRCP15J DRCP15J DNCP15J	DIODE	LT2A05G LT2A05G LT2A05G LT2A05G LT2A05G RGP15J RGP15J RGP15J RGP15J RGP15J TZX6V2B (TAPPING) BYW76 RGP15J 1N4148 (TAPPING) 1N4148 (TAPPING) 1N4045 BYW76 RGP15J 1N40045 BYW76 RGP15J 1N40045 1N40045 1N40045 1N40045
Q103 Q104 Q110 Q150 Q151 Q333 Q334 Ф401 Q501 Q502 Q501 Q502 Q542 Q544 Q544 Q550 Q601 Q701 Q702 Q721 Q730 Q731 Q730 Q734 Q780 Q807 Q808 Q809 Q809 Q811 Q921 Q923	T2SC5343Y- T2SC134380Y- T2SC13480Y- T2SC13480Y- T2SC13480Y- T2SC13480Y- T2SC1343Y- T2SC1343Y- T2SC1343Y- T2SC1343Y- T2SC1343Y- T2SC1343Y- T2SC5343Y- T2SC5	TR T	25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C5343Y 25C3343Y 25C	D912 D913 D913 D921 D922 D923 D927 D411 DA16 DA17 DA20 DA27  C101 C102 C106 C117 C118 C121 C150 C152 C153 C157 C164 C188 C301 C305 C315 C315 C315 C316 C305 C351 C370 C401 A C404 C405 C408	DIN40045 DRW76 DRW76 DRW76 DRW705 DIN40045 DIN40045 DIN40045 DIN40045 DIN40045 DIN40045 DIN40045 DIX5V6B DTZX5V6B	DIODE DIODE DIODE DIODE DIODE DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER CENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER CELECTRO CELECTRO CELECTRO	1140045 114004
D100 D101 D103 D313 D360 D361 D362 D367 D404 D405 D406 D407 D408 D410 D414 D415 D530 D531 D535 D540 D5414 D550 D551 D602 D720 D730 D733 D777 D781	DBA185 DBA282 DBA282 DTZX22C DTZX23B DTZX33B DTZX33B DTZX33B DTX33B DIX4337G DIX4337G DIX4337G DIX4337G DIX437G DIX437G DIX4148 DIX4155 DTZX7VSC DTZXYVSC DTZXYVSC DTZXYVSC DTZXSV6B DBAT85	DIODE ZENER DIODE DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	TZX33B (TAPPING) BA185 (TAPPING) BA282 RGP15J TZX22C (TAPPING) TZX33B (TAPPING) TZX33B (TAPPING) TZX33B (TAPPING) TX33B (TAPPING) TM337G RGP15J RGP15J RGP15J RGP15J 1N4937G 1N4937G 1N4937G 1N4937G 1N4937G 1N4937G 1N4937G 1N4937G 1N4937G 1N4184 (TAPPING) 1N4148 (TAPPING) TXXV5C (TAPPING) TZXVV5C (TAPPING) TZXVV5C (TAPPING) TZXVV5C (TAPPING) TZXVV5C (TAPPING) TZXSV6B (TAPPING) TZXSV6B (TAPPING)	C411 C415 C416 C417 C418 C424 C425 C500 C501 C502 C503 C508 C508 C509 C510 C516 C517 C518 C519 C524 C534 C534 C537 C538	CMYE2G334J CEXF2C339V CEXF2E100V CCYR3D471K CMYE2G1031 CEYD1H689W CMXM2A333J CCXB1H472K CEXF1E100V CEXF1E100V CEXF1E100V CEXF1E100V CEXF1E100V CEXF1E100V CEXF1H100V CCZB1H473K CCZB1H473K CCZB1H473K CCZB1H473K CCZB1H474C CBZF1H104Z CCZB1H103K CCZB1H103K CCZB1H103K CCZB1H103K CCZB1H103K	C ELECTRO C ELECTRO C ELECTRO C CERA C MYLAR C ELECTRO C CERA C CERA C CERA SEMI C CERA C CERA	160V RSS 3,3MF (8X16) TP 250V RSS 10MF (10X20) TP HIKR 2KV 470PF K 125C 400V PU 0.01MF J 50V RHD 6.8MF (16X35.5) 100V 0.033MF J TP 50V B 4700PF K (TAPPING) 25V RSS 47MF (5X11) TP 25V RSS 10MF TP 25V RSS 10MF TP 25V RSS 10MF TP 25V RSS 10MF TP 50V B 0.047MF K (AXIAL) 50V B 0.047MF K (AXIAL) 50V F 0.1MF Z (AXIAL) 50V B 0.01MF K (AXIAL)

3-4

∆ Symbol No.	Part No.	Part Name	Description	⚠ Symbol No.	Part No.	Part Name	Description
C540 C550 C551 C553 C557 C558 C560 C561 C568 C577 C589 C590 C602 C604 C605 C608 C610 C611 C612 C613 C614 C615 C616 C624 C626 C630 C634 C636 C634 C641 C642 C650 C660 C661 C661 C662 C660 C661 C662 C660 C690 C691 C711 C712 C713 C730 C737 C744 C770 C803 C804 C807 C801 C808 C809 C811 C808 C809 C811 C808 C809 C811 C808 C809 C811 C812 C813 C814 C821 C821 C821 C821 C821 C821 C821 C821	CCZB1H333K CEXF1E100V CEXF1E100V CCSB1H103K CRZF1H104Z CBZF1H104Z CBZF1H104Z CEXF1E101V CEXF1H339W CEXF1E101V CCZB1H561K CCZB1H500V CEXF1E100V CEXF1E100V CEXF1H109V	C CERA C ELECTRO C ELECTRO C CERA SEMI C ELECTRO C CERA C CERA C CERA C CERA C CERA C ELECTRO	50V B 0.033MF K (AXIAL) 25V RSS 10MF TP 25V RSS 10MF TP 50V B 0.01MF K (AXIAL) 50V F 0.1MF 72 (AXIAL) 50V F 0.1MF 72 (AXIAL) 55V RSS 100MF (6.3X11) TP 50V RSS 3.3MF (SX11) TP 25V RSS 100MF (6.3X11) TP 50V B 560PF K (AXIAL) 50V B 560PF K (AXIAL) 50V RSS 1MF (SX11) TP 25V RSS 100MF (13X20) TP 25V RSS 220MF (8X11.5) TP 25V RSS 220MF (8X11.5) TP 25V RSS 220MF (8X11.5) TP 25V RSS 20MF (8X11.7) TP 25V RSS 3.3MF (SX11) TP 25V RSS 10MF TP 50V RSS 3.3MF (SX11) TP 50V RSS 3.3MF (SX11) TP 50V RSS 3.3MF (SX11) TP 50V RSS 1MF (SX11) TP 25V RSS 100MF (6.3X11) TP 25V RSS 10MF (6.3X11) TP 25V	C921 C922 C923 C937 C920 C921 C922 C923 C937 C001 C001 C002 C003 C004 C005 C006 C010 C010 C010 C010 C011 C010 C010 C011 C010 C010 C011 C010 C010 C011 C010 C	CMXM2A102J CMXM2A102J CMXM2A102J CMXM2A102J CEXT2E100V CC781H222K HCBK471KCA HCBK471KCA HCBK471KCA HCBK471KCA HCBK471KCA HCBK471KCA HCBK471KCA HCBK471KCA HCBK102KCA HCFK103ZCA HCFK103ZCA HCFK103ZCA HCFK103ZCA HCFK103ZCA HCFK103ZCA HCBK102KCA HCFK103ZCA HCBK102KCA HCFK103ZCA HCBK102KCA HCFK103ZCA HCBK102KCA HCBK104KCA	C MYLAR C MYLAR C MYLAR C MYLAR C HIP CERA C CHIP CERA	100V 1000PF J TP 250V RSS 10MF (10X20) TP 550V BS 2200PF K (AXIAL) 50V X7R 470PF K 2012 50V X7R 1000PF K 2012 50V X7R 100PF K 2012 50V X7R 1000PF K 2012 50V X7R 100PF K 2012 50V X7R 1000PF K 2012 50V X7R 100PF K

No. YA008 3-5


⚠ Symbol No.	Part No.	Part Name	Description	⚠ Symbol No.	Part No.	Part Name	Description
CC667 CC680 CC701 CC709 CC711 CC712 CC713 CC715 CC716 CC726 CC727 CC737 CC737 CC742 CC744 CC777 CC782 Δ CF802	HCBK472KCA HCBK102KCA HCFK103ZCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCFK103ZCA HCFK103ZCA HCFK103ZCA HCCK330JCA HCQK330JCA HCGK30JCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK102KCA HCBK102KCA HCBK102KCA HCBK102KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA HCBK104KCA	C CHIP CERA	50V X7R 4700PF K 2012 50V X7R 1000PF K 2012 50V X7R 0.1MF Z 2012 50V X7R 0.1MF K 2012 50V YSV 0.01MF Z 2012 50V YSV 0.01MF Z 2012 50V CH 33PF J 2012 50V X7R 100MF Z 2012 50V X7R 100MF K 2012	R577 R578 R579 R580 R580 R590 R590 R593 R594 R595 R605 R606 R608 R608 R614 R615 R620	RD-AZ151J- RD-AZ330J- RD-AZ30J- RD-AZ101J- RD-AZ101J- RD-AZ102J- RD-AZ103J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ101J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J-	R CARBON FILM	1/6 150 OHM J 1/6 33 OHM J 1/6 130 OHM J 1/6 100 OHM J 1/6 100 OHM J 1/6 33 OHM J 1/6 33 OHM J 1/6 33 OHM J 1/6 34 OHM J 1/6 100 OHM J
R103 R1101 R1111 R150 R1511 R150 R1512 R152 R1554 R1555 R164 R1901 R3101 R3101 R3111 R3333 R334 R350 R3510 R370 R388 R394 R395 R397 R3996 R397 R397 R397 R397 R397 R397 R397 R397	RD-AZ123J- RN-4Z150JF RN-4Z150JF RN-4Z133J- RN-4Z133J- RN-AZ102J- RN-AZ102J- RN-AZ102J- RN-AZ151J- RN-AZ153J- RN-AZ153J- RN-AZ25JJ- RN-AZ22JJ- RN-AZ23JJ- RN-AZ33JJ- RN-AZ471J- RN-AZ471J- RN-AZ10JJ- RN-AZ10JJ- RN-AZ33JJ- RN-AZ3JJ- RN	R CARBON FILM R METAL FILM R CARBON	0.47MF 12/UCVSNDF/SV  1/6 12K OHM J 1/4 15K OHM J 1/6 13K OHM J 1/6 15O OHM J 1/6 27O OHM J 1/6 75O OHM J 1/6 75K OHM J 1/6 33O OHM J 1/6 33O OHM J 1/6 2.2K OHM J 1/6 2.2K OHM J 1/6 2.2K OHM J 1/4 4.7K OHM J 1/6 2.2K OHM J 1/6 3.3K OHM J 1/4 4.7K OHM J 1/6 2.2K OHM J 1/6 3.5K OHM J 1/6 1/6 0HM J 1/6 1/6 1/6 OHM J 1/6 1/6 3/8 OHM J 1/8 3/8 OHM J 1/8 3/8 OHM J 1/8 3	R641 R642 R641 R642 R646 R647 R649 R650 R651 R651 R652 R660 R680 R700 R701 R703 R704 R708 R708 R708 R708 R709 R710 R716 R718 R718 R720 R733 R741 R748 R750 R731 R741 R748 R750 R731 R741 R748 R750 R731 R741 R748 R750 R731 R741 R8417 R8517 R8617 R8617 R8618 R804 R806 R806 R807 R808 R808 R811 R821 R822 R823 R829 R830 R841 R850 R851 R851 R851 R851 R851 R851 R851 R851	RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ102J- RD-AZ472J- RD-AZ102J- RD-AZ472J- RD-AZ472J- RD-AZ472J- RD-AZ472J- RD-AZ472J- RD-AZ101J- RD-AZ103J- RD-AZ10J-	R CARBON FILM R	1/6 1K OHM J 1/6 1

3-6

⚠ Symbol No.	Part No.	Part Name	Description	⚠ Symbol No.	Part No.	Part Name	Description
R997 RA011 RA15 RA16 RA32 RA35 RA16 RA32 RA35 RA77 RA88 RC102 RC106 RC107 RC109 RC112 RC114 RC116 RC117 RC118 RC119 RC153 RC150 RC516 RC517 RC506 RC511 RC560 RC561 RC560 RC581 RC580 RC581 RC580 RC580 RC581 RC580 RC580 RC581 RC582 RC580 RC581 RC582 RC580 RC581 RC582 RC580 RC581 RC582 RC580 RC581 RC782 RC711 RC722 RC711 RC722 RC711 RC722 RC711 RC722 RC733 RC711 RC720 RC711 RC722 RC731 RC712 RC721 RC723 RC734 RC735 RC736 RC738 RC736 RC737 RC731 RC731 RC712 RC720 RC731 RC712 RC720 RC731 RC712 RC721 RC720 RC731 RC732 RC734 RC735 RC736 RC738 RC738 RC738 RC730 RC731 RC731 RC732 RC731 RC732 RC731 RC732 RC731 RC732 RC733 RC734 RC735 RC736 RC737 RC738 RC730 RC731 RC732 RC738 RC730 RC731 RC732 RC738 RC738 RC730 RC731 RC732 RC731 RC732 RC731 RC732 RC731 RC732 RC733 RC734 RC735 RC736 RC736 RC737 RC738 RC736 RC737 RC738 RC737 RC738 RC736 RC737 RC738 RC737 RC738 RC730 RC741 RC742 RC743 RC750 RC770 RC780 RC781 RC782 RC788	RD-271021-		1/2 1K OHM J 1/6 22 OHM J 1/6 75 OHM J 1/10 75 OHM J 2012 1/10 100 OHM J 2012 1/10 10 0HM J 2012 1/10 10 OHM J 2012	Symbol No.	Part No.  HRFT512JCA HRFT7512JCA HRFT750JCA  SCPX479K SCP2479K02  58E0000041  SCP2120K02  58E00000120  58E00000120  58E00000120  58E00000130  58E00000130  58E00000130  58E00000130  58E00000130  58E00000130  58C0000100  58C0000100  5CP2100K02  5CP2100K04  5CP2100K05  5CP2100K02  5	R CHIP COIL PEAKING COIL PEAKIN	Description

No. YA008 3-7

### **PACKING**



### PACKING PARTS LIST

⚠ Ref.No.	Part No.	Part Name	Description
1 2 3 4 5 6 6 7 7 7 8 8	GPBJV6B3022 4858199X00UP 4858199X00DN 4858115601 4858213801 PMJV6B3522 PMJV3B3322 48BC1514B- 48BC1514 AV29FH18UG AV29FH18UG BT-54013-6L	BOX PAD UP PAD DOWN POLY BAG 25"-28" BAG INSTRUCTION MANUAL MANUAL TRANSMITTER REMOCO TRANSMITTER REMOCO BOX LABEL BOX LABEL WARRANTY CARD	2pcs in 1set 2pcs in 1set Eng, Fre, Ger, Ita, Psa, Dut, Por Pol, Cze, Rom, Hun, Bul N (RM-C1514B) [AV-29FH1BUG] N (RM-C1514) [AV-29FH1SUG] [AV-29FH1BUG] [AV-29FH1BUG]


# JVC

## SCHEMATIC DIAGRAMS

**COLOUR TELEVISION** 

### AV-29FH1BUG, AV-29FH1SUG

CD-ROM No.SML200310







AV-29FH1BUG, AV-29FH1SUG	
STANDARD CIRCUIT DIAGRAM	
CONTENTS  SEMICONDUCTOR SHAPES	2-2 2-3
MAIN & CRT SOCKET PWB CIRCUIT DIAGRAM	2-5 2-7 2-9
No.YA008	




### **BLOCK DIAGRAM**





### PATTERN DIAGRAMS MAIN PWB PATTERN



FRONT

#### CRT SOCKET & PFC FILTER PWB PATTERN

