

# **V2201 Series Windows 10 LTSC Software User's Manual**

---

**Version 1.0, June 2021**

[www.moxa.com/product](http://www.moxa.com/product)

**MOXA<sup>®</sup>**

© 2021 Moxa Inc. All rights reserved.

# V2201 Series Windows 10 LTSC Software User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## Copyright Notice

© 2021 Moxa Inc. All rights reserved.

## Trademarks

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Technical Support Contact Information

[www.moxa.com/support](http://www.moxa.com/support)

### **Moxa Americas**

Toll-free: 1-888-669-2872  
Tel: +1-714-528-6777  
Fax: +1-714-528-6778

### **Moxa Europe**

Tel: +49-89-3 70 03 99-0  
Fax: +49-89-3 70 03 99-99

### **Moxa India**

Tel: +91-80-4172-9088  
Fax: +91-80-4132-1045

### **Moxa China (Shanghai office)**

Toll-free: 800-820-5036  
Tel: +86-21-5258-9955  
Fax: +86-21-5258-5505

### **Moxa Asia-Pacific**

Tel: +886-2-8919-1230  
Fax: +886-2-8919-1231

# Table of Contents

<b>1. System Initialization</b> .....	<b>1-1</b>
Initializing User Settings .....	1-2
Initializing the System .....	1-6
<b>2. BitLocker</b> .....	<b>2-1</b>
Enabling the BitLocker .....	2-2
Disabling the BitLocker .....	2-6
<b>3. Unified Write Filter</b> .....	<b>3-1</b>
Getting Started .....	3-2
Turning On UWF in a Running PC .....	3-2
Installing UWF Using WMI .....	3-5
<b>4. Moxa IO Controller Utility</b> .....	<b>4-1</b>
Getting Started .....	4-2
Setting the DIO Status .....	4-2
Setting the UART Mode .....	4-3
Setting the PCIE Status .....	4-4
Setting the LED Status .....	4-5
<b>5. Moxa Serial Interface Utility</b> .....	<b>5-1</b>
Setting the UART Mode .....	5-2
<b>6. IO Control API</b> .....	<b>6-1</b>
mxgpio .....	6-2
mxgpio_open .....	6-2
mxgpio_get_data .....	6-2
mxgpio_set_data .....	6-2
mxgpio_close .....	6-2
mxdgio .....	6-3
mxdgio_open .....	6-3
mxdgio_get_input_signal .....	6-3
mxdgio_get_output_signal .....	6-3
mxdgio_set_output_signal_low .....	6-3
mxdgio_set_output_signal_high .....	6-4
mxdgio_close .....	6-4
mxsp .....	6-4
mxsp_open .....	6-4
mxsp_get_interface .....	6-4
mxsp_set_interface .....	6-5
mxsp_close .....	6-5
mxwdg .....	6-5
mxwdg_open .....	6-5
mxwdg_refresh .....	6-5
mxwdg_close .....	6-6
<b>7. System Recovery</b> .....	<b>7-1</b>
Preparing a USB device .....	7-2
Bootting From a USB Disk .....	7-4
Creating a Backup Image .....	7-5
Restoring the System Using a Backup Image .....	7-8

## System Initialization

---

This chapter describes how to initialize the system settings when you boot up the computer for the first time.


The following topics are covered in this chapter:

- ❑ **Initializing User Settings**
- ❑ **Initializing the System**


# Initializing User Settings

The following is a non-exhaustive list of screens that you will see when configuring the Out Of Box Experience (OOBE) settings.


1. Select your region.




2. Select your keyboard layout.




3. Select a second keyboard layout if necessary.




4. Connect to a network. You may click **Skip for now** if you do not want to connect to a network now.




We recommend that you click **Yes** and connect to a network.




5. Enter a username for this computer and click **Next** to continue.



- 6. Enter the password for this user and click **Next** to continue.




- 7. Click **Yes** to see additional settings.






8. Choose the privacy settings for your device and configure them on the setting page. When finished, click **Accept** to complete.




## Initializing the System

1. When you sign in for the first time, the system will run the Windows Command Processor and the message **"Do you want to allow this app to make changes to your device?"** is displayed. Click **Yes**.



2. Wait for the process to complete. It might take a couple of seconds.



# 2

## BitLocker

---

This chapter describes the BitLocker setup process.


The following topics are covered in this chapter:

- ❑ **Enabling the BitLocker**
- ❑ **Disabling the BitLocker**


# Enabling the BitLocker

To enable the BitLocker for a drive:


1. Right-click on the drive and select the **Turn on BitLocker** option.




2. Select a method to back up the recovery key. For example, select **Save to a file**.




3. Select the path to store the file.




4. Select an option to specify which part of the drive to encryption and click **Next**.




5. Choose the drive encryption mode and click **Next**.




6. Click **Continue** with the **Run BitLocker...** option checked (default).



7. Click **Restart now**.



8. Wait for the encryption process to complete and click **Close**.




The system will be restarted immediately.


# Disabling the BitLocker

To disable the BitLocker for a drive:

1. Right-click on the drive and select the **Manage BitLocker** option.





2. Click **Turn off BitLocker**.






3. Wait for the decryption process to complete and click **Close** to exit the program.



4. Check the disk status after the decryption process is complete.



## Unified Write Filter

---

This chapter describes how to use the Unified Write Filter.

The following topics are covered in this chapter:

- **Getting Started**
- **Turning On UWF in a Running PC**
- **Installing UWF Using WMI**

# Getting Started

The Unified Write Filter (UWF) needs to be installed and enabled (and optionally configured) on your system before you can use it. The first time you enable UWF on your system, the following changes are made to improve the performance of UWF.


- Paging files are disabled.
- System restore is disabled.
- SuperFetch is disabled.
- File indexing service is turned off.
- Fast boot is disabled.
- Defragmentation service is turned off.
- BCD setting **bootstatuspolicy** is set to **ignoreallfailures**.

After UWF is enabled, select a drive to protect and start using UWF. You can install UWF for running PCs and devices and manage them remotely using Windows Management Instrumentation (WMI).

## Turning On UWF in a Running PC


### Using Windows Features.

- a. In the Windows taskbar, click on the start icon and type **Turn Windows features on or off**.
- b. In **Windows Features**, expand the Device Lockdown node and check **Unified Write Filter**.
- c. Click **OK**.




A progress bar is displayed indicating that Windows is searching for required files. Once the files are found, the progress bar will indicate that Windows is applying the changes.

- d. When the process is completed, click **Restart now** to reboot your computer.



### Using the Windows Command Line

1. Type **CMD** in the Windows search box and select **Run as administrator**.



2. Run the following command to enable the filter.

```
cmd uwfmgf filter enable
```

```
Administrator: Command Prompt

C:\Windows\system32>uwfmgr filter enable
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Unified Write Filter will be enabled after system restart.

C:\Windows\system32>
```

2. To enable write protection for a specific drive (e.g., **C**), run the command:

```
cmd uwfmgr.exe volume protect C:
```

```
Administrator: Command Prompt

C:\Windows\system32>uwfmgr filter enable
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Unified Write Filter will be enabled after system restart.

C:\Windows\system32>uwfmgr.exe volume protect C:
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

The volume C: will be protected by Unified Write Filter after system restart.

C:\Windows\system32>
```

3. Restart your computer.
4. After the computer restarts, use the following command to confirm that UWF is running:

```
cmd uwfmgr.exe get-config
```

```
Administrator: Command Prompt

C:\Windows\system32>uwfmgr.exe get-config
Unified Write Filter Configuration Utility version 10.0.17763
Copyright (C) Microsoft Corporation. All rights reserved.

Current Session Settings

FILTER SETTINGS
  Filter state:      OFF
  Pending commit:   N/A
  Shutdown pending: No

SERVICING SETTINGS
  Servicing State:  OFF

OVERLAY SETTINGS
  Type:              RAM
  Maximum size:      1024 MB
  Warning Threshold: 512 MB
  Critical Threshold: 1024 MB
  Freespace Passthrough: OFF
  Persistent:        OFF
  Reset Mode:        N/A
```

# Installing UWF Using WMI

If your computer is already set up and you do not want to use a provisioning package, you can configure UWF using Windows Management Instrumentation (WMI) providers. To turn on UWF using WMI, use the **UWF\_Filter** function, specifically the **UWF\_Filter.Enable** method, in one of the following ways:

- Use the WMI providers in a PowerShell script
- Use the WMI providers in an application
- Use the command line tool **uwfmgr.exe**

You must restart your device after you turn on or turn off UWF for the changes to take effect.

You can change the UWF settings even after the UWF is turned on. For example, you can move the page file location to an unprotected volume and re-enable the paging files.



## IMPORTANT!

If you have added UWF to your image by using SMI settings in a unattend.xml file, turning on UWF will only set the bootstatuspolicy BCD setting and turn off the defragmentation service. In this case, you must manually turn off the other features and services if you want to increase the performance of UWF.

All configuration settings for UWF are stored in the registry. UWF automatically excludes these registry entries from filtering. After a device restarts, the configuration settings are stored in the registry for the current session and the next session. Static configuration changes do not take effect until after a device restarts, and these changes are saved in the registry entries for the next session. Dynamic configuration changes occur immediately and take effect after a device restart.

# Moxa IO Controller Utility

---

This chapter describes how to use the Moxa IO Controller utility.

The following topics are covered in this chapter:

- **Getting Started**
- **Setting the DIO Status**
- **Setting the UART Mode**
- **Setting the PCIE Status**
- **Setting the LED Status**



# Getting Started

To use the Moxa IO Controller utility, do the following:

1. Install the utility.
2. Enable the settings for DIO, UART mode, PCIE, and LED.
3. Run the **Command Prompt** as an **Administrator** and change the path to:

**C:\Program Files\Moxa\Moxa Computer IO Controller.**

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.17763.292]
(c) 2018 Microsoft Corporation. All rights reserved.

C:\Windows\system32>cd /d C:\Program Files\Moxa\Moxa Computer IO Controller
C:\Program Files\Moxa\Moxa Computer IO Controller>_
```

Refer to the following sections for instructions on configuring additional settings.

## Setting the DIO Status

Run **DIO.exe** and follow the onscreen instructions to view or configure the DIO status.



### IMPORTANT!

The DIN and DOUT indices start from 0 in the Moxa IO Controller utility although the indices are printed starting from 1.

### Example:

```
D:\2201\x64\DIO.exe
UART Mode Test Program
    (0) Exit Program
    (1) Display DIN
    (2) Display DOUT
    (3) Set DOUT value
    (4) Display both DIN and DOUT
3
Input the Port Number (0 ~ 3) =
0
Input the value (0 or 1) = 0
Set digital output success!

UART Mode Test Program
    (0) Exit Program
    (1) Display DIN
    (2) Display DOUT
    (3) Set DOUT value
    (4) Display both DIN and DOUT
4
Din0 = 1 , Dout0 = 0
Din1 = 1 , Dout1 = 1
Din2 = 1 , Dout2 = 1
Din3 = 1 , Dout3 = 1
```

# Setting the UART Mode

Run **UartMode.exe** and follow the onscreen instructions to view or configure the UART mode.



## IMPORTANT!

The UART index starts from 0 in the Moxa IO Controller utility although it is printed starting with 1.

### Example:

```
Administrator: Command Prompt - UartMode.exe
C:\Users\moxa\Desktop\example>UartMode.exe
Serial Interface Test Program
    (0) Exit Program
    (1) Display Serial Interface
    (2) Set Serial Interface
1
COM1 = RS485-2W
COM2 = RS485-2W
Serial Interface Test Program
    (0) Exit Program
    (1) Display Serial Interface
    (2) Set Serial Interface
2
Input the Port Number (1 ~ 2) =
1
Input the value (0:RS485-2W, 1:RS422, 2:RS232 ) = 2
Set serial interface success!
Serial Interface Test Program
    (0) Exit Program
    (1) Display Serial Interface
    (2) Set Serial Interface
1
COM1 = RS232
COM2 = RS485-2W
Serial Interface Test Program
    (0) Exit Program
    (1) Display Serial Interface
    (2) Set Serial Interface
```

# Setting the PCIE Status

Run **PwrExample.exe** and follow the onscreen instructions to view or configure the PCIE status.



## IMPORTANT!

The PCIE index starts from 0 in the Moxa IO Controller utility although it is printed starting with 1.

### Example:

```
D:\2201\x64\PwrExample.exe
(2) Set Power on/off
2
Input the Socket Number (1 ~ 2) =
2
Input 0 or 1 (0 = Off, 1 = On) = 0
Set Power success!

Mini PCIE Power Contol Test Program
(0) Exit Program
(1) Display Power condition
(2) Set Power on/off
1
Socket1 is on
Socket2 is off

Mini PCIE Power Contol Test Program
(0) Exit Program
(1) Display Power condition
(2) Set Power on/off
2
Input the Socket Number (1 ~ 2) =
2
Input 0 or 1 (0 = Off, 1 = On) = 1
Set Power success!

Mini PCIE Power Contol Test Program
(0) Exit Program
(1) Display Power condition
(2) Set Power on/off
```

# Setting the LED Status

Run **LEDexample.exe** and follow the onscreen instructions to view or configure the LED status.



## IMPORTANT!

The LED index starts from 0 in the Moxa IO Controller utility although it is printed starting with 1.

### Example:

```
D:\2201\x64\LEDexample.exe
LED Test Program
  (0) Exit Program
  (1) Display LED
  (2) Set LED value
2
Input 0 or 1 (0 = Off, 1 = On) = 1
Set LED success!
LED Test Program
  (0) Exit Program
  (1) Display LED
  (2) Set LED value
1
LED1 is on
LED Test Program
  (0) Exit Program
  (1) Display LED
  (2) Set LED value
2
Input 0 or 1 (0 = Off, 1 = On) = 0
Set LED success!
LED Test Program
  (0) Exit Program
  (1) Display LED
  (2) Set LED value
1
LED1 is off
LED Test Program
  (0) Exit Program
  (1) Display LED
  (2) Set LED value
```

## Moxa Serial Interface Utility

---

This chapter describes how to use Serial Interface utility to set the UART mode.


The following topics are covered in this chapter:

- **Setting the UART Mode**


# Setting the UART Mode

1. Install the Moxa Serial Interface utility.

After the installation is complete, you should be able to see the **mxSerialInterface** utility in the programs menu by clicking on the **Start** button.



2. Run the **mxSerialInterface** utility.
3. Select the target COM port and UART mode and click **OK** to save the settings.



The following topics are covered in this chapter:

## □ **mxgpio**

- mxdgio\_open
- mxgpio\_get\_data
- mxgpio\_set\_data
- mxgpio\_close

## □ **mxdgio**

- mxdgio\_open
- mxdgio\_get\_input\_signal
- mxdgio\_get\_output\_signal
- mxdgio\_set\_output\_signal\_low
- mxdgio\_set\_output\_signal\_high
- mxdgio\_close

## □ **mxsp**

- mxsp\_open
- mxsp\_get\_interface
- mxsp\_set\_interface
- mxsp\_close

## □ **mxwdg**

- mxwdg\_open
- mxwdg\_refresh
- mxwdg\_close

# mxgpio

The `mxgpio` library operates on the general-purpose I/Os (GPIO) and consists of the following functions:

- `mxgpio_open`
- `mxgpio_get_data`
- `mxgpio_set_data`
- `mxgpio_close`

## Requirements

Name	Items
Header	<code>mxgpio.h</code>
Library	<code>mxgpio.lib</code>
DLL	<code>mxgpio.dll</code>

## mxgpio\_open

Syntax	<code>HANDLE mxgpio_open(void);</code>
Description	Open a GPIO handle
Parameters	None
Return Value	The status of the GPIO interface (1 or 0)

## mxgpio\_get\_data

Syntax	<code>int mxgpio_get_data(HANDLE fd, unsigned int port_no);</code>	
Description	Get the GPIO input status.	
Parameters	<code>fd</code>	Handle of the GPIO device
	<code>port</code>	A GPIO port index; starts from 0.
Return Value	The status of GPIO port; 0 is low, 1 is high.	

## mxgpio\_set\_data

Syntax	<code>int mxgpio_set_data(HANDLE fd, unsigned int port_no, int data);</code>	
Description	Set the GPIO status to high.	
Parameters	<code>fd</code>	Handle of the GPIO device
	<code>port</code>	A GPIO port index; starts from 0.
Return Value	Returns 0 on success, otherwise the function has failed	

## mxgpio\_close

Syntax	<code>void mxgpio_close(HANDLE fd);</code>	
Description	Close the GPIO device.	
Parameters	<code>fd</code>	Handle of the GPIO device
Return Value	None	



## mxdgio

The `mxdgio` library operates on the digital I/Os and consists of the following functions:

- `mxdgio_open`
- `mxdgio_get_input_signal`
- `mxdgio_get_output_signal`
- `mxdgio_set_output_signal_low`
- `mxdgio_set_output_signal_high`
- `mxdgio_close`

### Requirements

Name	Items
Header	<code>mxdgio.h</code>
Library	<code>mxdgio.lib</code>
DLL	<code>mxdgio.dll</code>

## mxdgio\_open

Syntax	<code>HANDLE mxdgio_open();</code>
Description	Opens the digital I/O device
Parameters	None
Return Value	The handle of the digital I/O

## mxdgio\_get\_input\_signal

Syntax	<code>int mxdgio_get_input_signal(HANDLE fd, int port);</code>	
Description	Gets the digital input status	
Parameters	<code>fd</code>	Handle of the digital I/O device
	<code>port</code>	A digital input port index; starts from 0
Return Value	The status of the digital input port; 0 is low, 1 is high	

## mxdgio\_get\_output\_signal

Syntax	<code>int mxdgio_get_output_signal(HANDLE fd, int port);</code>	
Description	Gets the digital output status	
Parameters	<code>fd</code>	Handle of the digital I/O device
	<code>port</code>	A digital output port index; starts from 0
Return Value	The status of the digital output port; 0 is low, 1 is high	

## mxdgio\_set\_output\_signal\_low

Syntax	<code>int mxdgio_set_output_signal_low(HANDLE fd, unsigned int port);</code>	
Description	Sets the digital output status to <code>low</code>	
Parameters	<code>fd</code>	Handle of the digital I/O device
	<code>port</code>	A digital output port index; starts from 0
Return Value	Returns 0 on success; otherwise, the function has failed	

## mxdgio\_set\_output\_signal\_high

Syntax	<code>int mxdgio_set_output_signal_high(HANDLE fd, unsigned int port);</code>	
Description	Sets the digital output status to <b>high</b>	
Parameters	<b>fd</b>	Handle of the digital I/O device
	<b>port</b>	A port index of a digital output port; starts from 0
Return Value	Returns 0 on success; otherwise the function has failed	

## mxdgio\_close

Syntax	<code>void mxdgio_close(HANDLE fd);</code>	
Description	Closes the digital I/O device	
Parameters	<b>fd</b>	Handle of the digital I/O device
Return Value	None	

## mxsp

The **mxsp** library operates on the UART (serial) interface and consists of the following functions:

- **mxsp\_open**
- **mxsp\_get\_interface**
- **mxsp\_set\_interface**
- **mxsp\_close**

### Requirements

Name	Items
Header	mxsp.h
Library	mxsp.lib
DLL	mxsp.dll

## mxsp\_open

Syntax	<code>HANDLE mxsp_open();</code>	
Description	Initializes the serial interface	
Parameters	None	
Return Value	Returns the serial interface handle.	

## mxsp\_get\_interface

Syntax	<code>int mxsp_get_interface(HANDLE fd, int port_index);</code>	
Description	Gets the serial interface mode	
Parameters	<b>fd</b>	The serial interface handle
	<b>port_index</b>	A serial interface port index; starts from 0.
Return Value	0: RS-232 mode 1: RS-485-2W mode 2: RS-422 mode 3: RS-485-4W mode	

## mxsp\_set\_interface

Syntax	<code>int mxsp_set_interface(HANDLE fd, int port_index, int port_interface);</code>	
Description	Sets the serial interface mode	
Parameters	<code>fd</code>	The serial interface handle
	<code>port_index</code>	A port index of the serial port; starts from 0
	<code>port_interface</code>	0: RS-232 mode 1: RS-485-2W mode 2: RS-422 mode 3: RS-485-4W mode
Return Value	Return 0 on success, otherwise the function has failed.	

## mxsp\_close

Syntax	<code>void mxsp_close();</code>
Description	Close the serial interface.
Parameters	None
Return Value	None

## mxwdg

The `mxwdg` library operates on the watchdog timer and consists of the following functions:

- `mxwdg_open`
- `mxwdg_refresh`
- `mxwdg_close`

### Requirements

Name	Items
Header	<code>mxwdg.h</code>
Library	<code>mxwdg.lib</code>
DLL	<code>mxwdg.dll</code>

## mxwdg\_open

Syntax	<code>PVOID mxwdg_open(unsigned long time);</code>	
Description	Open the watchdog timer	
Parameters	<code>time</code>	Initial refresh time in second.
Return Value	Return Pointer to Watchdog handle. Return -1 on failure.	

## mxwdg\_refresh

Syntax	<code>int mxwdg_refresh(PVOID fd);</code>	
Description	Refresh the watchdog timer.	
Parameters	<code>fd</code>	The handle.
Return Value	Returns 0 on success, otherwise the function has failed.	

## mxwdg\_close

Syntax	<code>void mxwdg_close(PVOID fd);</code>
Description	Closes the watchdog timer.
Parameters	<b>fd</b> The handle.
Return Value	This function does not return a value.

# System Recovery

---


This chapter describes the Windows Recovery setup process.

The following topics are covered in this chapter:


- ❑ **Preparing a USB device**
- ❑ **Booting From a USB Disk**
- ❑ **Creating a Backup Image**
- ❑ **Restoring the System Using a Backup Image**

## Preparing a USB device


1. Format the USB disk for the FAT32 file system.
2. Run the **tuxboot-windows-23.exe** program from the **\recovery** folder.
3. Select **Pre Downloaded** and click on the browse button (...).




4. Browse to and select the ISO file from the **\recovery** folder.




5. Select the USB Drive type and the Drive.
6. Click **OK**.



The boot files will be copied to your USB device.




7. After the files are copied, click **Exit** to stop the program.



8. Copy the **os\_image** directory from the **\recovery** folder to the **\*\home\partimag\*** folder on the USB device.  
The USB disk is now ready for use in the recovery process.


## Booting From a USB Disk

1. Turn on the computer and **press F2** when you hear the beep sound to enter the BIOS setup menu.
2. Select **Boot Manager** and press **Enter** to continue.






3. Select **EFI USB Devices** and press **Enter** to continue to boot from the USB device.



## Creating a Backup Image

After you boot the system from a USB disk, you will see the **Moxa System Save & Restore Utility** page.

1. In the **Moxa System Save & Restore Utility**, select **clonezilla live save disk**.



2. Wait for the USB device boot process to finish.

```

[ 5.141941] sd 0:0:1:0: [sdb] Attached SCSI disk
[ 5.257277] sd 0:0:0:0: Attached scsi generic sg0 type 0
[ 5.269691] sd 0:0:1:0: Attached scsi generic sg1 type 0
[ 5.280668] sr 1:0:0:0: Attached scsi generic sg2 type 5
Begin: Loading essential drivers ... [ 5.772551] Atheros(R) L2 Ethernet Driver - version 2.2.3
[ 5.774561] Copyright (c) 2007 Atheros Corporation.
[ 5.863196] Broadcom NetXtreme II 5771x 10Gigabit Ethernet Driver bnx2x 1.62.00-6 (2011/01/30)
[ 6.005932] Btrfs loaded
[ 6.054095] device-mapper: uevent: version 1.0.3
[ 6.059737] device-mapper: ioctl: 4.19.1-ioctl (2011-01-07) initialised: dm-devel@redhat.com
done.
Begin: Running /scripts/init-premount ... done.
Begin: Mounting root file system ... [ 6.289382] Uniform Multi-Platform E-IDE driver
[ 6.301889] ide_generic: please use "probe_mask=0x3f" module parameter for probing all legacy ISA
IDE ports
[ 6.801141] NTFS driver 2.1.30 [Flags: R/W MODULE].
[ 6.914295] NTFS volume version 3.1.
Begin: Running /scripts/live-premount ... done.
[ 7.331989] FAT: utf8 is not a recommended IO charset for FAT filesystems, filesystem will be cas
e sensitive!
[ 7.453369] aufs: module is from the staging directory, the quality is unknown, you have been war
ned.
[ 7.479098] aufs 2.1-standalone.tree-38-rcM-20110228
[ 7.610228] loop: module loaded
[ 7.905144] squashfs: version 4.0 (2009/01/31) Phillip Lougher
Begin: Running /scripts/live-realpremount ... done.
Begin: Mounting "/live/image/live/filesystem.squashfs" on "//filesystem.squashfs" via "/dev/loop0"
.. done.
done.
Begin: Running /scripts/live-bottom
... Begin: Configuring fstab ... done.
Begin: Preconfiguring networking ... done.
Begin: Loading preseed file ... done.
Begin: Running /scripts/init-bottom ... done.
INIT: version 2.88 booting
Using makefile-style concurrent boot in runlevel S.

```

3. Click **y** to continue the process.

```

Setting the TERM as linux
*****
Clonezilla image dir: /home/partimag
*****
Shutting down the Logical Volume Manager
  No volume groups found
  No volume groups found
Finished Shutting down the Logical Volume Manager
Selected device [sda] found!
The selected devices: sda
*****
Activating the partition info in /proc... done!
Selected device [sda] found!
The selected devices: sda
Searching for data partition(s)...
Excluding busy partition or disk...
Unmounted partitions (including extended or swap): sda1
Collecting info.. done!
Searching for swap partition(s)...
Excluding busy partition or disk...
Unmounted partitions (including extended or swap): sda1
Collecting info.. done!
The data partition to be saved: sda1
The swap partition to be saved:
Activating the partition info in /proc... done!
Selected device [sda1] found!
The selected devices: sda1
Getting /dev/sda1 info...
*****
The following step is to save the hard disk/partition(s) on this machine as an image:
*****
Machine: VirtualBox
sda (2103MB_VBOX_HARDDISK__ata-VBOX_HARDDISK_VB1c64a0a3-c9f7523d)
sda1 (2065MB_ntfs(In_VBOX_HARDDISK_)_ata-VBOX_HARDDISK_VB1c64a0a3-c9f7523d)
*****
-> "/home/partimag/xpe_savedisk".
Are you sure you want to continue? ? (y/n) y

```

4. Wait for the backup process to complete.

```

/dev/sdb1: read failed after 0 of 2048 at 0: Input/output error
No volume groups found
No volume groups found
Finished Shutting down the Logical Volume Manager
Checking the integrity of partition table in the disk /dev/sda...
Reading the partition table for /dev/sda...RETV=0
*****
done!
Saving the MBR data for sda...
1+0 records in
1+0 records out
512 bytes (512 B) copied, 0.00347646 s, 147 kB/s
*****
Starting saving /dev/sda1 as /home/partimag/xpe_savedisk/sda1.XXX...
/dev/sda1 filesystem: ntfs.
*****
Checking NTFS integrity in /dev/sda1... done!
Checking the disk space...
Use ntfsclone with gzip to save the image.
Image file will be split with size limit 1000000 MB.
*****
If this action fails or hangs, check:
* Is the disk full ?
*****
ntfsclone v2.0.0 (libntfs 10:0:0)
NTFS volume version: 3.1
Cluster size      : 2048 bytes
Current volume size: 2064510976 bytes (2065 MB)
Current device size: 2064513024 bytes (2065 MB)
Scanning volume ...
100.00 percent completed
Accounting clusters ...
Space in use      : 1770 MB (85.7%)
Saving NTFS to image ...
_ 0.64 percent completed

```

5. Select **poweroff** to power off the computer when the backup process is completed.


Free Software Labs, NCHC, Taiwan

Choose mode	
Now you can choose to:	
<b>poweroff</b> Poweroff	
reboot Reboot	
cmd Enter command line prompt	
rerun1 Start over (image repository /home/partimag, if mounted, will be umounted)	
rerun2 Start over_(keep_image_repository_/home/partimag_mounted)	
<OK>	

# Restoring the System Using a Backup Image

After you boot the system from a USB disk, you will see the **Moxa System Save & Restore Utility** page.

1. In the **Moxa System Save & Restore Utility**, select **clonezilla live restore disk**.



2. Wait for the USB boot process to complete.

```

Command (m for help): The partition table has been altered.
Calling ioctl() to re-read partition table.
Syncing disks.

Warning: Unable to open /dev/sr0 read-write (Read-only file system). /dev/sr0 has been opened read-only.
Warning: Unable to open /dev/sr0 read-write (Read-only file system). /dev/sr0 has been opened read-only.
Disk /dev/sda: 20 GiB, 21474836480 bytes, 41943040 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes
Disklabel type: dos
Disk identifier: 0x469e8113

Device      Boot  Start      End  Sectors  Size Id Type
/dev/sda1                2048  1026047  1024000  500M  7 HPFS/NTFS/exFAT
/dev/sda2    1026048 41943039 40916992 19.5G  7 HPFS/NTFS/exFAT


Disk /dev/sdb: 14.8 GiB, 15846080512 bytes, 30949376 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes
Disklabel type: dos
Disk identifier: 0x00000000

Device      Boot Start      End  Sectors  Size Id Type
/dev/sdb1  *    2048 30949375 30947328 14.8G  c W95 FAT32 (LBA)


Disk /dev/loop0: 208.9 MiB, 218980352 bytes, 427696 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes

```

3. Wait for the system restore process to complete.



4. Select **poweroff** to power off the computer after the backup process is complete.



5. Remove the USB device after the computer has been powered off.