




COMPONENTS

ILLUSTRATION




[N*m (kgf*cm, ft.*lbf)]: Specified torque

● Non-reusable part

c

ILLUSTRATION



N*m (kgf*cm, ft.*lbf): Specified torque

* For use with SST

● Non-reusable part

T

REMOVAL

1. REMOVE NO. 1 ENGINE UNDER COVER


2. REMOVE NO. 2 ENGINE UNDER COVER

3. REMOVE FRONT NO. 3 ENGINE UNDER COVER_ INFO


4. REMOVE FRONT CENTER FLOOR BRACE_ INFO

5. DRAIN COOLANT (for Engine with Exhaust Heat Recirculation System)_ INFO

6. REMOVE FRONT EXHAUST PIPE ASSEMBLY (w/ Exhaust Heat Recirculation System)




(a) Disconnect the 3 clamps and oxygen sensor connector.



(b) Disconnect the 2 heater water hoses.


(c) Remove the 4 bolts and 4 compression springs.



(d) Remove the front exhaust pipe assembly from the 3 exhaust pipe supports.

(e) Remove the 2 gaskets from the front exhaust pipe assembly and exhaust manifold.

7. REMOVE FRONT EXHAUST PIPE ASSEMBLY (w/o Exhaust Heat Recirculation System)




(a) Remove the 4 bolts and 4 compression springs.

(b) Remove the front exhaust pipe assembly from the 3 exhaust pipe supports.


(c) Remove the 2 gaskets from the front exhaust pipe assembly and exhaust manifold.

8. REMOVE FRONT NO. 1 FLOOR HEAT INSULATOR



(a) Remove the 3 nuts and No. 1 floor heat insulator.


9. REMOVE NO. 1 EXHAUST MANIFOLD HEAT INSULATOR



(a) Remove the 3 bolts and No. 1 exhaust manifold heat insulator.

10. REMOVE AIR FUEL RATIO SENSOR_ [INFO](#)


11. REMOVE MANIFOLD STAY



(a) Remove the 3 bolts and manifold stay.

12. REMOVE EXHAUST MANIFOLD

(a) Remove the 7 nuts, exhaust manifold and 2 gaskets.



13. REMOVE NO. 2 EXHAUST MANIFOLD HEAT INSULATOR



(a) Remove the 3 bolts and No. 2 exhaust manifold heat insulator.

INSTALLATION

1. INSTALL NO. 2 EXHAUST MANIFOLD HEAT INSULATOR




(a) Install the No. 2 exhaust manifold heat insulator with the 3 bolts.

Torque: **12 N·m (122 kgf·cm, 9ft·lbf)**

T

2. INSTALL EXHAUST MANIFOLD




(a) Install 2 new gaskets and the exhaust manifold with the 7 nuts.

Torque: **21 N·m (214 kgf·cm, 15ft·lbf)**

T

3. INSTALL MANIFOLD STAY



(a) Install the manifold stay with the 3 bolts.

Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**

T


4. INSTALL AIR FUEL RATIO SENSOR

INFO


5. INSTALL NO. 1 EXHAUST MANIFOLD HEAT INSULATOR

(a) Install the No. 1 exhaust manifold heat insulator with the 3 bolts.

Torque: **12 N·m (122 kgf·cm, 9ft·lbf)**



6. INSTALL FRONT NO. 1 FLOOR HEAT INSULATOR



(a) Install the No. 1 floor heat insulator with the 3 nuts.


Torque: **5.5 N·m (56 kgf·cm, 49in·lbf)**

7. INSTALL FRONT EXHAUST PIPE ASSEMBLY (w/ Exhaust Heat Recirculation System)

NOTICE:

When installing the water hose, ensure that the exhaust heat recirculation system is filled with coolant. Otherwise, the electric water pump may be damaged.

(a) Using a vernier caliper, measure the free length of the compression springs.



Minimum (front)	41.5 mm (1.64 in.)
Minimum (rear)	38.5 mm (1.52 in.)

HINT:

A77867 If the free length is less than minimum, replace the compression spring.


(b) Fully insert 2 new gaskets to the exhaust manifold and front exhaust pipe assembly.

(c) Using a plastic hammer and wooden block, tap in the new gaskets until its surface is flush with the exhaust manifold and front exhaust pipe assembly.

Text in Illustration


*1	Exhaust Manifold and Front Exhaust Pipe Assembly
----	--

*2	Gasket
*3	Wooden Block



- Be careful with the installation direction of the gaskets.
- Do not reuse the gaskets.
- Do not damage the gaskets.
- Do not push in the gasket by using the exhaust pipe when connecting it.


(d) Connect the front exhaust pipe assembly to the 3 exhaust pipe supports.



(e) Install the front exhaust pipe assembly with the 4 bolts and 4 compression springs.




Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**




(f) Connect the 2 heater water hoses.

(g) Connect the 3 clamps and oxygen sensor connector.



8. INSTALL FRONT EXHAUST PIPE ASSEMBLY (w/o Exhaust Heat Recirculation System)

(a) Using a vernier caliper, measure the free length of the compression springs.




Minimum (front)	41.5 mm (1.64 in.)
Minimum (rear)	38.5 mm (1.52 in.)

HINT:

^{A77867} If the free length is less than minimum, replace the compression spring.

(b) Fully insert 2 new gaskets to the exhaust manifold and front exhaust pipe assembly.

(c) Using a plastic hammer and wooden block, tap in the new gaskets until its surface is flush with the exhaust manifold and front exhaust pipe assembly.



Text in Illustration



*1	Exhaust Manifold and Front Exhaust Pipe Assembly
*2	Gasket
*3	Wooden Block

- Be careful with the installation direction of the gaskets.
- Do not reuse the gaskets.
- Do not damage the gaskets.
- Do not push in the gasket by using the exhaust pipe when connecting it.

(d) Connect the front exhaust pipe assembly to the 3 exhaust pipe supports.

(e) Install the front exhaust pipe assembly with the 4 bolts and 4 compression springs.

Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**



9. ADD COOLANT (for Engine with Exhaust Heat Recirculation System)_ INFO

10. INSPECT FOR COOLANT LEAK (for Engine with Exhaust Heat Recirculation System)_ INFO

11. INSTALL FRONT CENTER FLOOR BRACE_ INFO

12. INSTALL FRONT NO. 3 ENGINE UNDER COVER_ INFO




13. INSTALL NO. 2 ENGINE UNDER COVER

14. INSTALL NO. 1 ENGINE UNDER COVER

15. INSPECT FOR EXHAUST GAS LEAK

COMPONENTS

ILLUSTRATION



N*m (kgf*cm, ft.*lbf): Specified torque

* For use with SST

● Non-reusable part


T

REMOVAL

1. DRAIN COOLANT (for Engine with Exhaust Heat Recirculation System)

INFO

2. REMOVE TAIL EXHAUST PIPE ASSEMBLY




(a) Remove the 2 bolts and 2 compression springs.

T

(b) Remove the tail exhaust pipe assembly from the 2 exhaust pipe supports.

(c) Remove the gasket from the front exhaust pipe assembly.


3. REMOVE FRONT NO. 3 ENGINE UNDER COVER



(a) Remove the 4 clips and front No. 3 engine under cover.

T

4. REMOVE FRONT CENTER FLOOR BRACE




(a) Remove the 4 bolts and front center floor brace.

T

5. REMOVE OXYGEN SENSOR

INFO

6. REMOVE FRONT EXHAUST PIPE ASSEMBLY (w/ Exhaust Heat Recirculation System)



(a) Disconnect the 2 heater water hoses.




(b) Remove the 2 bolts and 2 compression springs.

(c) Remove the front exhaust pipe assembly from the 3 exhaust pipe supports.

(d) Remove the gasket from the exhaust manifold.

7. REMOVE FRONT EXHAUST PIPE ASSEMBLY (w/o Exhaust Heat Recirculation System)



(a) Remove the 2 bolts and 2 compression springs.

(b) Remove the front exhaust pipe assembly from the 3 exhaust pipe supports.


(c) Remove the gasket from the exhaust manifold.

INSTALLATION

1. INSTALL FRONT EXHAUST PIPE ASSEMBLY (w/ Exhaust Heat Recirculation System)

NOTICE:

When installing the water hose, ensure that the exhaust heat recirculation system is filled with coolant. Otherwise, the electric water pump may be damaged.



A77857

(a) Using a vernier caliper, measure the free length of the compression springs.


Minimum	41.5 mm (1.64 in.)
---------	--------------------

HINT:

If the free length is less than minimum, replace the compression spring.

(b) Fully insert a new gasket to the exhaust manifold.

(c) Using a plastic hammer and wooden block, tap in the new gasket until its surface is flush with the exhaust manifold.



Text in Illustration



*1	Exhaust Manifold
*2	Gasket
*3	Wooden Block

- Be careful with the installation direction of the gasket.
- Do not reuse the gasket.
- Do not damage the gasket.
- Do not push in the gasket by using the exhaust pipe when connecting it.

(d) Connect the front exhaust pipe assembly to the 3 exhaust pipe supports.

(e) Install the front exhaust pipe assembly with the 2 bolts and 2 compression springs.


Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**



(f) Connect the 2 heater water hoses.

2. INSTALL FRONT EXHAUST PIPE ASSEMBLY (w/o Exhaust Heat Recirculation System)

(a) Using a vernier caliper, measure the free length of the compression springs.



Minimum	41.5 mm (1.64 in.)
---------	--------------------


HINT:

If the free length is less than minimum, replace the compression spring.

(b) Fully insert a new gasket to the exhaust manifold.

(c) Using a plastic hammer and wooden block, tap in the new gasket until its surface is flush with the exhaust manifold.


Text in Illustration



*1	Exhaust Manifold
*2	Gasket
*3	Wooden Block

- Be careful with the installation direction of the gasket.
- Do not reuse the gasket.
- Do not damage the gasket.
- Do not push in the gasket by using the exhaust pipe when connecting it.

(d) Connect the front exhaust pipe assembly to the 3 exhaust pipe supports.




(e) Install the front exhaust pipe assembly with the 2 bolts and 2 compression springs.

Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**

3. INSTALL OXYGEN SENSOR

INFO


4. INSTALL FRONT CENTER FLOOR BRACE



(a) Install the front center floor brace with the 4 bolts.

Torque: **51 N·m (520 kgf·cm, 38ft·lbf)**


5. INSTALL FRONT NO. 3 ENGINE UNDER COVER



(a) Install the front No. 3 engine under cover with the 4 clips.

6. INSTALL TAIL EXHAUST PIPE ASSEMBLY

(a) Using a vernier caliper, measure the free length of the compression springs.



Minimum	38.5 mm (1.52 in.)
---------	--------------------


HINT:

If the free length is less than minimum, replace the compression spring.

A77867

(b) Fully insert a new gasket to the front exhaust pipe assembly.

(c) Using a plastic hammer and wooden block, tap in the new gasket until its surface is flush with the front exhaust pipe assembly.




Text in Illustration

*1	Front Exhaust Pipe Assembly
*2	Gasket
*3	Wooden Block

- Be careful with the installation direction of the gasket.
- Do not reuse the gasket.
- Do not damage the gasket.
- Do not push in the gasket by using the exhaust pipe when connecting it.

(d) Connect the tail exhaust pipe assembly to the 2 exhaust pipe supports.



(e) Install the tail exhaust pipe assembly with the 2 bolts and 2 compression springs.

Torque: **43 N·m (440 kgf·cm, 32ft·lbf)**

7. ADD COOLANT (for Engine with Exhaust Heat Recirculation System) INFO

8. INSPECT FOR COOLANT LEAK (for Engine with Exhaust Heat Recirculation System) INFO

9. INSPECT FOR EXHAUST GAS LEAK