

NXP AN11461 sensor Application note

<http://www.manuallib.com/nxp/an11461-sensor-application-note.html>

This application note is related to the installation procedures of the PTEV501B Board. It describes the board and the required actions to hand on quickly the Evaluation board.

Manuallib.com collects and classifies the global product instruction manuals to help users access anytime and anywhere, helping users make better use of products.

<http://www.manuallib.com>

AN11461

Quick Start Up Guide PTEV501B Board

Rev. 1.2 — 6 March 2014
277612

Application note
COMPANY PUBLIC

Document information

Info	Content
Keywords	PTEV501, PT501, LPCXpresso, MCU, Code Red, eclipse, LPC1227, reader library
Abstract	This application note is related to the installation procedures of the PTEV501B Board. It describes the board and the required actions to hand on quickly the Evaluation board.



Revision history

Rev	Date	Description
1.2	20140306	Updated clock configuration for use with external clock source
1.1	20131212	Added Mass erase description and schematics of PTEV501B analog part
1.0	20131118	First release

Contact information

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

1. Introduction

This application note gives a detailed overview of the hardware for operating with the PT501 NFC Card Emulation and NFC Peer-to-Peer Solution [1]. We use the LPCXpresso LPC 1227 [4] and the Blueboard (**Chapter 2**), the installation procedures of the Development Environment (**Chapter 5.1**) and the handling of the project using the NXP Reader Library (**Chapter 5.3**).

The projects used in this documentation are:

- Card Emulation

2. Hardware overview of the PT501 Card Emulation solution

The PT501 Card Emulation solution is made up of 2 separate boards:

- A PTEV501B Evaluation board [3] provided by NXP (**12NC**: 9353 029 06699). This board has connectors which are designed to fit exactly to the ones of the companion LPCXpresso LPC 1227 development board.
- A commercial LPCXpresso LPC 1227 development board [4] (**12NC**: 935294603598, **Type**: OM13008) which can be provided by NXP or bought directly on the market. See [2].

Once the two boards are put together via the connectors, the PT501 Card Emulation solution is ready for use.

2.1 PTEV501B Evaluation board




Fig 1. Picture of PTEV501B Evaluation board

The PTEV501B Evaluation board embeds the PT501 generic 13.56 MHz communication interface, with matching network and the antenna. The PT501 supports different kind of contactless communication methods and protocols at 13.56 MHz:

- Passive target device for NFC IP-1 mode communication (Peer to Peer)
- Card operation mode supporting ISO/IEC 14443-A and FeliCa compliant protocol

Thanks to the relevant solder bridges, the host link of PTEV501B Evaluation board can be configured for:

- I²C
- SPI




Fig 2. Picture of solder bridges in default configuration

The default interface configuration of the PTEV501B Evaluation board is SPI. The detailed interface configuration is described in section 2.6.

2.1.1 Comparison with the PNEV512B Evaluation board

The PTEV501B has basically the same board layout as the PNEV512B Evaluation board. Since the PT501 acts as passive device in card emulation and P2P mode, all parts for the transmitter output are not necessary. This is visible if one compares the two boards as in Figure 3.




Fig 3. Comparison of PTEV501B and PNEV512B

Figure 4 and 5 show the analog parts of the PTEV501B and PNEV512B boards. DNP (do not place) means that this components have routed footprints but are not placed on the PCB to show the differences to the PNEV512B.

Table 2. Unused components of the PNEV512B analog part

Component type	Part Nr.
Inductor	L2, L3, L4
Resistor	R23
Capacitor	C7, C8, C14, C16, C17, C18, C21, C22, C23, C24

2.2 CE certification of the Blueboard

The PTEV501B V1.0 is CE certified.

2.3 LPCXpresso LPC1227 development board

The LPC1227 development board integrates a NXP ARM Cortex-M0 microcontroller LPC1227 with 128 Kbytes of Flash memory and 8 Kbytes of RAM. It integrates a lot of hardware parts:

- 1 Serial UART interface,
- 1 SPI controller,
- 1 I²C controller,
- Serial Wire test/debug interface,
- For detailed information, see LPC12xx User Manual [5]

The LPCXpresso board contains a JTAG/ SWD debugger called the “LPC-Link” and a target MCU. LPC-Link is equipped with a 10-pin JTAG header and it seamlessly connects to the target via USB (the USB interface and other debug features are provided by NXP’s ARM9 based LPC3154 MCU).




Fig 6. Picture of LPCXpresso LPC1227 development board

2.4 Preparation of the hardware

The first step after unpacking the Blue Board and the LPCXpresso is soldering the connectors onto the boards to get them together. In our example we use a multipoint connector as one can see on the pictures below.




Fig 7. Multipoint Connectors we used

One may buy these connectors at any electronic store. Here are some examples [7]. After soldering the connectors connect the boards as shown on the following figure.




Fig 8. LPCXpresso with the Multipoint Connectors

Now the hardware is ready to use. Please connect the LPCXpresso board with the Blueboard.




Fig 9. Connect the two boards

2.5 Interesting points of measurement

On the PTEV501B Evaluation board are test pads for measurement purposes.

- VCC
- D6
- AUX1
- SIGOUT
- GND
- D7
- AUX2
- IRQ
- D5
- ALE
- SIGIN
- VMID




Fig 10. Interesting points of measurement

2.6 Preparing the Blueboard for the use with SPI or I²C

The Blueboard is generally delivered in SPI configuration. To change the interface to I²C the four appropriate 0R0 resistors in the interface config section need to be resoldered on the I²C side of the solder jumpers. Also the two 0R0 resistors at A0 and A1 need to be changed.

Table 3. A0 and A1 interface configuration

Appropriate solder jumpers (0R0 resistors) for interface configuration

Signal	Interface type	
	SPI	I ² C
A0	R20	R21
A1	R24	R23

3. PT501 clock requirements

The PT501 is characterized to a frequency of **27.12 MHz**, but it is possible to operate it with a frequency between **1 MHz** and **33 MHz** on pin OSZIN. As clock source any stable CLK-signal in this frequency range can be used. To avoid that unwanted noise disturbs the clock, the PT501 has an internal frequency check.

The operating frequency of 13.56 MHz and the expected 13.56 MHz, derived from the 27.12MHz clock source are compared. If the frequencies differ too much, the received RF-clock is assumed to be a disturbance and the card cannot be used. This is the case e.g. if an external clock of 2 MHz is provided on the CLK input pin.

To use other frequencies than 13.56 MHz the RF-clock frequency check can be disabled by register settings. See 3.2 *Software configuration*.

Note: The correct register settings to disable the frequency check are mandatory if a clock **below 23 MHz** is used, between 23 MHz and 33 MHz it can be enabled.

3.1 Hardware configuration

The PTEV501B is prepared to be used in conjunction with an on board crystal oscillator or a clock generated by the LPC1227 LPCXpresso Board. The following table describes the necessary soldering changes for the different configurations:

Table 4. PT501 clock configuration

R31 can be placed as 0Ω resistor or solder bridge

Clock source	R31	XT1	C29	C30
Crystal oscillator (default)	Not placed	27,12 MHz	15pF	15pF
External clock from LPC1227 LPCXpresso Board	0 Ω	Not placed	Not placed	Not placed




Fig 13. Crystal oscillator as clock source (default)





Fig 14. LPC1227 as clock source

Figure 15a shows a snippet of the PTEV501B schematics. If one would like to use a different CLK-source as described above, the external clock signal should be connected to pin OSCIN by connecting to one of the component pads shown in Figure 15b.



a.

b.

Fig 15. Schematics of the PTEV501B clock input

3.2 Software configuration

This section describes the software configuration for the PTEV501B with an external clock source. This can either be the CLKOUT-function of the LPC1227 or any stable clock signal in the frequency range of 1 MHz to 33 MHz.

3.2.1 LPC1227 LPCXpresso Board as clock source

Please make sure to change the hardware configuration as defined in section 3 before loading and running the modified software package into the LPC1227 to avoid breaking any hardware.

To use the PTEV501B with the LPC1227 LPCXpresso Board as external clock source some modifications need to be done in the *system_LPC12xx.c* file:

3.2.1.1 Configure the Main Clock

For this example configuration a frequency of 24 MHz is used. To achieve this following settings of the SYSPLLCTRL register are required.

The SYSPLLCLKSEL_Val (0x01 for System Oscillator) defines the clock source for the internal System PLL which must be activated by setting the SYSPLL_SETUP to 1.

The SYSPLLCTRL_Val specifies the output frequency of the System PLL. This can be configured by the Bits 0-6 of the SYSPLLCTRL register, in this case a frequency of 24 MHz.

Other system clock settings may also be used as long as the LPC1227 generated clock is in the range as defined in section 3. Please refer to the LPC122x User Manual [6] and Data Sheet [5] for detailed description of the supported configurations.

The MAINCLKSEL_Val sets the clock source for the system Main clock (0x3 for the System PLL output).

```

126 */
127 #define CLOCK_SETUP          1
128 #define MAINCLK_SETUP        1
129 #define SYSOSC_SETUP          1
130 #define SYSOSCCTRL_Val       0x00000000
131 #define SYSPLLCLKSEL_Val     0x00000001
132 #define SYSPLL_SETUP         1
133 #define SYSPLLCTRL_Val       0x00000041
134 #define MAINCLKSEL_Val       0x00000003
    
```

Fig 16. Main Clock configuration

3.2.1.2 Enable the CLKOUT functionality

To use the CLKOUT pin of the LPC1227 the CLKOUTCLK_SETUP has to be enabled. The CLKOUTCLKSEL_Val specifies the clock source, here 0x3 for the Main clock at 24 MHz, so no further division by the CLKOUTCLKDIV_Val is needed (0x01).

```


142 #define PMUCFG_SETUP          0
143 #define PMUCFG_Val           0x00000400
144 #define CLKOUTCLK_SETUP      1
145 #define CLKOUTCLKSEL_Val     0x00000003
146 #define CLKOUTCLKDIV_Val     0x00000001
147
148 /*
149 //----- <<< end of configuration section >
150 */
    
```

Fig 17. CLKOUT configuration

3.2.1.3 Configure the CLKOUT setup

With the enabled CLKOUTCLK_SETUP in the previous section the `#if` statement for the CLKOUT configuration is true.

The CLKOUT function is routed to PIO0_12 and needs to be configured (0x02). It is very important to update the clock source by toggling the CLKOUTUEN register.



```

481
482 #if (CLKOUTCLK_SETUP)
483   LPC_IOCON->PIO0_12 |= 0x02;      /* CLKOUT function */
484   LPC_SYSCON->CLKOUTCLKSEL = CLKOUTCLKSEL_Val;
485   LPC_SYSCON->CLKOUTUEN = 0x01;  /* update CLKOUT source
486   LPC_SYSCON->CLKOUTUEN = 0x00;
487   LPC_SYSCON->CLKOUTUEN = 0x01;
488   LPC_SYSCON->CLKOUTDIV = CLKOUTCLKDIV_Val;
489 #endif

```

Fig 18. CLKOUT setup configuration


For detailed information about the LPC1227 clock configuration and register settings please refer to the product datasheet and user manual.

3.2.2 Other clock source

If any other clock source with a frequency between 1 MHz and 23 MHz is used for the PT501, following register settings are mandatory to turn off the frequency check:

1. Write 0xBF to register 0x3C
2. Read from register 0x3C

In the Card Emulation software package this register setting can be activated/deactivated by the `#define PT501_EXT_XTAL` statement in `main.c`.



```

156 #ifndef PT501_EXT_XTAL
157   /* switch off frequency check */
158   uint8_t value = 0;
159
160   status = phhalHw_WriteRegister((phhalHw_Rc523_DataParams_t *)&hal, 0x3C, 0xBF);
161   CHECK_STATUS(status);
162
163   status = phhalHw_ReadRegister((phhalHw_Rc523_DataParams_t *)&hal, 0x3C, &value);
164   CHECK_STATUS(status);
165 #endif

```

Fig 19. Register settings for the frequency check function in main.c

4. Installation of the LPCXpresso Board

The guidelines to install the reader are as follows:

- Connect the LPCXpresso Board to a real USB2.0 port of the PC (for speed reasons) using the mini-USB connector. The PC detects and installs the Board automatically.
- Once the Board is installed, open the Device Manager of the PC to check that the installation is successful. The item “USB Device with DFU Capabilities” is displayed.

Please be sure to always connect both USB ports to the computer. If the USB port of the Blueboard is not connected to an USB port, it won't work because of the missing power.




Fig 20. Enumeration of the LPCXpresso Board in Device Manager Window

5. Managing the PT501 CE solution project with LPCXpresso IDE

The PT501 Card emulation solution project is delivered in a zip package. It can be extracted, edited, compiled and linked with LPCXpresso™ IDE.


LPCXpresso™ is a new, low-cost development platform available from NXP. It supports NXP's ARM-based LPC microcontrollers. The platform is comprised of a simplified Eclipse-based IDE and low-cost target boards which include an attached JTAG debugger.

Use at least the LPCXpresso version 4.2 or higher to benefit a bug-free IDE and the up-to-date features.

This tool can be freely downloaded from the LPCXpresso website [2]. Before one can download the software, it is necessary to create an account. Creating an account is absolutely free.

5.1 Installation of LPCXpresso IDE

The IDE is installed into a single directory, of one’s choice. Multiple versions can be installed simultaneously without any issues. The installation starts after double-clicking the installer file. Then click “next” on the setup wizard.



Then read the license agreement then click next.




Fig 22. LPCXpresso installation setup wizard 2

There are numbers of other screens on the setup wizard but generally the default options can be accepted. After installation, an information file will be displayed. Click “Next” to accomplish the installation.




Fig 23. LPCXpresso installation setup wizard 3

After this installation step one will be asked if he wants to install some required drivers. The installation of these drivers should be accepted.




Fig 24. Windows Security dialog

After the setup wizard has finished one can launch the newly installed IDE.




Fig 25. LPCXpresso installation setup wizard 4




Fig 26. LPCXpresso IDE

Directly after the first start of the Eclipse IDE one will see an info dialog, that this is only an unregistered copy of LPCXpresso IDE. Just confirm the dialog and follow the instructions on the Welcome Screen to get a registered version without the debug limit of 8k. The registration is free and needs one to navigate to the website of Code Red. The Link is shown in the menu, Help → Product activation → Create Serial number and Activate...




Fig 27. Product activation




Fig 28. Product activation

If one doesn't already have an account at Code Red, please sign up to get an activation code. The code will be sent to the provided e-mail address.




Fig 29. Product activation

Once the activation code arrives please open the activation window by pointing to Help → Product activation → Enter Activation code, and enter the code.

The success of the product activation will be confirmed by an info dialog.

5.2 Extraction of the PT501 CE solution project

Once the LPCXpresso™ IDE is installed on a Computer, the sequence of installing the reference reader project is indicated:

- Start the LPCXpresso™ IDE.
- Select the option "Import project(s)" (see picture below).
- Browse the zip archive.

- LPCXpresso™ IDE unzips the software package.
- The software package is ready for use.




Fig 30. Importing a project into the LPCXpresso IDE

At the Quick Panel on the left side, choose “Import projects(s)”.




Fig 31. Importing a project into the LPCXpresso IDE

Browse the desired project and click “Next”.




Fig 32. Importing a project into the LPCXpresso IDE

When the import process has finished one can start browsing the code. Most interesting might be the main.c which is located in ../src/main.c in the project.

Before one can run the project, the Evaluation board with the PT501 needs to be connected to the computer. Wait until the according drivers have been installed.

5.3 Start the project

One can quickly start the reader project by editing the main function in the module **main.c**. This function first performs the hardware initializations of the LPC1227 and the PT501.

Detailed descriptions of the code in the form of comments are provided in the **main.c** file. This should provide a detailed overview of how to initialize certain components.

5.3.1 Run the project

Before running the project, please ensure that the LPCXpresso with the PTEV501B Evaluation board is connected with the computer.




Fig 33. Run the project

Choose the desired project and click at the left side the Debug Button like shown at the example picture.




Fig 34. Run the project

After the build process one can see the size of the image in the console window.




Fig 35. Run the project

The initialization of the LPC-Link can take a few seconds.




Fig 36. Run the project

After the software upload, the execution of the project starts immediately.




Fig 37. Stop the project

After the execution has reached the end of the main function please click the Terminate button to stop the execution. Otherwise one won't be able to rerun the project.

One can now do the following with the buttons towards the top of the "Debug" view:

	Run the program.
	Step over C/C++ line.
	Step into a function.
	Stop the debugger.
	Pause execution of the running program.
	Instruction stepping mode (disassembly).

Fig 38. Debug Buttons

6. Card Emulation - Associated Project

6.1 Tag Type 2 and Type 4 Card Emulation

This example only works with the LPCXpresso LPC1227 development board.

The PT501 supports 2 different operating modes:

- Passive target device for NFC IP-1 mode communication (Peer to Peer)
- Card operation mode supporting ISO/IEC 14443-A and FeliCa compliant protocol

The card operation mode is passive mode, in which the PT501 does not generate an RF field but acts as a card that modulates the field for communication with the reader. The IC only supports parts of the ISO/IEC 14443-A protocol, the ISO/IEC 14443-4 as well as the ISO/IEC 7816-4 commands need to be provided by the Microcontroller.

A specification to store data for any kind of service and application is specified in the NFC Forum and it is called NFC Data Exchange Format. Storing NDEF formatted data inside contactless card products as mapping models as well as the management of NFC forum device as a specific platform such as a NFC Forum Type 4 Tag are defined in [9]. The following project shows an exemplary implementation of a Tag 4 Type Card on the PN501. Therefore one NDEF File and one capability container (CC) file, with ISO file identifier (ISO FID) equal to E103h, are presented to the reader.

6.1.1 Configuration of the example project

In order to change some of the possible options before compiling the project, the file "src\nxprplib\intfs\phCardEmu_Options.h" should be edited. This file contains toggles to enable/disable the T2T and T4T functionality, memory sizes, as well as the pin numbers in which the PT501 chip is connected to the LPC1227. Further options are also indicated on the file.

Before flashing the modified project it is mandatory to perform a **Mass erase** on the flash memory of the LPC1227. This can be achieved by clicking the **Program Flash** icon in the LPCXpresso IDE.




Fig 39. Program Flash icon in LPCXpresso IDE

In the Program Flash wizard the Mass erase feature can be found in the **Erase flash memory** tab. After activating the **Mass erase** algorithm click OK to perform the procedure.




Fig 40. Program Flash wizard with Erase flash memory tab

6.1.2 Changing the NDEF message

The predefined NDEF message can be changed in the following files:

- T4T: ../src/nxprdlb/comps/phce7816p4T_Apps/phce7816p4T_T4T_Const.c

```

main.c | phce7816p4T_T4T_Const.c
1 #include <phce7816p4T_T4T.h>
2
3 #define NORMAL 0
4 #define MAX_SMARTPOSTER 1
5 #define BIG_MIME_IMAGE 2
6 #define MAX_VCARD 3
7
8 // define this to one of the above for NDEF predefined content
9 #define T4T_NDEFFILE_PREDEF NORMAL
10
11 // This is the data structure returned by the GetData on tag GetVersion
12 const byte TLV_VERSION[] = {
13     P1_GETDATA_TAG_VERSION, P2_GETDATA_TAG_VERSION, (byte)0x16, // header: version informat
14     (byte)'1', (byte)'3', // year in ASCII
15     (byte)'0', (byte)'1', // month in ASCII
16     (byte)'1', (byte)'5', // day in ASCII
17     (byte)' ',
18     (byte)'N', (byte)'X', (byte)'P',

```

Fig 41. Change NDEF content for T4T

- T2T: ../src/nxprdlb/comps/phceT2TCmdHdl/src/Sw/phceT2T_Const.c

```

main.c | phceT2T_Const.c
1 #include "phceT2T_Sw.h"
2
3 #define NORMAL 0
4 #define MAX_SMARTPOSTER 1
5 #define BIG_MIME_IMAGE 2
6 #define MAX_VCARD 3
7
8 // define this to one of the above for NDEF predefined content
9 #define T4T_NDEFFILE_PREDEF NORMAL
10
11 const uint8_t T2T_LOCK_CC_DEF[16] = {
12     0x00, 0x00, 0x00, 0x00, // internal bytes
13     0x00, 0x00, 0x00, 0x00, // internal bytes
14     0x00, 0x00, 0x00, 0x00, // internal bytes AND
15     // static lock bytes (
16     // CC
17     0xE1, 0x10, 0x00, 0x00 // 3rd byte - data mem
18 };
19
20

```

Fig 42. Change NDEF content for T2T

6.1.3 Program flow




Fig 43. Program flow of the Card Emulation application

The first blocks describe the initialization of the necessary layers and components independent of the card emulation. Depending which tag type is used the appropriate component will then be initialized. If Tag Type 2 and Tag Type 4 are enabled, both are

being initialized. After applying the protocol settings, the PT501 waits for a successful activation or the card side. According to the first command (RATS – yes or no) after the card activation the appropriate tag type component starts.

7. References

- [1] **PT501 data sheet**
http://www.nxp.com/documents/data_sheet/PT501.pdf
- [2] **LPCXpresso website**
www.nxp.com/redirect/lpcware.com/lpcxpresso/downloads/older
- [3] **PTEV501 Evaluation board**
<http://www.nxp.com/demoboard/PTEV501.html>
- [4] **LPC1227 LPCXpresso Board**
www.nxp.com/redirect/embeddedartists.com/products/lpcxpresso/lpc1227_xpr.php
- [5] **LPC122x family data sheet**
http://www.nxp.com/documents/data_sheet/LPC122X.pdf
- [6] **LPC122X family User Manual**
http://www.nxp.com/documents/user_manual/UM10441.pdf
- [7] **Multipoint Connectors we used:**
Grid Dimension: 2.54mm, at least 27 pins
www.nxp.com/redirect/conrad.at/ce/de/product/741119/STIFTLEISTE-1-X-36-POLIG-VERGOL-RM-254
and
www.nxp.com/redirect/conrad.at/ce/de/product/736427/BUCHSENLEISTE-EINREIHIG-36-POLIG-RM254
- [8] **Direct link to the NXP Reader Library**
<http://www.nxp.com/documents/software/200310.zip>
- [9] **TYPE 4 TAG: NFC Forum, Type 4 Tag Operation Specification, Version 1.0, March 13, 2007**
www.nxp.com/redirect/nfc-forum.org/specs

8. Legal information

8.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

8.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors accepts no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary

testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Evaluation products — This product is provided on an "as is" and "with all faults" basis for evaluation purposes only. NXP Semiconductors, its affiliates and their suppliers expressly disclaim all warranties, whether express, implied or statutory, including but not limited to the implied warranties of non-infringement, merchantability and fitness for a particular purpose. The entire risk as to the quality, or arising out of the use or performance, of this product remains with customer.

In no event shall NXP Semiconductors, its affiliates or their suppliers be liable to customer for any special, indirect, consequential, punitive or incidental damages (including without limitation damages for loss of business, business interruption, loss of use, loss of data or information, and the like) arising out of the use of or inability to use the product, whether or not based on tort (including negligence), strict liability, breach of contract, breach of warranty or any other theory, even if advised of the possibility of such damages.

Notwithstanding any damages that customer might incur for any reason whatsoever (including without limitation, all damages referenced above and all direct or general damages), the entire liability of NXP Semiconductors, its affiliates and their suppliers and customer's exclusive remedy for all of the foregoing shall be limited to actual damages incurred by customer based on reasonable reliance up to the greater of the amount actually paid by customer for the product or five dollars (US\$5.00). The foregoing limitations, exclusions and disclaimers shall apply to the maximum extent permitted by applicable law, even if any remedy fails of its essential purpose.

8.3 Licenses

Purchase of NXP ICs with ISO/IEC 14443 type B functionality



This NXP Semiconductors IC is ISO/IEC 14443 Type B software enabled and is licensed under Innovatron's Contactless Card patents license for ISO/IEC 14443 B.

The license includes the right to use the IC in systems and/or end-user equipment.

RATP/Innovatron
Technology

8.4 Trademarks

Notice: All referenced brands, product names, service names and trademarks are property of their respective owners.

MIFARE — is a trademark of NXP N.V.

DESFire — is a trademark of NXP N.V.

MIFARE Ultralight — is a trademark of NXP N.V.

MIFARE Plus — is a trademark of NXP N.V.

9. List of figures

Fig 1.	Picture of PTEV501B Evaluation board	3	Fig 22.	LPCXpresso installation setup wizard 2	16
Fig 2.	Picture of solder bridges in default configuration	4	Fig 23.	LPCXpresso installation setup wizard 3	16
Fig 3.	Comparison of PTEV501B and PNEV512B	4	Fig 24.	Windows Security dialog	17
Fig 4.	Schematics of the PTEV501B analog part	5	Fig 25.	LPCXpresso installation setup wizard 4	17
Fig 5.	Schematics of the PNEV512B analog part	5	Fig 26.	LPCXpresso IDE	18
Fig 6.	Picture of LPCXpresso LPC1227 development board	6	Fig 27.	Product activation	18
Fig 7.	Multipoint Connectors we used	7	Fig 28.	Product activation	19
Fig 8.	LPCXpresso with the Multipoint Connectors	7	Fig 29.	Product activation	19
Fig 9.	Connect the two boards	7	Fig 30.	Importing a project into the LPCXpresso IDE ..	20
Fig 10.	Interesting points of measurement	8	Fig 31.	Importing a project into the LPCXpresso IDE ..	21
Fig 11.	Blueboard in SPI configuration	9	Fig 32.	Importing a project into the LPCXpresso IDE ..	21
Fig 12.	Blueboard in I ² C configuration	9	Fig 33.	Run the project	22
Fig 13.	Crystal oscillator as clock source (default)	10	Fig 34.	Run the project	22
Fig 14.	LPC1227 as clock source	11	Fig 35.	Run the project	23
Fig 15.	Schematics of the PTEV501B clock input	11	Fig 36.	Run the project	23
Fig 16.	Main Clock configuration	12	Fig 37.	Stop the project	24
Fig 17.	CLKOUT configuration	12	Fig 38.	Debug Buttons	24
Fig 18.	CLKOUT setup configuration	13	Fig 39.	Program Flash icon in LPCXpresso IDE	25
Fig 19.	Register settings for the frequency check function in main.c	13	Fig 40.	Program Flash wizard with Erase flash memory tab	26
Fig 20.	Enumeration of the LPCXpresso Board in Device Manager Window	14	Fig 41.	Change NDEF content for T4T	27
Fig 21.	LPCXpresso installation setup wizard 1	15	Fig 42.	Change NDEF content for T2T	27
			Fig 43.	Program flow of the Card Emulation application	28

10. Contents

1.	Introduction	3
2.	Hardware overview of the PT501 Card Emulation solution	3
2.1	PTEV501B Evaluation board.....	3
2.1.1	Comparison with the PNEV512B Evaluation board.....	4
2.2	CE certification of the Blueboard.....	6
2.3	LPCXpresso LPC1227 development board	6
2.4	Preparation of the hardware.....	6
2.5	Interesting points of measurement.....	8
2.6	Preparing the Blueboard for the use with SPI or I ² C	8
3.	PT501 clock requirements	10
3.1	Hardware configuration	10
3.2	Software configuration	11
3.2.1	LPC1227 LPCXpresso Board as clock source.....	11
3.2.1.1	Configure the Main Clock.....	12
3.2.1.2	Enable the CLKOUT functionality.....	12
3.2.1.3	Configure the CLKOUT setup	13
3.2.2	Other clock source	13
4.	Installation of the LPCXpresso Board	14
5.	Managing the PT501 CE solution project with LPCXpresso IDE	14
5.1	Installation of LPCXpresso IDE.....	15
5.2	Extraction of the PT501 CE solution project.....	19
5.3	Start the project.....	22
5.3.1	Run the project.....	22
6.	Card Emulation - Associated Project	25
6.1	Tag Type 2 and Type 4 Card Emulation	25
6.1.1	Configuration of the example project.....	25
6.1.2	Changing the NDEF message.....	26
6.1.3	Program flow.....	28
7.	References	29
8.	Legal information	30
8.1	Definitions	30
8.2	Disclaimers.....	30
8.3	Licenses.....	30
8.4	Trademarks	30
9.	List of figures.....	31
10.	Contents.....	32

Please be aware that important notices concerning this document and the product(s) described herein, have been included in the section 'Legal information'.

© NXP N.V. 2014.

All rights reserved.

For more information, visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

Date of release: 6 March 2014
277612

Document identifier: AN11461