










3



Register your product and get support at
www.philips.com/welcome

DVP3310K



Warning

- Risk of overheating! Never install the DVD player in a confined space. Always leave a space of at least four inches around the DVD player for ventilation. Ensure the curtains or other objects never cover the ventilation slots on the DVD player.
- Never place the DVD player, remote control or batteries near naked flames or other heat sources, including direct sunlight.
- Only use this DVD player indoors. Keep this DVD player away from water, moisture and liquid-filled objects.
- Never place this DVD player on other electrical equipment.
- Keep away from this DVD player during lightning storms.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Visible and invisible laser radiation when open. Avoid exposure to beam.

警告

- 小心过热! 切勿将DVD播放机安装在封闭空间内。始终在DVD播放机周围留出至少4英寸的空间以便通风。确保窗帘或其它物体不会遮挡DVD播放机上的通风槽。
- 切勿将DVD播放机、遥控器或电池放在明火或其它热源(包括直射的阳光)附近。
- 仅在室内使用此DVD播放机。让此DVD播放机远离水、湿气和盛有液体的物体。
- 切勿将此DVD播放机放在其它电子设备上面。
- 雷电天气期间, 请远离此DVD播放机。
- 将电源插头或设备耦合器用作断电设备时, 该断电设备应可以随时使用。
- 该设备打开时, 存在可见及不可见的激光辐射。避免直视激光束。

EN Print your user manual at www.philips.com/support



ZH_CN 要打印用户手册, 请访问 www.philips.com/support

PHILIPS 2009 © Koninklijke Philips N.V.
 All rights reserved.
 12 NC 8670 000 48856
 sgptt_908/93-2_1



PHILIPS

1



2

