



Ohaus Corporation

29 Hanover Road

Florham Park, NJ

07932-0900

INSTRUCTION MANUAL

Models CD-31 and CD-33 Indicators



TABLE OF CONTENTS

OVERVIEW OF CONTROLS	1
OVERVIEW OF DISPLAY INDICATORS	2
1. GETTING TO KNOW YOUR INDICATOR	3
1.1 Introduction	3
2. INSTALLATION	3
2.1 Unpacking and Checking	3
2.2 Selecting the Location	3
2.3 Connecting the Indicator to a Scale base	4
2.4 Connecting the RS232 Interface	4
2.4.1 Hardware	4
2.5 Connecting Power	5
2.5.1 Cautionary Notes	5
2.5.2 Turning On the Indicator	5
2.5.3 Power ON/OFF	5
2.6 Scale Base Setup	6
3. SETTING UP YOUR INDICATOR	10
3.1 Setting Time and Date	10
3.2 Readout	11
3.3 Good Manufacturing Practices (GMP) Data	13
3.4 Good Manufacturing Practices (GMP) Set	14
3.5 Print	15
3.6 RS232	16
3.7 Legal for Trade (LFT)	17
3.8 Mode	18
3.9 Units	19
3.10 Global	19
3.11 Custom Unit	21
3.12 Menu Lock-Out Protection	22

TABLE OF CONTENTS (Cont.)

4. OPERATING YOUR INDICATOR	23
4.1 Calibration23	
4.1.1 Span Calibration	24
4.1.2 User Calibration	25
4.1.3 Linearity Calibration	26
4.1.4 Calibration Test	37
4.1.5 Calibration GMP Printout	28
4.2 Weighing 29	
4.2.1 Manual Taring	29
4.2.2 Preset Taring	30
4.3 Percent Weighing	31
4.4 Parts Counting	32
4.5 Animal Weighing	33
4.6 Checkweigh34	
4.7 Printing Data	35
4.7.1 RS232 Commands	35
4.7.2 Output Formats	35
5. CARE AND MAINTENANCE	38
5.1 Troubleshooting	38
5.2 Error Codes List	39
5.3 Service Information	40
5.4 Replacement Parts	40
5.5 Accessories40	
5.6 Technical Data	40

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*