

# DECT 511 DECT 515


## User manual



Charge the handset(s) 24 hours  
before use.

# PHILIPS

## Quick start guide


The **pilot key** allows you to browse the menus. **Up**  to go left in the menus and **down**  to go right in the menus & options.

Press **+**  to select a menu or an option and validate a setting. It is also used as shortcut to menus



Answer/end a call



Make a call

Predial number &  or  and dial number

Read Call log

 up and browse 





Redial a number

 up and browse  and 



Call from phonebook

 down, browse  through the list and 

Add a name in the phonebook

Predial number and select **+**  scroll to  Store and select **+** , enter the name and press **+**  OK

Adjust the earpiece volume during a call

Scroll up  to increase the volume, scroll down  to decrease the volume

Adjust the handset loudspeaker volume

During a handsfree call, up  to increase, down  to decrease

Mute and unmute the microphone

During a call press **+**  Options, press **+**  Mute press **+**  End mute









Transfer a call/Intercom (if there are at least 2 handsets)

Press  + number phone







Read an event

Press **+**  View


Set the date and time

Press **+**  to enter the carousel, scroll to  Handset and select **+** , scroll to  Date and time and select **+**  Press **+**  to select Set date and enter the current date, press **+**  OK. Scroll to Set time and enter the current time, press **+**  OK

Set the handset external ring tone

Press **+**  to enter the carousel, scroll to  Sounds and select **+** , press to select **+**  Handset ring tones. Press to select **+**  External ring tone Browse through the list to hear the ring tones and select **+**  your ring tone

Activate/deactivate the answer machine

Press  on the base station to switch the answer machine ON or OFF

# DECT 511/DECT 515 Handset

**Pilot key**

- Press to enter the carousel or select a menu or an option
- Scroll to move through the menus & options
- Move the cursor left/right
- Scroll up to access the **Call Log** from idle mode
- Scroll down to access the **Phonebook** from idle mode
- A long press to unlock the keypad

**Loudspeaker\***

- Short press to take the line or to activate the handset loudspeaker during a call

**Keypad lock & Editing**

- Short press to insert \*
- Long press to lock/unlock the keypad in idle mode
- Long press to insert R (in between-digit pause) when dialling
- Long press to enter multitap system or Eaton<sup>®</sup> editor when entering text
- A short press to change the letter when editing in Eaton<sup>®</sup>.

**SMS key**

- Short press to directly access Send new SMS from idle mode
- Short press from the **Phonebook** or the **Call log** menu to edit an SMS

Earpiece



Microphone

**Talk**

- Press to take the line, answer a call or hang up.

**Clear/Recall**

- To correct a digit when predialling or a character when editing
- Short press to go back one menu when navigating
- Long press to return to idle mode when navigating
- To insert R for operator services when on line

**Do not disturb & case mode**

- Short press to insert # when dialling
- Long press to activate/deactivate the "Do Not Disturb" mode
- Long press to insert a pause (P) when dialling
- Press to switch case mode when editing

**Alarm clock**

- A short press to dial 0
- A long press to activate/deactivate the alarm clock

**Call transfer/Intercom**

- Short press to initiate or cancel internal call
- Short press during internal call to transfer the call or switch between internal call and External call
- Short press to answer an internal call or to release an internal call

**\*Warning :** Handsfree activation could suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.





# Icons on the handset display

The display gives information about the operation of your telephone



On first use, it is sometimes necessary to wait for a few minutes of charge before seeing icons on the display.



When charging, the battery bars scroll from empty to full status. When the handset discharges, the battery shows the status : Full , 2/3 , 1/3  and empty .



The answer machine is activated (DECT 515). **When blinking**, this symbol indicates that there is a new message on the answer machine or on the operator voice mailbox. **When fast blinking** it shows that the answer machine is full.



The ring tone is deactivated.



An external call is in progress. **When blinking**, this symbol indicates that there is an incoming external call in progress or that the line is already busy.



An internal call is in progress. **When blinking**, this symbol indicates that there is an internal incoming call.



The handset loudspeaker is activated. **When blinking**, this symbol shows that the base loudspeaker is activated (only for DECT 515).




The SMS function is activated. **When blinking**, this symbol indicates that a new SMS has been received. **When fast blinking**, it indicates that the SMS memory is full.



The handset is registered and in range of the base. **When blinking**, this symbol indicates that the handset is not registered to the base.

## DECT 511 base station



### Paging key

The paging key enables you to locate a missing handset. Press the key until the handset starts to ring. Once retrieved, press any key on the handset to end paging.

## DECT 515 base station



### New message indicator

**When blinking**, it indicates that there is a new message.

**When fast blinking**, it indicates that the answer machine memory is full.



### ON/OFF key

Press to switch the answer machine ON or OFF



### Play/Stop key

Short press to play new message

Short press to stop a message while listening to it

.....Loudspeaker



### Paging key

Press to locate all handsets



### Skip/Fast forward key

Short press to go to the next message while listening

Long press to fast forward the current message while listening



### Delete key



Short press to delete current message


Long press to delete all the messages (except unread ones)

<b>Quick start guide</b>	1
<b>DECT 511 / DECT 515 handset</b>	2
<b>Icons on the handset display</b>	3
<b>DECT 511 / DECT 515 base stations</b>	4
<b>Table of Contents</b>	5-6
<b>Menu structure</b>	7-11
<b>Conformity, Environment and Safety</b>	12
<b>Declaration of conformity</b>	
Using GAP standard compliance	13
<b>Installing the DECT 511/515</b>	
Unpacking your DECT 511	14
Unpacking your DECT 515	14
Installing the base station	15
Installing and replacing the batteries in the handset	15
Battery life and range	15
<b>Introduction</b>	
Philips screen saver	16
Idle mode	16
Understanding the menu system	16
How to navigate in the menus	16
<b>Basic principles</b>	17
<b>In-call features</b>	18
<b>Editing systems</b>	19-20
<b>SMS</b>	
Send new SMS	21
Read SMS	22
SMS settings	25
<b>Handset</b>	
Babysit mode	28
Registration	28
Rename handset	29
Date & time	29
Display contrast	30
Backlight	30
Screen saver	30

<b>Answer machine</b>	
Saved messages	31
Outgoing messages	33
Answerphone settings	33
Record and listen to a memo	37
<b>Intercom</b>	
Internal call	38
Call transfer	38
Conference call	39
Babysit mode	39
<b>Phonebook</b>	
Add new	40
View	40
<b>Call log</b>	
View	43
Delete all	45
Call log settings	45
<b>Operator services</b>	46
<b>Extra</b>	
Call duration	47
Alarm clock	47
“Do Not Disturb” mode	48
<b>Sounds</b>	
Handset ring tones	49
Base ring tones	50
Group ring tones	50
Handset ring tone volume	50
Base ring tone volume	50
My ring tones	51
Record personal melody	51
Settings	52
<b>Base</b>	
Enable registration	54
Line settings	54
Service code settings	56
<b>FAQ</b>	57-58
<b>Troubleshooting</b>	59-60
<b>Index</b>	


# Menu structure

By using the "Pilot key"  on the side of the handset, you can scroll  through the menus.





\* only available in the UK








Play/Record new  
Delete







\* only available in the UK



### Safety information

This equipment is not designed to make emergency calls when the power fails. An alternative has to be made available to allow emergency calls.

### Conformity

Hereby, Philips declares that the DECT 511xx and DECT 515xx are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. This product can only be connected to the analogue telephone network of the UK and Ireland.

### Power requirements

This product requires an electrical supply of 220-240 volts, alternating monophased power, excluding IT installations defined in standard EN 60-950. In case of power failure, the communication can be lost.

### Warning !

The electrical network is classified as hazardous according to criteria in the standard EN 60-950. The only way to power down this product is to unplug the power supply from the electrical outlet. Ensure the electrical outlet is located close to the apparatus and is always easily accessible.

### Telephone connection

The voltage on the network is classified as TNV-3 (Telecommunication Network Voltages), as defined in the standard EN 60-950.

### Safety precautions

Do not allow the handset to come into contact with water. Do not open the handset or the base station. You could be exposed to high voltages. Do not allow the charging contacts or the battery to come into contact with conductive materials.

### Environmental care

Please remember to observe the local regulations regarding the disposal of your packaging materials, exhausted batteries and old phone and where possible promote their recycling.

# Declaration of conformity

We  
Philips Consumer Electronics  
Route d'Angers  
72081 Le Mans Cedex 9  
France

Declare that the products DECT 511xx and DECT 515xx are in compliance with the Annex III of the R&TTE-Directive 1999/5/EC and then with the following essential requirements:

Article 3.1.a (protection of the health & the safety of the user) : EN 60950-1 (10/2001)

Article 3.1.b (protection requirements with respect to electromagnetic compatibility : ETSI EN 301 489-6 V1.2.1 (08/2002) & ETSI EN 301 489-1 V1.4.1 (08/2002)

Article 3.2 (effective use of the radio spectrum) EN 301 406 (2003)

The presumption of conformity with essential requirements regarding Council Directive 1999/5/EC is ensured.



Date : 10/05/2004    Le Mans  
Quality Manager, Home Communication


## Using GAP standard compliance

The GAP standard guarantees that all DECT™ GAP handsets and base stations comply with a minimum operating standard irrespective of their make. Your DECT 511/515 handset and base station are GAP compliant, which means the minimum guaranteed functions are : register a handset, take the line, receive a call and dial. The advanced features may not be available if you use another handset than a DECT 511/515 with your base station.

To register and use your DECT 511/515 handset with a GAP standard base station of a different make, first follow the procedure described in the manufacturer's instructions, then follow the procedure page 28.

To register a handset from another make to the DECT 511/515 base station, place the base station into registration mode (page 28), then follow the procedure in the manufacturer's instructions.

Philips has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.

 A financial contribution has been paid to the associated national recovery & recycling system.

 The labelled packaging material is recyclable.

DECT™ is a Trade Mark of ETSI registered for the benefit of the implementers of the DECT technology.

# Installing the DECT 511/515

## Unpacking your DECT 511

The DECT 511 package contains:

One DECT 511 base station



One DECT 511 handset



NiMh 2HR  
AAA 600 mAh  
rechargeable  
batteries



A user guide




A guarantee



A power supply



A line cord\*



## Unpacking your DECT 515

The DECT 515 package contains:

One DECT 515 base station



One DECT 515 handset



NiMh 2HR  
AAA 600 mAh  
rechargeable  
batteries



A user guide



A guarantee



A power supply



A line cord\*



In DECT 511 and DECT 515 multi-handset packs, you will also find one or more additional handsets, chargers with their power supply and additional rechargeable batteries.


**\*Warning :** You may find in the box the line adaptor delivered separately from the line cable. In this case, please, first plug this line adaptor to the line cable before connecting it to the line socket.

## Installing the base station


Situate your product close enough to the telephone and mains power sockets so that the cables will reach. To properly install the base station, plug the line cord and the power cable into the base station. Plug the cord and the cable into the wall. A beep indicates that the phone is properly installed (only available for DECT 515). If you have a broadband DSL Internet Installation, please make sure you have one DSL filter plugged directly on each line socket used in the house and check the modem and the phone are plugged in the correct filter slot (one specific for each).

**Warning!** The electrical network is classified as dangerous according to criteria in the standard EN 60-950. The only way to power down this product is to unplug the power supply from the electrical outlet. Ensure the electrical outlet is located close to the apparatus and is always easily accessible. Please take care that the power supply and telephone line are connected to the correct sockets as incorrect placement could damage your equipment.

**Warning!** *Always use the cables provided with the product.*



## Installing and replacing the batteries in the handset



To insert the batteries, open the battery cover, place the batteries as indicated and put the battery cover back. When the handset is placed on the base station the 3 battery bars scroll (if charge is needed). Allow the handset to charge for 24 hours to reach full charge. On first use it may be necessary to wait for a few minutes before seeing symbols on the display.

In case you need to change the batteries, the following type is mandatory 2HR AAA NiMh 600 mAh.

**Warning:** *the base station must always be plugged into the mains when charging or when in use. Always use rechargeable batteries.*



Batteries should not be disposed of with general household waste.

## Battery life and range

Optimal battery life is reached after 3 cycles of complete charge & discharge. When reaching the range limit and the conversation becoming crackly, move closer to the base. To reach optimal range, place the base station away from electrical appliances.

Battery life in standby mode	Battery life in communication	Indoor range	Outdoor range
up to 200 hours	up to 15 hours	up to 50 metres	up to 300 metres









# Introduction



## Philips screen saver



After 2 minutes of inactivity, the screen saver is displayed:  
You can deactivate it (see p.30)

## Idle mode

In idle mode, the DECT 511/515 display shows various information:


- The date & time, the name of the handset and the instructions to access the menu.
- Missed calls , new SMS  or new messages  (answer machine) or network voicemailbox message , if any.
- "Do Not Disturb" mode , and the alarm clock , if activated.



To activate/deactivate these functions press  or 










## Understanding the menu system



To access the carousel menu from idle mode, press  on the side of the handset. The carousel represents a loop of icons that gives access to the different first level menus.

Scroll up or down  to reach the desired menu and select .

The sub menus are listed and represented by little squares  at the bottom of the display. To reach one particular sub-menu use the "pilot key"  and press  to validate your choice. A "tick"  shows the selected sub-menu or option. The  shows the option you are browsing.

Note: some menus are also directly accessible via a dedicated key on the keypad like the SMS menu with  or the Intercom with .



## How to navigate in the menus




Press to access the carousel menu



Scroll to Sounds, and select 




Scroll to Handset ring tone vol. and select 



The current level is heard, browse  to hear other levels



Browse through the levels and select one 



## Basic principles

### To make and to answer a call

#### Pre dialling



Dial the number



Make the call

#### Direct dialling



Press the key



Dial the number

#### Answer a call

When ringing



Take the line

### To call from the phonebook



Scroll down to directly access Phonebook



Choose a name in the list



Make the call or press **+>** to select Call in the options



### To store a name from predial



Dial the number



Press to enter the options



Scroll to Store and select **+>**



Enter the name and press **+>**OK



### To store an SMS



Dial the number



Press to enter the options



Scroll to Send SMS and select **+>**



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS settings** page 25




Enter the Destination box\* and press **+>**OK



Enter the text and press **+>**



Scroll to Store and select **+>**



### Redial from call log




Scroll up to directly access Call log and select **+>**




Choose an entry in the list



Make the call or press **+>** to select Call in the options



## In call features

During an external call, some other options are available. Press  to enter Options.

### To mute the handset microphone



Press to enter Options



Press to select Mute (the caller can no longer hear you)



Press again to resume the conversation (End mute)



### Intercom (available only if you have at least two handsets)

During an external call, you can use the intercom in-call option to call another handset and for example transfer the call to this handset.



Press to enter Options



Scroll to Intercom (the caller can no longer hear you)

If there is only one additional handset it rings automatically, otherwise select a handset from the list.



Press Transfer when the second handset has taken the line.



Other options are available such as Switch and Conference call (see page 38).

### To record a conversation (DECT 515 only)



Press to enter Options



Scroll to Record and select 



To listen to the conversation, go to the call log menu or the messages list

### To switch the handset loudspeaker ON/OFF

Press  to activate or deactivate the handset loudspeaker

**Warning** : Handsfree activation could suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.

### To increase/decrease the handset & earpiece/loudspeaker volume during a call





Scroll up to increase or down to decrease the volume when on line

There are 5 volume levels available. The last setting is stored for the next calls.

### To access the phonebook or the call log

Press  to enter the options. Scroll to Phonebook or Call log and select 




### Caller Line identification and Call waiting



If you subscribe to the Call waiting service, a beep in the earpiece informs you of a second incoming call. The name or number of the second caller may be displayed if you also subscribe to Caller Display service. To answer that second call, use  +  (according to your network, the code may be different). Please contact your network provider for more details.


## Case mode

By default, the first letter of a sentence is in upper case. Use  to change the case mode:

- all letters in upper case (AB)
- all letters in lower case (ab) or
- the first letter in upper case and the rest of the word in lower case (Ab).

Punctuation and mathematical marks are available through  and  while other special characters are also available on  (see table page 20).

Scroll  to move the cursor left or right. Press  to delete a character ; a long press deletes the whole text.

DECT 511/515 uses two editing systems : Multi-tap and Eatoni<sup>®</sup>. While editing, a long press on  enables you to switch between the two systems.


## The standard multi-tap system

This system allows you to enter the text character by character, pressing the corresponding key as many times as necessary to reach the desired character.

**The Eatoni<sup>®</sup> system** is a predictive editing system designed to help you to write an SMS. A little E in the header helps you to know the mode you are using.

Eatoni<sup>®</sup> is a word editor that chooses the most probable letter.

The operation of the Eatoni<sup>®</sup> system is the following:

Press the key that displays the character you want to edit. The character that is most likely to be correct is displayed on the screen. If it does not match the expected letter, press  to display the next most probable character available on the key.

Let's compare Multitap and Eatoni<sup>®</sup> systems to write "Peter".

To write "Peter" with multi-tap

Press  once : P

Press  twice : Pe

Press  once : Pet

Press  twice : Pete

Press  three times : Peter

Keypad Keys	Multi-tap Sequence
1	[space] 1 @ _ # = < > ( ) & ∞ £ \$ ¥ [ ] { } ∞ \$
2	a b c 2 à ä ç å æ
3	d e f 3 è é Δ φ
4	g h i 4 ì Γ
5	j k l 5 Λ
6	m n o 6 ñ ò ö
7	p q r s 7 β Π Θ Σ
8	t u v 8 ù ü
9	w x y z 9 f Ω Ξ Ψ
0	. 0 , / ; " ' ! ; ? ; * + - % \ ^ ~

To write "Peter" with Eatoni<sup>®</sup>



Long press  to activate Eatoni<sup>®</sup>



Press 



Press  to change character



Press 



Press 




Press 



Press 




Press  to validate the name

Eatoni<sup>®</sup> & LetterWise are trademarks of Eatoni Ergonomics, Inc. and used by Philips under license.



- Send new SMS
- Read SMS
- SMS settings

SMS menu is also accessible via the carousel or 

Important information are also available on the SMS leaflet in the box

SMS stands for Short Message Service. To benefit from this service you must subscribe to the Caller Line Identification Service (CLI) together with the SMS service from your network provider. SMS can be exchanged with a phone (mobile or compatible fixed lines) provided the receiver has also subscribed to the CLI & SMS services.

Your DECT 511/515 factory settings correspond to the main national operator. If you wish to send or receive SMS through another service provider you must set the corresponding numbers (see page 27 and the SMS leaflet).

A password can protect your SMS box\*, but it is not compulsory.

To send an SMS to the receiver's own SMS box\*, you must know his destination box.

## Send new SMS

### To send an SMS to a phone


sms

Press to directly reach Send new SMS and select 





Select your SMS box\* (only if you have created several SMS boxes). To create a SMS box please refer to **SMS settings** page 25




Enter the password if any and press OK (optional)



Enter the phone number directly and press OK or press  to retrieve the number from the Phonebook



Enter the Destination box\* number (optional), press OK.  
**Note:** the destination box is the SMS box of the receiver.







Enter the text and press  (see page 19)



Press to select Send now, otherwise





if you want to store your SMS, scroll to Store and select .  
The SMS stored can be later retrieved from Read SMS



The sent SMS can be up to a maximum of 160 characters long. The special characters **␣**, **]** and **[** count for 2. The DECT 511/515 can store 25 SMS for the 3 boxes\*.



## Read SMS

The SMS list contains the stored and received SMS.  
The received SMS are shown by  and the stored SMS are shown .

### To read an SMS/to view the number



Press to directly reach Send new SMS

Scroll to Read SMS and select 



Select your SMS box\* (only if you have created several SMS boxes).  
To create a SMS box please refer to **SMS settings** page 25

Enter the password if any and press OK (optional)

Browse the list of SMS and select 

Press to select Read SMS

or scroll to View number and select 



When reading the list of received SMS, some options are only available for SMS received from a phone. Those options are Reply, Forward, Copy to phonebook, Call and View number. The options Reply and Copy to phonebook use the sender's own sub-address.

### To save a ring tone only available in the UK

This option enables to save a downloaded ring tone in your handset or in your base station (only available for DECT 515 base station) received through an SMS. This saved ring tone will be then inserted in the menu Sounds in the list of My ring tones (see p. 50).



Press to directly reach Send new SMS

Scroll to Read SMS and select 

Select your SMS box\* (only if you have created several SMS boxes).  
To create a SMS box please refer to **SMS settings** page 25


Enter the password if any and press OK (optional)

Browse the list of SMS and select  the SMS containing the ring tone

Press to select Read SMS

Press to select Save ring tone

Press to select Handset or scroll to Base station and select 





## To reply to an SMS

sms



Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).  
To create a SMS box please refer to **SMS Settings** page 25



Enter the password if any and press OK (optional)



Browse the list of SMS and select the one you want to reply to





Scroll to Reply and press



Enter the text and press



Press to select Send now



## To forward an SMS

sms



Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).  
To create a SMS box please refer to **SMS Settings** page 25



Enter the password if any and press OK (optional)



Browse the list of SMS and select the one you want to forward



Scroll to Forward and press



Enter the number and press OK



Enter the Destination box\* number (if any) and press OK

You can modify the text if necessary or select



Press to select Send now



**Warning:** for copyright reasons, it is strictly forbidden to forward a downloaded ring tone.





## To send again

sms

Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS Settings** page 25



Enter the password if any and press OK (optional)



Browse the list of SMS and select the one you want to send again



Scroll to Send again and press



## To delete an SMS

sms

Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS Settings** page 25



Enter the password if any and press OK (optional)



Browse the list of SMS and select the one you want to delete



Scroll to Delete SMS and press



Press OK to confirm



## To copy a number to the phonebook

sms

Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS Settings** page 25



Enter the password if any and press OK (optional)




Browse the list of SMS and select



Scroll to Copy to phonebook and select



Enter the name and press OK





## To call from the SMS list

sms

Press to directly reach Send new SMS



Scroll to Read SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS Settings** page 25




Enter the password if any and press OK (optional)



Browse the list of SMS and select



Scroll to Call and select or make the call



## SMS settings

### To set the SMS mode

If there are 2 SMS-enabled phones on your telephone line, you will have to deactivate the SMS feature on 1 of the devices.

sms

Press to directly reach Send new SMS



Scroll to SMS settings and select



Press to select Mode



Press to select On or scroll to OFF and select



### To set your personal SMS boxes only available in the UK

sms

Press to directly reach Send new SMS



Scroll to SMS settings and select



Scroll to SMS boxes and select





Scroll to Add new and select



Enter the SMS box number and press OK














Enter the password twice and press OK (optional)















## To change the password of an SMS box only available in the UK

-  Press to directly reach Send new SMS
-  Scroll to SMS settings and select 
-  Scroll to SMS boxes and select the one for which you want to change the password 
-  Press to select Change password 
-  Enter the old password and press OK
-  Enter the new password twice and press OK









**Note:** If you forgot your password you can delete the corresponding SMS box

## To delete an SMS box only available in the UK

-  Press to directly reach Send new SMS
-  Scroll to SMS settings and select 
-  Scroll to SMS boxes and select the one you want to delete 
-  Scroll to Delete and select 
-  Press OK to confirm 

**Warning:** when an SMS box is deleted, all the SMS contained in this box are deleted at the same time.

## To choose by default an SMS centre

-  Press to directly reach Send new SMS 
-  Scroll to SMS settings and select 
-  Scroll to SMS centre and select , choose an SMS centre 
-  Press to select Choose by default



## To set the SMS centre number(s)

The SMS are sent through a centre. To receive an SMS from another operator, you must set the corresponding numbers.

sms



Press to directly reach Send new SMS



Scroll to SMS settings and select




Scroll to SMS centre and select



Choose an SMS centre and select




Scroll to Edit incoming number and select



Enter the number and press OK



Scroll to Edit outgoing number and select



Enter the number and press OK



## Handset

- Babysit mode
- Registration
- Rename handset
- Date & time
- Display contrast
- Backlight
- Screen saver

## Babysit mode

if there are at least 2 handsets

This feature allows you to monitor the baby's room. Place the handset in the room to be monitored and you will hear the noise coming from the room on the additional handset.

### To activate/deactivate the babysit mode

- Press to enter the carousel menu
- Scroll to Handset and select
- Press to select Babysit mode
- Select ON or scroll to OFF and select



An intercom is necessary to monitor the room (see page 38).

**Note:** during an intercom, you can still answer a call or make a call with the handset

## Registration


Up to 6 handsets can be registered to the base station. 1 handset can be registered to 4 base stations.

**Warning:** If you wish to associate non Philips handsets to the DECT 511 or DECT 515 base station, make sure that this handset is GAP compliant otherwise it will not operate properly (see p 13).

### To register a handset

Unplug and plug back in the mains lead to put the base in registration mode

- With the additional handset, press to start the registration
- Enter the 4-digit RC code written on the sticker placed under the base station and press OK



### To unregister a handset

- Press to enter the carousel menu
- Scroll to Handset and select
- Scroll to Registration and select
- Scroll to Un-register handset and select
- Choose the handset to un-register from the list and press OK
- Enter the 4-digit RC code and press OK












**Note:** should you have your handset serviced alone, please make sure it is unregistered from the base station before taking it back to the repair centre.



## To select a base station

Each DECT 511/515 handset can be used with up to 4 base stations.

To use a handset with another base station, the handset must be first registered to that base station.









-  Press to enter the carousel menu
-  Scroll to Handset and select 
-  Scroll to Registration and select 
-  Scroll to Base selection and select 
-  Choose the base from the list and press OK




**Warning:** the handset will automatically operate with the last base station to which it was registered. If the handset is out of range, it will automatically search for another base station from the list.

## Rename handset













### To rename a handset


-  Press to enter the carousel menu
-  Scroll to Handset and select 
-  Scroll to Rename handset and select 
-  Long press to delete the current name
-  Enter the name and press OK



## Date & time

### To set the date and time

-  Press to enter the carousel menu
-  Scroll to Handset and select 
-  Scroll to Date & time and select 
-  Select Set date
-  Enter the current date and press OK
-  Scroll to Set time and select 
-  Enter the current time and press OK




**Warning:** If your phone is connected to an ISDN line through an adaptor, the date & time may change after each call. Please check the date & time settings in your ISDN system. Please contact your network provider (see FAQ p.56).



## Display contrast

To set the display contrast


- Press to enter the carousel menu
- Scroll to Handset and select
- Scroll to Display contrast and select
- Browse through the levels and select the appropriate one



## Backlight

To set the display backlight duration or deactivate it

- Press to enter the carousel menu
- Scroll to Handset and select
- Scroll to Backlight and select
- Browse through the durations OFF / 10 seconds / 20 seconds and select




## Screen saver

After 2 minutes of inactivity, the screen saver is displayed. You can choose to activate or deactivate it

To activate or deactivate the screen saver

- Press to enter the carousel menu
- Scroll to Handset and select
- Scroll to Screen saver and select
- Press to select ON or scroll to OFF and select





## Answer machine










- Saved messages
- Record a memo
- Outgoing messages
- Answerphone settings


The DECT 515 includes an answer machine that records the calls when it is activated. You can reach the answer machine from the base station or the handset.

By default, the answer machine is activated. It can store up to 25 messages within the maximum recording time of 30 minutes. A message can be up to 3 minutes long.

### To switch the DECT 515 Telephone Answer Machine ON/OFF

From the handset

-  Press to enter the carousel menu
-  Scroll to Answer machine and select 
-  Scroll to Answerphone settings and select 
-  Press to select Mode
-  Press to select ON or scroll to  OFF and select 



From the base station

A press on  activates or deactivates the answer machine. Once activated, the red indicator is lit.

## Saved messages


You can listen to new or saved messages via the handset or the base station.

### To listen to new message(s) via the handset

The display shows that there is 1 or more new messages(s) (1 .

Press  to view.

The message is automatically played.




**Note:** the entry shows the number of times the caller tried to reach you. If you have subscribed to the Caller Identification Service (CLI), the display shows the name of the caller and its group if activated (see page 39).





## To play and browse through saved message(s) via the handset

- ➡️ Press to enter the carousel menu
- 🔍 Scroll to Answer machine and select ➡️
- ➡️ Select Saved messages, the message which was recorded first is automatically played
- ➡️ Press ➡️ to access the Options
- ➡️ Press to select Play
- 🔍 To go to next or previous messages, scroll to Next message or Previous message and select ➡️



**Note:** you can listen to the message(s) via the Call log. Scroll up to access Call log and scroll to choose the message from the call log list. The entry is marked ➡️ (see page 42).

## To play and go to next saved message(s) via the base station

- ▶️ Press to play a message and press once again to stop a message while listening
- ▶️▶️ Press to go to the next message while listening. Make a long press to fast forward the messages while listening

## To delete a message via the handset

- ➡️ Press to enter the carousel menu
- 🔍 Scroll to Answer machine and select ➡️
- ➡️ Select Saved messages, the message which was recorded first is automatically played
- ➡️ Press ➡️ to access the Options
- 🔍 Scroll to Delete and select ➡️
- ➡️ Press ➡️OK to confirm



## To delete a message via the base station

- Press  to delete the current message.
- Make a long press to delete all the messages (except unread ones)









The other options available from the handset are Call (if number is displayed), Store (if number is displayed) and Send SMS (if number is displayed).





## Settings

### To select the answer mode and the outgoing message (OGM) type

You can select among 2 answer modes : Answer only (when no messages can be left) and Answer & record (when messages can be left). For each mode, 2 outgoing message types are available: predefined or personal message. By default the answer machine is set to Answer & Record with predefined OGM.

-  Press to enter the carousel menu
-  Scroll to Answer machine and select 
-  Scroll to Outgoing Messages and select 
-  Select Answ. machine mode
-  Choose the appropriate mode among the 4 options above (2 answer modes and 2 outgoing message types) and select 



















**Note:** a predefined message cannot be deleted

### To record your personal outgoing message (OGM)

You can record 5 different personal OGM: a specific personal OGM for Answer & record mode for each group (A, B or C), the standard OGM for Answer & record mode for normal callers (not belonging to any group) and the standard OGM for Answer only mode for all callers. It is possible to record specific messages for specific groups only if you subscribe to the Caller Line Identification service (CLI) and if you have set the groups in the phonebook (see page 41).

**You can also download outgoing messages through an online service (see Leaflet "Download of ring tones and answerphone messages")\*.**

-  Press to enter the carousel menu
-  Scroll to Answer machine and select 
-  Scroll to Outgoing Messages and select 
-  Scroll to Record outgg msg and select 
-  Choose between the different type of OGMs and the various groups and press 
-  Scroll to Record new and select 
-  Press  to start recording and once again to stop recording





The message is automatically played back. You can delete and/or record it again. The personal message can be up to 1 minute long

**Note:** Select Standard OGM for answer only mode or Standard OGM for Answ. & Record mode if you have no CLI subscription.

**Warning:** Please make sure that you have selected the appropriate answering machine mode (refer to page 33 “**To set the answer mode and the outgoing message type**”)

### To set the number of rings before answering

You can set the answer machine to start playing the outgoing message after a given number of rings (3, 5, 7 or Toll saver). The toll saver option (activated by default) is useful when using the remote access. The answer machine will start playing the outgoing message after 3 rings if there are new messages. If there is no new message the outgoing message will be played after 5 rings. Hang up after the 4th ring if you want to check if you have any messages at no cost.



Press to enter the carousel menu



Scroll to Answer machine and select




Scroll to Answerphone settings and select



Scroll to Number of rings before answering and select



Choose between Toll saver, 3 rings, 5 rings or 7 rings and select



### To set the voice language

You can change the language of the predefined message (OGM).



Press to enter the carousel menu



Scroll to Answer machine and select




Scroll to Answerphone settings and select



Scroll to Voice language and select



Choose the appropriate language among the list and select






## To set the call screening

This feature allows you to activate or deactivate the base station loudspeaker so that you can choose whether to hear or not the callers leaving a message. You can set permanent call screening on the base station.

- ➔ Press to enter the carousel menu
- 📞 Scroll to Answer machine and select ➔
- 📞 Scroll to Answerphone settings and select ➔
- 📞 Scroll to Call screening and select ➔
- ➔ Press to select Off or scroll to 📞 Low, Medium, High or Boost and select ➔





**Note:** this feature is activated by default on Medium level.

Call screening "call by call" on the handset is also possible. While the caller is leaving a message, press ➔ to listen and press ➔ again to stop listening. Adjust the volume with 📞.

## To set the recording quality


There are 2 recording qualities: standard and high. In standard quality the total capacity is 30 minutes and in high quality the capacity is up to 15 minutes.

- ➔ Press to enter the carousel menu
- 📞 Scroll to Answer machine and select ➔
- 📞 Scroll to Answerphone settings and select ➔
- 📞 Scroll to Recording quality and select ➔
- 📞 Choose between High or Standard and select ➔



## To activate and deactivate the remote control

- ➔ Press to enter the carousel menu
- 📞 Scroll to Answer machine and select ➔
- 📞 Scroll to Answerphone settings and select ➔
- 📞 Scroll to Remote control and select ➔
- ➔ Select Mode
- ➔ Press to select ON or scroll to 📞 OFF and select ➔



**Note:** the default setting is OFF. Activate this feature if you want to be able to remotely use the answer machine.



## To remotely control your answer machine

To remotely access your answer machine :

- from another phone dial home
- if your answer machine is on, during or after the message press the star \* key on the handset ; if your answer machine is off, you will hear a beep after 45 seconds, then press the star \* key
- dial your remote control code (the default code is the registration code RC)
- if you have new messages they will be automatically played.

The following table indicates the features available when remotely accessing the answer machine.

Record memo	dial 0	Delete	dial 6
Play previous message	dial 1	Activate answer machine	dial 7
Play message	dial 2	Stop	dial 8
Play next message	dial 3	Deactivate	dial 9
Listen again	dial 5		

## To change the remote control code

The default code is the registration code. We advise you to personalize it.



Press to enter the carousel menu



Scroll to Answer machine and select



Scroll to Answerphone settings and select






Scroll to Remote control and select



Scroll to Change code and select




Delete the default code, enter your new remote control code and press OK












## Record and listen to a memo



This feature allows you to leave local messages for your family on the answer machine. A memo is recorded from the handset, it is represented by  in the call log and can last up to 3 minutes.

### To record a memo

-  Press to enter the carousel menu
-  Scroll to Answer machine and select 
-  Scroll to Record a memo and select 
-  Press to start recording and once again to stop



### To listen to a new memo

The display shows there is 1 new local message (1 ). Press  to View. The message is automatically played. Delete is also available in the options (see page 32)

### To listen to a saved memo

You can use the Answer machine sub menu Saved messages and select Play or listen to a new or a saved memo through the base station (see page 32).



## Intercom

Call all

Intercom menu is accessible via the carousel or

*Handset list*

## Using the Intercom (if there are at least 2 handsets)

This feature allows you to make free internal calls, transfer external calls from one handset to another, use the conference option and the babysit feature (room monitoring).

### Internal call



Press to call the selected handset + handset number (for example )



Hang up

**Note:** If the handset does not belong to the Philips DECT 511/515 range, this function may not be available.

### Fast call transfer when on line

During a call you can transfer the call without waiting for the other handset to pick up. All the handsets will then ring.



Press to call the other handset



Hang up

**Note:** the person on hold hears music. A press on allows you to switch between the 2 calls.

### Call transfer to a specific handset when on line

During a call you can transfer the call to a specific handset.



Press to call the selected handset + handset number (for example )



Hang up

**Note:** the person on hold hears music. A press on allows you to switch between the 2 calls.

### Call transfer via the in-call options

During a call you can transfer the call via the in call options.



Press to enter the options (with handset 1).



Scroll to Intercom and select

If there is only one additional handset, it rings automatically. Otherwise:



Browse through the handset list and select the one you want to transfer the call to



The called handset rings. The external call is put on hold. If there is no answer from the called handset you can resume the call on the first handset.



Take the line on the called handset, both internal callers can talk



Press to select Transfer (with handset 1)

Scroll to Switch and come back to the external caller

**Note:** to answer the call on the second handset you can press .

### Conference call via the in-call options

Conference call allows one external call to be shared with two handsets (in intercom). The 3 people can share the conversation. No operator subscription is needed.



Press to enter the options (with handset 1)



Scroll to Intercom and select .

If there is only one additional handset, it rings automatically. Otherwise:



Browse through the handset list and select  the one you want to call.

The called handset rings. The external call is put on hold. If there is no answer from the called handset you can resume the call on the first handset.



Take the line on the called handset, both internal callers can talk



Scroll to the Conference call option and select .

The 3 people can share the conversation.

**Note:** to answer the call on the second handset you can press .

### To initiate the babysit (room monitoring) if there are at least two handsets

To use the babysit mode feature you need to activate it (see page 28) & initiate an intercom. Place the handset in the room to be monitored and you will hear the noise coming from the room on the additional handset.




Press to enter the options



Scroll to Intercom and select .

If there is only one additional handset, it rings automatically. Otherwise:



Browse through the handset list and select  the one you want to call. The called handset rings.



Take the line on the called handset, the room monitoring can start.





## Phonebook

- Add new
- View

Phonebook menu is accessible via the carousel or 

65 names and numbers can be stored in the phonebook.

The phonebook contains all the information related to the callers, especially the group settings. The names and numbers are shared with all the handsets registered to your base.










### Group settings


There are 3 groups (group A, group B and group C). When ringing, the ring tone helps you identify the caller's group (see p.49) and the screen shows the caller's name. A subscription to the Caller Line identification is needed.

## Add new

The names are stored in alphabetical order.


### To add a name to the phonebook

-  Press to enter the carousel menu
-  Scroll to Phonebook and select 
-  Scroll to Add new and select 
-  Enter the number and press  OK
-  Enter the name and press  OK (see page 19 "Editing systems")



### To store a name and number from predial

Once the number is dialled, press  to reach the options, scroll to Store and select .







Enter the name and press  OK

## View

To quickly reach a name in the list, enter the first character (browse through the list if several names start with the same letter).












## To call




-  Scroll down to directly reach the list of names
-  Browse through the list of names and select  a name
-  Make the call
-  Or press to reach the options
-  And press again to select Call











## To change a number


-  Scroll down to directly reach the list of names
-  Browse through the list of names and select  a name
-  Scroll to Change number and select 
-  Press to erase the current number
-  Enter the new number and press  OK






**Note:** it is possible to erase the current number with . You can simply change any digit by moving the cursor  to reach the digit and press .

## To change a name

-  Scroll down to directly reach the list of names
-  Browse through the list of names and select 
-  Scroll to Change name and select 
-  Press to erase the current name
-  Enter the new name and press  OK



**Note:** it is possible to erase the current name with . You can simply change any letter by moving the cursor  to reach the letter and press .



**To define a group for a name and number** (see Group settings p.39)



Scroll down to directly reach the list of names




Browse through the list of names and select a name



Scroll to Select group and select



Browse through the groups and select



**To change the SMS box number** only available in the UK



Scroll down to directly reach the list of names




Browse through the list of names and select a name



Scroll to Change SMS box and select



Enter the destination box number and press OK



**To delete an entry**



Scroll down to directly reach the list of names



Browse through the list of names and select



Scroll to Delete and select



Press OK to confirm



**To send an SMS from the phonebook**



Scroll down to directly reach the list of names



Browse through the list of names and select



Scroll to Send SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS settings** page 25



Enter the password and press OK (optional)



Enter the Destination box\* number (optional), press OK





Enter the text and press OK (see page 19)



Press to select Send now



**Note:** once in the list of names, press  to directly edit an SMS



## Call log

- View
- Delete all
- Call log settings

Call log menu is accessible via the carousel or 

The call log can store up to 40 entries

-  : unanswered calls
-  : memo or recorded conversation\*
-  : messages\*
-  : outgoing calls
-  : answered calls
-  : messages (operator voice mail/if operator sends the information)

\* DECT 515 only

The call log shows the list of incoming calls.

If you have subscribed to the Caller Line Identification (CLI), you will also have the list of outgoing calls. In this case the name (or number) of the callers will be displayed. The date & time of the call are also shown.

## View

### To view the call log



Scroll up to directly reach the calls list



Browse through the list and read the information





### To listen to a message (DECT 515 only)



Scroll up to directly reach the calls list



Browse through the list and select  the entry marked with 



Select Play in the options



### To call / redial



Scroll up to directly reach the calls list



Browse through the list and select  an outgoing call entry\*\*



Press to call



Or press to select Call in the options



\*\* **Note** : to be able to call back a correspondent in the case of an incoming call, you need to subscribe to the Caller Line Identification service.



## To view the number




Scroll up to directly reach the calls list



Browse through the list and select an entry



Scroll to View number and select



## To store the caller's number



Scroll up to directly reach the calls list



Browse through the list and select an entry



Scroll to Store and select



Enter the name and press OK



## To delete a name and a number



Scroll up to directly reach the calls list



Browse through the list and select an entry



Scroll to Delete and select



Press OK to confirm your choice



**Warning:** if a message is associated to the entry, it is also erased from the answer machine, whether it is read or not (DECT 515 only). (see page 45)

## To send an SMS from the call log



Scroll up to directly reach the calls list



Browse through the list and select an entry



Scroll to Send SMS and select



Select your SMS box\* (only if you have created several SMS boxes).



To create a SMS box please refer to **SMS settings** page 25



Enter the password and press OK (optional)



Enter the Destination box\* number (optional), press OK





Enter the text and press **+↵**OK (see page 19)

Press to select Send now

**Note:** once in the list of names, press **Ⓜ** to directly edit an SMS

## Delete all

To delete all the call log




Press to enter the carousel menu

Scroll to Call log and select **+↵**

Scroll to Delete all and select **+↵**

Press to confirm **+↵**OK



**Note:** entries with unread messages will also be deleted (DECT 515 only).

## Call log settings

You can set the call log to store information about incoming calls and/or outgoing calls.





Press to enter the carousel menu

Scroll to Call log and select **+↵**

Scroll to Call log settings and select **+↵**

Press to select Incoming calls or scroll to **↵** Outgoing calls and select **+↵**

Browse through the options and select **+↵** the one that suits you





## Operator services

This feature allows you to activate or deactivate operator services that are subscription dependent. You need to set up codes (see page 56).

Contact your network operator for more details. You can usually subscribe to Call forward, operator voice mailbox etc...

### Example of service: Call forward

Calls can be redirected to another phone number. Set the code (see page 56) and activate it when necessary.

#### To activate call forward



Press to enter the carousel menu



Scroll to Operator services and select 



Press to select Call forward




Enter or retrieve from the phonebook the number to which



the calls are to be forwarded and press OK


The number is automatically chained to the call forward prefix and the system dials the number.



Operator Services  
Call forward  
00000000



Hang up



Thu 13 May 04 08:00  
Call forwarded  
+ ( View

From now on the calls will be redirected to the assigned phone number.

#### To deactivate call forward




Press to select View



Press to select Cancel



Hang up









Forwarded to:  
0243984341  
+ ( Cancel



## Extra

- Call duration
- Alarm clock
- Do Not Disturb mode












## Call duration


-  Press to enter the carousel menu
-  Scroll to Extra and select 
-  Press to select Call duration
- The total communication time is displayed
-  Press  to Reset the counter




## Alarm clock

### To set the alarm clock

-  Press to enter the carousel menu
-  Scroll to Extra and select 
-  Scroll to Alarm clock and select 
-  Scroll to Set day and select . Choose a day.
-  Scroll to Set time and select 
-  Enter the time and press OK



When the alarm rings, press any key to stop it. The snooze is then activated (will ring again every 5 minutes). To definitely stop it press 

### To activate / deactivate the alarm clock


A long press on  activates/deactivates the alarm clock with your own settings.





## To set the alarm ring tone type and ring tone volume

- Press to enter the carousel menu
- Scroll to Extra and select
- Scroll to Alarm clock and select
- Scroll to Settings and select
- Press to select Ring tones
- Choose among the available ring tones and select
- Scroll to Ring tone volume and select
- Choose among the available volume levels and select





## Do not Disturb mode

This feature allows you to screen calls after a certain time in the evening or when you do not want to be disturbed. Enter the time and select the group(s) allowed to call you. If none of the 4 groups is selected but the feature is activated, then nobody will be able to reach you. If the caller does not belong to an allowed group, the handset and base station will remain silent, while the caller will hear ringing. The answer machine (if activated) or the operator voice mail (network dependent) will answer the call. The feature is deactivated by default. You need to subscribe to the Caller Line Identification service (CLI).


### To set the Do not Disturb mode

- Press to enter the carousel menu
- Scroll to Extra and select
- Scroll to Do not disturb mode and select
- Scroll to Set day and select the day and press
- Scroll to Start time, enter the time and press OK
- Scroll to Stop time, enter the time and press OK
- Scroll to Allowed caller choice, activate the callers group(s) allowed to call you and select



**Warning!** Only allowed callers will be able to reach you during the selected day & time

A long press on activates/deactivates this mode with your own settings.











## Sounds

- Handset ring tones
- Base ring tones
- Group ring tones
- Handset ring tone volume
- Base ring tone volume
- My ring tones\*
- Record personal melody
- Settings









## Handset ring tones


### To set the external ring tone

-  Press to enter the carousel
-  Scroll to Sounds and select 
-  Press to select Handset ring tones
-  Press to select External ring tone
-  Browse through the list of ring tones and select  one










### To set the internal ring tone (ring tone for internal calls)


-  Press to enter the carousel
-  Scroll to Sounds and select 
-  Press to select Handset ring tones
-  Scroll to Internal ring tone and select 
-  Browse through the list of ring tones and select  one




## Base ring tones

only available for DECT 515

-  Press to enter the carousel
-  Scroll to Sounds and select 
-  Scroll to Base ring tones and select 
-  Browse through the list of ring tones and select  one






## Group ring tones

To set the group ring tones

There are 3 groups of callers (see p 40 Group settings). You can associate 1 ring tone to a group.

- Press to enter the carousel
- Scroll to Sounds and select
- Scroll to Group ring tones and select
- Scroll through the 3 different groups and select one
- Browse through the list of ring tones and select



## Handset ring tone volume

- Press to enter the carousel
- Scroll to Sounds and select
- Scroll to Handset ring tone vol. and select
- The current level is heard, browse through the levels to hear them
- Press to select the appropriate volume




**Warning :** We strongly advise to put the handset far from your ear when it is ringing.

## Base ring tone volume

only available for DECT 515

- Press to enter the carousel
- Scroll to Sounds and select
- Scroll to Base ring tone vol. and select
- The current level is heard, browse through the levels to hear them
- Press to select the appropriate volume





## My ring tones

only available in the UK

This menu gives access to all available downloaded ring tones. These ring tones can be set on your handset or on your base station (only available for DECT 515 base station) (see page 22). You can store up to 3 downloaded ring tones.

### To rename a downloaded ring tone (set on handset or on base station)



Press to enter the carousel



Scroll to Sounds and select



Scroll to My ring tones and select




Press to select Handset or scroll to Base station and select



Browse through the list of downloaded ring tones and select



Press to select Change name



### To delete a downloaded ring tone



Press to enter the carousel



Scroll to Sounds and select



Scroll to My ring tones and select




Press to select Handset or scroll to Base station and select



Browse through the list of downloaded ring tones and select



Scroll to Delete and select



## Record personal melody

only available for DECT 515

### To play a recorded melody



Press to enter the carousel





Scroll to Sounds and select



Scroll to Record pers. melody and select



Press to select Play



### To record a new melody




Press to enter the carousel



Scroll to Sounds and select




Scroll to Record pers. melody and select





Scroll to Record new and select

Press to start recording



### To delete a recorded melody




Press to enter the carousel



Scroll to Sounds and select



Scroll to Record pers. melody and select



Scroll to Delete and select



Press OK to confirm

## Settings

### To set the base loudspeaker volume only available for DECT 515



Press to enter the carousel




Scroll to Sounds and select



Scroll to Settings and select



Press to select Base loudspeaker vol.



Press to select the appropriate volume

### To set the earpiece tone



Press to enter the carousel




Scroll to Sounds and select



Scroll to Settings and select



Scroll to Earpiece tone and select




Browse through the options and select the appropriate setting




### To set the key & feedback tones

- +↵ Press to enter the carousel
- ↶↷ Scroll to Sounds and select +↵
- ↶↷ Scroll to Settings and select +↵
- ↶↷ Scroll to Key & feedback tones and select +↵
- +↵ Press to select ON or scroll to ↶↷ OFF and select +↵



### To set the notification beep


- +↵ Press to enter the carousel
- ↶↷ Scroll to Sounds and select +↵
- ↶↷ Scroll to Settings and select +↵
- ↶↷ Scroll to Notification beep and select +↵
- +↵ Press to select ON or scroll to ↶↷ OFF and select +↵



### To activate/deactivate the music on hold

The feature allows the caller to hear music when the call is put on hold when transferring a call from one handset to the other.

- +↵ Press to enter the carousel
- ↶↷ Scroll to Sounds and select +↵
- ↶↷ Scroll to Settings and select +↵
- ↶↷ Scroll to Music on hold and select +↵
- +↵ Press to select ON or scroll to ↶↷ OFF and select +↵





## Base station

- Enable registration
- Line settings
- Service code settings

## Enable registration

This feature allows you to register a DECT peripheral without keypad. Some DECT peripherals, such as repeaters, do not have any keypad. A special menu-operated procedure is used to register such peripherals to the base station. Also use the peripheral instructions to register it to the base

### To register a DECT peripheral



Press to enter the carousel menu



Scroll to Base station and select




Press to select Enable registration



Enter the peripheral code (RC code) and press OK

Follow the instructions in the peripheral manual



## Line settings

### To change the dial mode



Press to enter the carousel menu



Scroll to Base station and select




Scroll to Line settings and select



Press to select Dial mode



Press to select Tone or scroll to Pulse and select



Note: this setting allows you to select pulse dialling (also called “Loop disconnect” and used in countries without DTMF tone dialling capability or using old PABX)



### To change the recall type



- Press to enter the carousel menu
- Scroll to Base station and select
- Scroll to Line settings and select
- Scroll to Recall type and select
- Press to select Short flash or scroll to Long flash and select



**Note:** this setting is useful when using operator services. The use of some services accessed with  $\text{C}_m+1$ ,  $\text{C}_m+2$  and  $\text{C}_m+3$  (call waiting, call forward...) will depend on the flash setting (short/long) according to your installation type (ISDN, Public, PABX).

### To change the configuration

- Press to enter the carousel menu
- Scroll to Base station and select
- Scroll to Line settings and select
- Scroll to Choose country/oper. and select
- Browse through the countries and select the appropriate one.
- Browse through the operator type and select the appropriate one.



### To activate and deactivate the first ring

To prevent the phone from ringing when receiving an SMS, the first ring tone is deactivated. You can activate it.

- Press to enter the carousel menu
- Scroll to Base station and select
- Scroll to Line settings and select
- Scroll to First ring and select
- Choose between ON or OFF and select







## Service code settings

When you subscribe to extra services with your operator you may need to set some codes in your phone. The default codes are the codes used by the main national operator. If you subscribed to another operator you may need to change the codes. Contact your network operator for more information on the services.



Press to enter the carousel menu



Scroll to Base station and select




Scroll to Service code settings and select



Browse the list of services and select



Enter the code and press



**1/ I have no dialling tone after having installed my phone. How do I solve this problem?**

Check that you have connected your phone using the supplied line cable and not the one from any previous phone (they are often wired differently).

Check that you have fully charged the handset according to the instructions given for the phone.

Check that the aerial icon (radio link with the base station) is displayed. If the handset is not registered you may need to register it (see p.28).

**2/ Can the handset be left on the base all the time?**

Yes there is no "memory effect". The handset can be left on the base station for all current models using NiMh batteries.

**3/ Will my phone lose all recorded data (phonebooks entries, recorded messages) in the case of a general power cut?**

No it will not. The data recorded in your phone is not deleted in the case of a general power failure or when you unplug your base station or when you replace the batteries.

**4/ I have set up the date & time on my phone and the information given after a call is not correct. Why?**

If you have a ISDN phone installation, these parameters (date & time) may be transferred directly through the ISDN to the phone. If you did not set-up the ISDN correctly this can explain why the information transmitted is not correct. Set-up the date & time directly on the ISDN phone installation or, if this is not possible, call the Operator/dealer who provided and installed the ISDN.

**5/ I cannot use the answering machine of my Philips phone together with my Fax plugged into the same line, why is this?**

To avoid this, it is recommended to set up the number of rings before the answering machine switches on.

Example: if the network mail box or a fax is set to answer the calls after 4 rings, please set up your answering machine on 3 rings. To set up the number of rings, please see p 34.

**6/ What is CLI and how do I make it work?**

CLI stands for Caller Line Identification and it is a special service that you may subscribe to from your network operator. Once you have subscribed to the service, a CLI enabled phone will display the callers number (unless withheld) as the phone rings so that you may decide whether or not to take the call.

**7/ The CLI service does not work on my Philips phone, on my digital phone installation (ISDN, ADSL). How do I solve this problem?**

Our products are designed to work on an analogue network. If you plugged your PHILIPS phone into a digital installation, the CLI may not be displayed upon incoming calls. Digital phone installations (ISDN) are not always compatible with analogue phones as far as operator services are concerned.

You may find the information regarding compatibility in the user guide of your ISDN. If not, please contact the ISDN manufacturer to check if the device is designed to display CLI on analogue phones. ISDN over 2 or 3 years old are generally not compatible with analogue phones for the CLI Service.

Note that the filters used with some ADSL lines can filter out part of the CLI signal and prevent the phone from displaying CLI correctly. It is possible to purchase better ADSL filters that do not cause this problem.

## 8/ What is CNIP (Caller Name Identification)?

As with the CLI service this new feature is dependent on the Network and it has to be activated by your Operator (by subscription). It will allow you to have the name of the caller displayed upon an incoming call. This service may not be available from all Operators yet. We advise you to check with your Operator. NB. If the name of the caller is registered in your phonebook upon an incoming call it will be the name you have registered which will be displayed and not the one provided by the Operator. The data in your phonebook will have priority over the Operator's data in this particular case. The CNIP uses the same technology as for the CLI. Therefore the limits of this service are identical (please refer to the questions related to CLI if the service is not working properly). Remember that it only works with alphanumeric display.

## 9/ How many telephones can I have?

All items of telephone equipment have Ringtone Equivalence Number\* (REN), which is used to calculate the number of items which may be connected to any one telephone line.

Your DECT 511/515 has a REN of 1. A total REN of 4 is allowed, if the total REN of 4 is exceeded, the telephones may not ring.

With different telephone types there is no guarantee of ringing, even when the REN is less than 4.

## 10/ My answering machine does not record the messages left by my correspondents. How do I solve this problem?

Check the operator voice mail box is not activated. If it is activated, set the answering machine so that it starts recording first (set up the number of rings before the answering machine switches on).

## 11/ Which are the conditions required to be able to send an SMS ?

You must first have a subscription to Caller Display (CLI) service from your network operator as well as an SMS service subscription from the appropriate provider.

## 12/ Is it possible to write, read send or receive an SMS when the other handset is in communication (DECT 511 and DECT 515 multi-handset packs only)?

No it is not possible.

## 13/ What happens if I send an SMS to a fixed line with no SMS phone ?

The correspondent could receive a vocal message (SMS provider dependent).

## 14/ Is it possible to send an SMS to a fixed line in another country ?

This feature depends on your provider. Please contact your provider for more details.

## 15/ How can I get the SMS centre number ?

One SMS centre number at least is pre-programmed in your DECT 511/DECT 515. However, should you need to store another number, other numbers can be set into the phone from the menu SMS/SMS Settings/SMS centre. Please check the incoming and outgoing centre numbers with the SMS provider or from the enclosed addendum to your phone user manual.




## 16/ What is the destination box\* useful for ?

This is the number of a personal SMS box. It is a way to send an SMS to someone's personal box instead of sending it to the default box, which is a kind of common box. If you send an SMS without specifying an SMS box number (destination box), then the SMS will be sent to the default box if the receiver's phone deals with multi-boxes features (provider dependent).

## 17/ When using my SMS-enabled Philips phone with another SMS-enabled phone on the same line, can it cause any problems ?

Yes, this will prevent the phones from receiving SMS. You need to deactivate the SMS feature on one of the phones. Your DECT 511/DECT 515 has a feature which enables you to turn the SMS feature off. Go to menu SMS/SMS Settings/Mode/OFF


## Telephone troubleshooting

PROBLEMS	CAUSES	SOLUTIONS
The icon  does not scroll when the handset is placed on the base	<ul style="list-style-type: none"> <li>- Bad battery contact</li> <li>- Dirty contact</li> <li>- Battery is full</li> </ul>	<ul style="list-style-type: none"> <li>- Move the handset slightly</li> <li>- Clean the contact with a cloth moistened with alcohol</li> <li>- No need to charge</li> </ul>
No dialling tone	<ul style="list-style-type: none"> <li>- No power</li> <li>- Batteries are empty</li> <li>- You are too far from the base station</li> <li>- Wrong cable</li> <li>- Line adaptor not plugged to the line cord</li> </ul>	<ul style="list-style-type: none"> <li>- Check the connections. Reset the phone : unplug and plug back in the mains</li> <li>- Charge the batteries at least 24 hours</li> <li>- Move closer to the base station</li> <li>- Always use the cable provided</li> <li>- Plug the line adaptor to the line cord</li> </ul>
No ring tone	<ul style="list-style-type: none"> <li>- The ring tone is deactivated</li> <li>- The Do not Disturb mode is ON</li> </ul>	<ul style="list-style-type: none"> <li>- Increase the volume (page 50)</li> <li>- Deactivate it (page 48)</li> </ul>
The icon  does not appear	<ul style="list-style-type: none"> <li>- No mains power</li> <li>- The handset is too far from the base station</li> </ul>	<ul style="list-style-type: none"> <li>- Check connections</li> <li>- Move closer to the base station</li> </ul>
The icon  is blinking	<ul style="list-style-type: none"> <li>- Handset not registered to the base station</li> </ul>	<ul style="list-style-type: none"> <li>- Register the handset to the base (page 28)</li> </ul>
- Crackling on the line	<ul style="list-style-type: none"> <li>- You are too far from the base station</li> <li>- The base station is too close to electrical appliances, reinforced concrete walls or metal door-frames</li> </ul>	<ul style="list-style-type: none"> <li>- Move closer to the base station</li> <li>- Move the base station to find a better place (the higher the better)</li> </ul>
The handset displays 'not available' - when attempting to add another handset to the base station - when using a handset	<ul style="list-style-type: none"> <li>- The procedure to add a handset has failed, try again</li> <li>- Maximum number of handsets (6) has been reached</li> <li>- Base station is already busy with another handset (ie : phonebook)</li> </ul>	<ul style="list-style-type: none"> <li>- Disconnect and connect the base station power supply. Follow the procedure to register a handset (page 28)</li> <li>- Un-register a handset</li> <li>- Wait until it is available</li> </ul>
Noise interference on your radio or television	The DECT 511/515 base station or mains power pack are too close to electrical appliances	Move the power pack or base station as far as possible
Caller Line Identification (CLI) service does not work	- The service is not activated	- Check your subscription with your network operator

PROBLEMS	CAUSES	SOLUTIONS
A phonebook entry cannot be memorised	The phonebook is full	Delete an entry to free memory
No new SMS are received	<ul style="list-style-type: none"> <li>- SMS memory is full</li> <li>- The SMS mode is deactivated</li> </ul>	<ul style="list-style-type: none"> <li>- Delete old SMS</li> <li>- Activate it (p 25)</li> </ul>
No SMS can be sent or received	<ul style="list-style-type: none"> <li>- The outgoing or incoming SMSC number is not set or is wrong</li> <li>- The destination box* is wrong</li> <li>- SMS mode is OFF</li> <li>- You have no subscription</li> <li>- Another SMS-enabled phone is also on your line</li> <li>- There is a problem of compatibility between operators</li> <li>- The identity is withheld</li> </ul>	<ul style="list-style-type: none"> <li>- Refer to the SMS leaflet to get the correct SMSC's numbers</li> <li>- See point 16 page 58</li> <li>- Activate SMS mode (page 25)</li> <li>- Contact your provider for more information</li> <li>- Deactivate the SMS mode on one of the device.</li> <li>- Contact your provider for more information</li> <li>- Show identity</li> </ul>
No caller Id/ poor audio quality/Poor connection quality with broadband DSL internet	<ul style="list-style-type: none"> <li>- DSL filter(s)/splitter missing or insufficient number of filters</li> <li>- Modem &amp;/or phone plugged in the wrong DSL filter slot</li> <li>- Defective DSL filter(s)</li> </ul>	<ul style="list-style-type: none"> <li>- Make sure you have one DSL filter plugged directly on each line socket used in the house</li> <li>- Check the modem and the phone are plugged in the correct filter slot (one specific for each)</li> <li>- The filter(s) can be defective. Replace it/them and make another test</li> </ul>

only available in the UK

### Answer machine troubleshooting

PROBLEMS	CAUSES	SOLUTIONS
The answer machine does not record messages	<ul style="list-style-type: none"> <li>- The memory is full</li> <li>- The answer only mode is activated</li> <li>- The Answer &amp; record is not activated</li> </ul>	<ul style="list-style-type: none"> <li>- Delete messages</li> <li>- Select the Answer &amp; record mode</li> <li>- Press </li> </ul>
The remote control access does not work	The remote control access is not activated	Activate the remote control access (page 35)
It is not possible to record an outgoing message	The memory is full	Delete messages
The DECT 515 hangs up during remote access	<ul style="list-style-type: none"> <li>- 3 failed attempts to send a code</li> <li>- Duration is too long</li> </ul>	<ul style="list-style-type: none"> <li>- Enter the correct code</li> <li>- Manage the remote control quicker</li> </ul>
The answer machine stops automatically	<ul style="list-style-type: none"> <li>- The memory is full</li> <li>- Message exceeds 3 mn</li> </ul>	<ul style="list-style-type: none"> <li>- Play &amp; delete messages</li> <li>- Messages must not exceed 3 mn</li> </ul>

# Index

## A

Add new (phonebook) 40  
Alarm clock 47  
Answer a call 1, 17  
Answer machine settings 33

## B

Babysit mode 28, 39  
Base keys 4  
Base installation 15  
Batteries & battery life 15

## C

Call duration 47  
Call forward 46  
Call log settings 45  
Call transfer 38  
Call screening 35  
Change name 40  
Change number 41  
Choose country/operator 55  
Conference call 39  
Conformity 12  
Copy to phonebook 24

## D

Date and time 29  
Declaration of conformity 13  
Define groups 42  
Delete all (call log) 45  
Delete call log entry 44  
Delete an entry (phonebook) 42  
Delete an SMS 24  
Destination box 58 (n°16)  
Dial mode 54  
Display contrast 30  
Do Not Disturb mode 48

## E

Earpiece tone 52  
Edition mode 19  
Enable registration (DECT peripheral) 54

## F

FAQ 57  
First ring 55  
Forward SMS 23

## G

GAP 13  
Groups 40, 50

## H

Handset keys 2  
Handset ring tones 49

## I

Idle mode 16  
Intercom 18, 38

## K

Key & feedback tones 53  
Keypad lock/unlock 2

## L

Line settings 54  
Listening to messages (Answer machine) 31  
Local message (Memo) 37  
Loudspeaker 2, 18

## M

Make calls 17, 25, 41, 43  
Music on hold 53  
Mute 18

## N

Navigation in menus 16  
Notification beeps 53

## O

Outgoing messages 33

## P

PABX/PSTN 54  
Phonebook 40  
Predial 17  
Pulse 54

## R

Range 15  
Read SMS 22  
Recall type 55  
Recording quality 35  
Record conversation 18  
Record a memo 37  
Record personal melody 51  
Recording personal outgoing message 33  
Redial 17  
Register handset 28  
Remote access to answer machine 36  
Remote control code (answer machine) 36  
Rename handset 29  
Ring tone type (alarm) 48  
Ring tone volume (alarm) 48  
Rings before answering (Answer machine) 34

## S

Screening calls 35  
Screen saver 16, 30  
Send new SMS 21  
Send SMS (from phonebook) 42  
Send SMS (from call log) 44  
Service codes settings 56  
SMS box 25  
SMS centre 26, 27  
SMS mode 25  
SMS settings 25

## T

Toll saver (Answer machine) 34  
Tone 54

## U

Unpacking your DECT 511/515 14  
Unregister handset 28

## V

View the call log 43  
Voice language 34  
Volume (earpiece) 18  
Volume (ring tone) 50

© 2004

Philips Consumer Electronics

Home communication

All rights reserved

Printed in Hungary

[www.philips.com](http://www.philips.com)



**GB**

**IRL**

**3 111 285 21872**

# INFORMATION ON TEXT MESSAGING (SMS) IN EIRE

You must first subscribe to your network provider's Caller Display service.

Example : call EIRCOM free 1901.

**WARNING !** Change the operator type in your phone :

Go to **Base station** menu and select **Line Settings** sub menu.

Select the **Choose country/oper.** sub menu and choose the appropriate setting among the list (for example: Eircom).

Please refer to your phone user manual.

The network SMS centre numbers are automatically set in your phone on SMS

Centre 1:

Send SMS service number (Outgoing number) : 1740 9900

Receive SMS service number (Incoming number) : 0818 365 135

Contact your network provider for more information.

Registration to SMS service is done by sending your first SMS.

There is a charge for sending SMS text messages (contact your network provider for more information).

**REMINDER !** If there are two **SMS-enabled** phones on your telephone line, you will have to deactivate the SMS feature on one of the devices.

**SMS and Caller Display subscription** : The way to subscribe to and to connect to the Short Message Service (SMS) as well as the SMS function may be operator dependent and may vary in time. Please contact your network operator for more information. The following information is believed to be exact at the time of writing. It is provided for guidance only and does not guarantee accuracy over time.

**SMS and Caller Display disclaimer** : The Short Message Service and Caller Display features of your telephone terminal are network operator dependent. The terminal can provide them only if the network offers such features and if the user has subscribed to these features. Your phone has been carefully developed and tested according to the latest version of the SMS and CLI standards, and is up to date at the time of product release. However, Philips cannot take any responsibility and cannot guarantee the interoperability with the operator's network in case of standard modification, network modification and/or of incomplete or inaccurate implementation of the standard by the network's operator.



# INFORMATION ON TEXT MESSAGING (SMS) IN THE UK

You must first subscribe to your network provider's Caller Display service.

Registration to the SMS service is done by sending your first SMS.

There is a charge for sending SMS text messages (Contact your network operator for more information).

By default, your phone is set with the SMS centre 1 (British Telecom).

If you change this setting, the SMS service may not work.

**SENDING SMS FROM A FIXED LINE TO A FIXED LINE** : follow instructions in the user guide.

**SENDING SMS FROM A FIXED LINE TO A MOBILE** : follow instructions in the user guide.

**Warning** : When sending an SMS to a mobile phone, do not enter any destination box as your SMS will not be delivered.

**USING DESTINATION BOX ON YOUR PHONE** (not available on DECT 311) :

In order to receive an SMS in a specific SMS box, you must have previously sent at least one SMS from this box.

**REMINDER !** If there are two **SMS-enabled** phones on your telephone line, you will have to deactivate the SMS feature on one of the devices.

**SMS and Caller Display subscription** : The way to subscribe to and to connect to the Short Message Service (SMS) as well as the SMS function may be operator dependent, and may vary in time. Please contact British Telecom for more information. The following information is believed to be exact at the time of writing. It is provided for guidance only and does not guarantee accuracy over time.

**SMS and Caller Display disclaimer** : The Short Message Service and Caller Display features of the telephone terminal are network operator dependent. The terminal can provide them only if the network offers such features and if the user has subscribed to these features. Your phone has been carefully developed and tested according to the latest version of the SMS and CLI standards, and is up to date at the time of product release. However, Philips cannot take any responsibility and cannot guarantee the interoperability with the operator's network in case of standard modification, network modification and/or of incomplete or inaccurate implementation of the standard by the network's operator.

# PHILIPS

Personalise your Philips cordless telephone!

## 0906 666 0788

Download one of the latest top ringtones and answering machine messages for your telephone !

### TOP 30

- 13854 Adams Family
- 10002 Benny hill
- 37917 Boulevard of broken dream**
- 10027 Dawson's creek**
- 97573 If you leave me now
- 10008 I'll be there for you**
- 88301 Killamagiro
- 27246 Left outside alone
- 15028 Scooby Doo
- 10055 Magnum
- 10132 Mission impossible
- 75251 Only when I sleep
- 29326 Pretty woman
- 45208 Purple haze
- 55313 Ride it
- 74201 Round here
- 10017 Sesame Street**
- 15968 Stacy's mom**
- 10022 Teletubbies
- 15040 The Simpsons**
- 18223 Through the wire
- 20875 Tilt ya head back
- 21171 Toxic
- 59889 Unwritten
- 98530 Walk on by
- 18230 Yeah
- 79077 You can do it**

### RADIO HITS

- 4078 Aftermath
- 87299 Call on me
- 50106 Curtain falls
- 45515 Do they know it's Christmas
- 46413 Encore - Numb
- 95589 Enjoy the Silence**
- 57918 Everlasting love
- 62637 Flying
- 11710 Good vibration**
- 40446 I believe in you
- 98411 If there's any justice
- 97393 I'll stand by you
- 86955 Just lose it

- 89956 Lose my breath
- 19313 Misunderstood**
- 80367 My boo
- 94209 My prerogative
- 67265 Nothing hurts like love
- 01845 Obsession
- 59791 Out of the blue
- 08764 Right to be wrong
- 79527 Rip it up
- 10064 Room on the 3rd floor**
- 59740 Shark Tale**
- 45194 Sunday Morning**
- 59786 The weekend
- 35339 Thinking of you
- 68339 This is the last time
- 83402 What you're waiting for
- 40250 Wonderful**
- 39294 You won't forget about me

### TV SERIES

- 42034 Alf**
- 70717 Ally Mac Beal**
- 82141 Arnold and Willy
- 10127 Baa baa black sheep
- 42767 Batman**
- 10097 Baywatch
- 55679 Benny Hill
- 16381 Beverly hills 90210
- 10024 Bewitched
- 20452 Bold and beautiful
- 74307 Bonanza
- 79938 Buffy
- 79953 Charlie's angels
- 00053 Charmed
- 42033 Cosby show**
- 10006 Dallas**
- 02671 Davy Crockett
- 10126 Dharma & Greg
- 46428 Dynasty
- 10085 ER**
- 02611 Fraggle rock
- 70728 Friends
- 10015 Go Go !
- 02617 Goldorak go

- 79960 Happy days
- 82143 Hawai five
- 15393 He man**
- 80065 Inspector Gadget
- 10051 Lois and Clark
- 15003 Looney Tunes
- 80079 Love Boat**
- 46423 Man from U.N.C.L.E
- 10052 Married with children
- 15026 Maya the Bee
- 10013 Mc Gyver
- 23801 Melrose Place
- 10011 Monty Python Flying Circus**
- 10135 Murder, she wrote
- 09191 Ninja Turtles
- 16468 Quantum Leap**
- 10090 Rawhide
- 10091 Saved by the bell
- 10038 Star trek
- 10094 Streets of San Francisco
- 10084 Teletubbies
- 55773 The A Team
- 79940 The avengers
- 11003 The bridge on the river Kwai
- 22969 The Invaders
- 80071 The Knight Rider
- 80101 The little house on the prairie
- 10014 The Muppet show**
- 10083 The nary named Fran
- 54238 The Persuaders
- 10089 The prisoner
- 10081 The Saint
- 10000 The twilight zone**
- 21002 The young and restless
- 10021 Thunderbirds

### Answering machine messages

- 829432 TV Game show
- 829410 Army Man
- 829408 Alarm
- 800286 Hey ya - Hey you
- 800284 White Flag

## **The download of ring tones and outgoing messages (only available in the UK and depending on the network technical availability)**

To personalise your cordless telephone, there is nothing better than a melody and a message of your choice! Simply call 0906 666 0788 and that's it!

### **The download of ring tones**

First of all you must subscribe to the SMS function with your network provider (see **SMS leaflet**).

Just call 0906 666 0788 and follow the instructions!

You have chosen your ring tone? You are about to receive it by SMS. Then you will be able to download it on your telephone (see "**SMS**" chapter in the user manual, part "**Read SMS/To save a ring tone**"). Be careful, only three downloaded ring tones can be saved! If you wish to download another ring tone, you will have to delete one of them from "My ring tones" list (see "**SOUNDS**" chapter in the user manual, part "**My ring tones/To delete a ring tone**").

### **The download of outgoing messages (only available on DECT phones with answer machines).**

By default, your answer machine is switched on. You have to change its settings to the "Answer and Record with personalised OGM" mode (refer to "**ANSWER MACHINE**" chapter in the user manual, part "**Settings/To record your personal outgoing message**"). These two conditions are necessary to receive your message. Be careful! On the "Answer and Record with personalised OGM" mode, recording a new message will automatically delete the previous one. Before downloading an outgoing message, make sure your answer machine is not full.

Keep in mind your Remote Control code (RC) written under your base station (see the "**ANSWER MACHINE**" chapter in the user manual, part "**Settings/To change the remote control code**").

Just call 0906 666 0788 and follow the instructions!

Remember to free the line. Do not answer the next call and wait for your answer machine to record the message.

You can choose to welcome all the callers with this message or only the group of your choice. In this case, you must previously subscribe to the Caller Display Service offered by your network provider.

